ART

NOT

AVAILABLE

DLR STOCK MANDATORY STOCKING LIST

ссылка	Номер детали	Кол-во	Описание
	87414866	1	RELAY,
	121410A1	5	FUSE, 5 Amp
	121411A1	5	FUSE, 7.5 Amp
	121412A1	5	FUSE, 10 Amp
	121413A1	5	FUSE, 15 Amp
	121414A1	5	FUSE, 20 Amp
	121415A1	5	FUSE, 25 Amp
	121416A1	5	FUSE, 30 Amp
	325289A1	1	BELT, Water Pump, TJ480 / 530, T9050 / 9060
	87366407	1	BELT, Accessory Drive, Alternator & A/C, T9050 / 9060, TJ480 / 530
	87282333	1	BELT, Accessory Drive, T9030 / 9040, TJ380 /430
	355341A1	1	SWITCH, Clutch
	87357396	1	VALVE, SOLENOID, Pulse With Modulation
	87443710	1	FILTER, AIR, Primary
	87443713	1	FILTER, AIR, Secondary
	368459A1	2	RELAY, 70 Amp
	370632A1	1	TUBE,
	371739A1	2	COIL, Solenoid
	87409372	2	Head, Filter, Trans.
	375512A1	2	O-RING,
	375514A1	2	SEAL, OIL, PTO
	375553A1	2	GASKET,
	87408613	1	FILTER, CAB, Recirculated Air
	417927A1	1	SWITCH, Plunger, TJ380 /430, T9030 / 9040
	427581A1	1	GASKET, Master Clutch, T9030 / 9040, TJ380 /430
	428676A1	2	O-RING, Filter
	87408714	2	FILTER, Conical
	86018758	1	FILTER, HYDRAULIC OIL, Main Hydraulic (Below Battery)
	1931099	1	FILTER, ENGINE OIL, , TJ380 /430, T9030 / 9040
	441700A1	1	FILTER, Oil, TJ480 / 530, T9050 / 9060
	87395356	1	FILTER, FUEL, , T9050 / 9060, TJ480 / 530
	441702A1	1	FILTER, COOLANT, , TJ480 / 530, T9050 / 9060
	A186004	1	SENSOR, Engine RPM
	B505572	72	OIL, HYDRAULIC, 5 Gal

ART

NOT

AVAILABLE

DLR STOCK RECOMMENDED STOCKING LIST

ссылка	Номер детали	Кол-во	Описание
	43263	8	BOLT, Hex, M12 x 60, 10.9,
	392530	6	NUT, M16, Cl 10,
	9843612	2	BOLT, Hex, M20 x 100, 10.9,
	9846950	8	BOLT, Hex, M20 x 90, 10.9,
	14458081	2	O-RING, -122, Cl 7, 1.112" ID x .103" Thk,
	86624983	6	BOLT, Hex, M16 x 110, 10.9,
	86625266	12	WASHER, M17.5 x 30 x 4, HT,
	86637742	4	O-RING, -246, 70 Duro, 4.484" ID x .139" Thk,
	86639034	4	BOLT, Hex, M16 x 320, 10.9, Full Thd,
	86639145	2	BOLT, Hex, M20 x 130, 10.9,
	827-22080	10	BOLT, Hex, M22 x 80, 10.9, Full Thd,
	86639171	10	BOLT, Hex, M22 x 130, 10.9,
	86639318	10	WASHER,
	86639325	2	WASHER, M10 x 24.5 x 3, HT,
	177250A1	1	SWITCH, LIGHTS,
	228273A1	6	BOLT, M20 x 110, CL 10.9, Hub
	235676A1	1	CONNECTOR,
	239942A3	1	SEAL, Axle
	256305A2	1	POTENTIOMETER, Draft Control
	259012A1	1	POTENTIOMETER,
	86994156	2	FILTER, AIR, A/C
	87432424	1	SEAL, Axle
	279266A1	1	SWITCH,
	365414A1	1	MIRROR, Manual
	360580A1	1	MIRROR, Electric
	A177462	1	MIRROR, Interior
	324437A1	1	MIRROR, REPLACEMENT,
	329737A1	1	HOSE,
	87407241	1	HOSE, Lower Radiator, T9030 / 9040, TJ380 /430
	87437992	1	TUBE, Lower Radiator, T9050 / 9060, TJ480 / 530
	363226A1	1	BUMPER, Door
	87434676	1	SENDER UNIT, Fuel
	371737A1	2	VALVE, SOLENOID,
	371738A1	2	KIT, O-Ring
	375720A1	1	PIN, Drawbar, Cat. 4, 2"
	376530A1	2	SUPPORT, Step
	393878A1	1	PIN, Quick Release
	87454949	1	UNIT, Armrest Controller
	404450A1	2	SENSOR, Trans.
	451767A1	1	BEARING, Pillow Block
	87406903	2	COLLAR CLAMP,
	418506A1	1	SWITCH, Park Brake
	427514A1	2	SEAL, OIL,
	427524A1	2	BREATHER,
	428156A1	1	PLUG,

DLR STOCK RECOMMENDED STOCKING LIST

ссылка	Номер детали	Кол-во	Описание
	428159A1	2	SEAL, OIL,
	428165A1	2	O-RING,
	86000308	1	KIT, Spider Bearing, 8C
	435439A1	2	MOUNT, RUBBER,
	92269C1	2	LAMP, WORK,
	433479A1	1	CAP, Fuel
	L115548	2	CLAMP,
	L115549	2	CLAMP, , TJ380 /430, T9030 / 9040
	S8820S00F	2	SEAL, OIL,
	87409372	2	Head, Filter, Trans.

02-01 RADIATOR AND HOSES, TJ380 / 430 & T9030 / 9040



TJ430 TRACTOR (1/06-) - Engine

02-01 RADIATOR AND HOSES, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87416960	1	RADIATOR,
2	87407241	1	HOSE, Lower Radiator
3	87407250	1	CONNECTOR, HYD.,
4	L115549	2	CLAMP, Hose
5	87407233	1	HOSE,
6	L115548	4	CLAMP, Hose
7	87407248	1	CONNECTOR, HYD.,
8	86637719	1	FITTING, 90є, 1/4" Hose x 1/8" NPTF, Barbed, Elbow, 90, 1/4" ID x 1/8" ntpf
9	82039341	6	CLAMP, HOSE,
10	87445564	1	HOSE, Dearation Tank to Radiator
11	87521350	1	HOSE, Dearation Tank to Engine Vent
12	86624128	1	FITTING, 1/4" Hose x 1/8" NPTF, Barbed, Elbow, 90, 1/4" ID x 1/8" nptf
13	86625232	2	FITTING, 45є, 1/4" Hose x 1/8" NPTF, Barbed, 45, 1/4" ID x 1/8" nptf
14	87445129	1	HOSE, Engine Coolant Fill
15	87384580	1	TANK, Dearation
16	A170241	1	CAP, RADIATOR, 103 kpa
17	43234	6	BOLT, Hex, M8 x 25, 10.9,
18	86625263	7	WASHER, M8 x 20 x 1.6,
19	435458A1	1	HOSE, Dearation Tank to Recovery Bottle
20	87324174	1	BOTTLE, Recovery Coolant
21	238903A1	1	CAP, FILLER,
22	435460A1	1	HOSE, Overflow
23	86010402	1	CLAMP, 1/2", Insul, 3/8" Bolt,
24	43235	4	BOLT, Hex, M8 x 30, 10.9,
25	86624184	9	WASHER, M8 x 16 x 1.6,
26	412250	4	NUT, LOCK, M8 x 1.25, Cl 8,
27	87445127	1	TUBE, Engine Coolant Fill
28	86984443	1	FITTING,
29	87362758	1	BRACKET, Mounting
30	86508618	4	BOLT, Hex, M10 x 45, 10.9,
31	86625253	4	WASHER, M11 x 24 x 2,
32	507586	2	CLAMP, HOSE, #20, 0.81/1.75 Type F Worm,
33	257492	3	CLAMP, 9/16", Insul, 3/8" Bolt, 14.3mm
34	435421A1	2	STRAP, SECURING,
35	87311244	1	BRACKET, SUPPORTING, Mounting
36	86639209	6	BOLT, Hex, M8 x 35, 10.9,
37	9515003	2	BOLT, Hex, M10 x 30, 10.9, Full Thd,
38	86624176	7	WASHER, M10 x 20 x 2,
39	86500689	2	NUT, M10, Cl 10,
40	86508619	1	BOLT, Hex, M10 x 60, 10.9,
41	87304771	1	SPACER,
42	L19029	2	CLAMP, Double

02-03 RADIATOR MOUNTING AND SHROUD, TJ380 / 430 & T9030 / 9040



02-03 RADIATOR MOUNTING AND SHROUD, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87416960	1	RADIATOR,
2	87438150	1	SEAL, Foam
3	434023A1	1	SEAL, Lower Radiator
4	H434809	1	COCK, DRAIN,
5	320990A1	2	SEAL,
6	320126A1	1	SEAL,
7	87408084	1	SEAL, Top
8	328196A1	2	SEAL,
9	318842A1	1	SEAL,
10	627-8030	4	BOLT, Hex, M8 x 30, 10.9,
11	86625263	10	WASHER, M8 x 20 x 1.6,
12	43263	2	BOLT, Hex, M12 x 60, 10.9,
13	86625255	4	WASHER, M13.5 x 24.5 x 3, HT,
14	435433A1	4	WASHER, 13.5 x 44.5 x 3mm
15	L13142	2	BUSHING, Engine Mount
16	412126	4	NUT, LOCK, M12 x 1.75, Cl 8,
17	446410A1	1	FRAME ASSY,
18	9861444	10	BOLT, Hex, M10 x 20, 10.9, Full Thd,
19	86625253	10	WASHER, M11 x 24 x 2,
20	435465A1	2	MOUNT, RUBBER, Isolator
21	412085	2	BOLT, Hex, M12 x 80, 10.9,
22	320992A1	1	SEAL, Lower Frame
23	86639313	10	WASHER, M8 x 20 x 1.6,
24	412250	10	NUT, LOCK, M8 x 1.25, Cl 8,
25	361250A1	2	BRACKET, Mount
26	43362	5	NUT, M8, Cl 10,
27	414616A1	2	SEAL, Shroud
28	414617A1	2	SEAL, Shroud
29	414785A1	1	SHROUD, Fan

02-07 AIR INDUCTION SYSTEM, TJ380 / 430 & T9030 / 9040



TJ430 TRACTOR (1/06-) - Engine

02-07 AIR INDUCTION SYSTEM, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87444727	1	FILTER, AIR, See Figure: 02-09
2	214-32144	2	CLAMP, HOSE, 8.25/9.125 HD Worm, W/liner, Hose
3	87443802	1	HOSE, 8"
4	87443608	1	TUBE, Air Intake
5	87443670	1	CLAMP, COLLAR, Clamp
6	827-10100	1	BOLT, Hex, M10 x 100, 10.9,
7	832-10410	3	NUT, LOCK, M10 x 1.5, Cl 8,
8	895-11010	2	WASHER, M10 x 20 x 2,
9	87443716	1	PRESCREENER ASSY., Inc. 10
10	87443800	1	CLAMP, COLLAR,
11	87443148	1	DUCT, AIR, Intake
12	87443916	2	CLAMP, SPECIAL,
13	87437258	2	CLAMP,
14	87309822	1	BRACKET, SUPPORTING, Intake Support
15	231-1445	2	NUT, LOCK, 5/16"-18, GB, 5/16"
16	87310919	1	U-BOLT, 7"
17	495-11034	2	WASHER, 5/16", SAE,
18	87303963	1	TUBE, AIR INTAKE,
19	214-32128	1	CLAMP, HOSE, 7.25/8.125 HD Worm, W/liner, 8"
20	87342642	1	TUBE, AIR INTAKE, Rubber
21	214-3280	1	CLAMP, HOSE, 4.25/5.125 HD Worm, W/liner, 5"
22	87304386	1	HOSE,
23	214-3240	4	CLAMP, HOSE, 1.75/2.625 HD Worm, W/liner, 2.5"
24	87304384	1	HOSE,
25	87443913	1	VALVE, Check
26	87300581	1	CLAMP, Valve
27	827-8045	1	BOLT, Hex, M8 x 45, 10.9,
28	895-11008	3	WASHER, M8 x 16 x 1.6,
29	832-10408	2	NUT, LOCK, M8 x 1.25, Cl 8,
30	627-8030	1	BOLT, Hex, M8 x 30, 10.9,
31	827-10040	4	BOLT, Hex, M10 x 40, 10.9, Full Thd,
32	896-15010	10	WASHER, M10 x 24.5 x 3, HT,
33	896-15010	4	WASHER, M10 x 24.5 x 3, HT,
34	832-46410	4	NUT, LOCK, M10 x 1.5, Cl 8,
35	87521399	1	SUPPORT, Hood Rear
36	627-12040	4	BOLT, Hex, M12 x 40, 10.9, Full Thd,
37	896-11012	10	WASHER, M13.5 x 24.5 x 3, HT,
38	87389398	1	SUPPORT, Hood, If Used
38	87589707	1	SUPPORT, Hood, If Used
39	829-1412	3	NUT, M12, Cl 10,
40	627-12030	3	BOLT, Hex, M12 x 30, 10.9,
41	896-15012	3	WASHER, M12 x 28.5 x 4, HT,
42	728-16100	1	PIN, CLEVIS, M16 x 100, If Used
43	733-4032	1	PIN, SPLIT (COTTER), M4 x 32, If Used
44	353-408	2	PLUG, Dome, .750" hole, Nylon, Dome

ссылка	Номер детали	Кол-во	Описание
45	627-10020	6	BOLT, Hex, M10 x 20, 10.9, Full Thd,
46	858-10120	1	M10 x 120, CL10.9
47	87550203	2	BUSHING, GUIDE, Latch Pin
48	829-1310	2	NUT, M10, Cl 10,

02-09 AIR CLEANER ASSEMBLY



TJ430 TRACTOR (1/06-) - Engine

02-09 AIR CLEANER ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
1	87444727	1	FILTER, AIR, Cleaner, Inc. 2 thru 6, TJ380 /430, T9030 / 9040
1	87443705	1	AIR CLEANER, Cleaner, Inc. 2 thru 6, TJ480 / 530, T9050 / 9060
2	87367918	1	PRE-CLEANER ASSY, AIR, , T9030 / 9040, TJ380 /430
2	87368008	1	PRE-CLEANER ASSY, AIR, , T9050 / 9060, TJ480 / 530
3	87443710	1	FILTER, AIR, Primary Element
4	87443713	1	FILTER, AIR, Safety Element
5	S113982	1	CAP, Rubber
6	87443715	1	COVER, FILTER, Cover, Air , Inc. 7 - 11
7	87389246	1	HANDLE,
8	87341276	1	COVER, TOP,
9	627-6016	2	BOLT, Hex, M6 x 16, 10.9,
10	892-11006	2	WASHER, LOCK, M6,
11	829-1406	2	NUT, M6, Cl 10,

02-10 AIR COOLER MOUNTING, TJ380 / 430 & T9030 / 9040



TJ430 TRACTOR (1/06-) - Engine

02-10 AIR COOLER MOUNTING, TJ380 / 430 & T9030 / 9040

сылка	Номер детали	Кол-во	Описание
1	87306420	1	COOLER, Charged Air
2	251400A1	1	BELLOWS, LH
3	87306140	1	BELLOWS, RH
4	L124635	4	CLAMP, HOSE,
5	87303966	1	TUBE, AIR INTAKE, Charged Air, LH
6	87439767	1	TUBE, Charged Air, RH
7	87340760	2	HOSE ASSY.,
8	L116820	4	CLAMP, Hose
9	87304473	1	TUBE, AIR INTAKE, 90
10	238-6240	1	O-RING, -240, 90 Duro, 3.734" ID x .139" Thk,
11	87304529	1	CLAMP, SPECIAL, V-Band
12	832-10410	2	NUT, LOCK, M10 x 1.5, Cl 8,
13	895-15010	2	WASHER, M11 x 24 x 2,
14	434177A1	4	MOUNT, RUBBER,
15	496-41041	2	WASHER, 13/32" x 1 1/8" x .134",
16	827-10040	2	BOLT, Hex, M10 x 40, 10.9, Full Thd,
17	827-8110	2	BOLT, Hex, M8 x 110, 10.9,
18	895-15008	2	WASHER, M8 x 20 x 1.6,
19	496-41034	2	WASHER, .344" x 1" x .098", HDN, .344" x 1" x .098"
20	832-10408	2	NUT, LOCK, M8 x 1.25, Cl 8,

02-13 BLOCK HEATER



TJ430 TRACTOR (1/06-) - Engine

02-13 BLOCK HEATER

ссылка	Номер детали	Кол-во	Описание
1	196466A1	1	CABLE, ELECTRIC, 1829 mm (72 in)
2	87413582	1	HEATER, 120V, TJ380 /430, T9030 / 9040
3	19-135	1	STRAP,
4	338862A1	1	HEATER, 120V, T9050 / 9060 - For block heater gasket order P/N 3688557 from Cummins, TJ480 / 530 - For block heater gasket order P/N 3688557 from Cummins
5	9861444	2	BOLT, Hex, M10 x 20, 10.9, Full Thd, , TJ480 / 530, T9050 / 9060
6	86625251	2	WASHER, M10 x 18 x 1.6, , T9050 / 9060, TJ480 / 530

02-14 ENGINE MOUNTING AND ATTACHING PARTS, TJ380 / 430 & T9030 / 9040



02-14 ENGINE MOUNTING AND ATTACHING PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87440096	1	FAN, Viscous, 32"
2	87419100	1	PLATE, MOUNTING,
3	430406A1	1	DRIVE, Viscous Fan, 810 Series
4	896-11012	6	WASHER, M13.5 x 24.5 x 3, HT,
5	627-12030	6	BOLT, Hex, M12 x 30, 10.9,
6	87024879	12	WASHER, .344" x 1" x .098" Thk
7	627-8025	6	BOLT, Hex, M8 x 25, 10.9,
8	832-10408	6	NUT, LOCK, M8 x 1.25, Cl 8,
9	827-16160	2	BOLT, Hex, M16 x 160, 10.9, M16 x 160, CL10.9
10	86637662	2	WASHER,
11	435439A1	2	MOUNT, RUBBER,
12	435471A1	2	WASHER, .656" x 3.50" x .187" thk
13	86624156	2	WASHER, 21/32" x 1 1/2" x .188", HDN, .656" x 1.5" x .188" thk
14	832-10416	2	NUT, LOCK, M16 x 2, Cl 8,
15	827-20220	2	BOLT, Hex, M20 x 220, 10.9, M20 x 220, CL10.9
16	896-15020	2	WASHER, M20 x 44.5 x 5, HT,
17	379611A1	4	WASHER,
18	361187A1	2	ISOLATOR, Mount
19	379611A1	4	WASHER,
20	832-10420	2	NUT, LOCK, M20 x 2.5, Cl 8,

02-16 EXHAUST SYSTEM, TJ380 / 430 & T9030 / 9040



TJ430 TRACTOR (1/06-) - Engine

02-16 EXHAUST SYSTEM, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87443198	1	MUFFLER, without Spark Arrestor
2	87430632	1	ELBOW, Inc. 3
3	87430634	1	CLAMP, Muffler
4	357686A1	1	CLAMP,
5	87308233	1	TUBE, Double Wall
6	87406903	2	COLLAR CLAMP,
7	87376393	1	TUBE, Flexible
8	87439947	1	BRACKET, Support
9	87439948	1	U-BOLT, 6"
10	87362	2	WASHER, 5/16" SAE,
11	86050277	2	NUT, LOCK, 5/16"-18, GB, 5/16"
12	87308225	1	ELBOW, Exhaust
13	86639302	6	SCREW, 12 Pt Hd, M10 x 25, 12.9,
14	87527524	1	SHIELD, Debris
15	337475	2	NUT, M12, Cl 10,
16	86625256	2	WASHER, M12 x 28.5 x 4, HT,
17	87308232	1	SHIELD, Heat
18	9515003	2	BOLT, Hex, M10 x 30, 10.9, Full Thd,
19	86639325	6	WASHER, M10 x 24.5 x 3, HT,
20	87439927	1	BRACKET, Heat Sheild
21	43248	6	BOLT, Hex, M10 x 40, 10.9, Full Thd,
22	86500689	4	NUT, M10, Cl 10,
23	86625252	14	WASHER, M10 x 21.5 x 2.5, HT,
24	87308231	1	SHIELD, Manifold Heat
25	9846677	4	BOLT, Hex, M10 x 25, 10.9, Full Thd,
26	86636816	2	BOLT, CARRIAGE, M10 x 25, CL8.8
27	87527959	1	SHIELD, Debris
28	404824A1	AR	SHIM,
29	100037	4	NUT, M10 x 1.5, Cl 8,
30	87304384	1	HOSE, Aspirator
31	214-3240	2	CLAMP, HOSE, 1.75/2.625 HD Worm, W/liner,

02-18 ENGINE ASSY., TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-18 ENGINE ASSY., TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87434306	1	ENGINE, - ASSY (F3BE0684G*E901)
1	87434307	1	ENGINE, - ASSY (F3BE0684H*E901)
2	8094835	1	KIT, ENGINE OVERHAUL,
3	8094836	1	KIT, REPAIR,

02-19 CYLINDER BLOCK & RELATED PARTS, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-19 CYLINDER BLOCK & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504191027	1	- ASSY
2	504108192	14	SCREW,
2	99432869	25	SCREW,
2	99433863	1	SCREW,
3	99448193	6	GASKET, THK. 0.08 mm
3	99448192	6	GASKET, THK. 0.1 mm
3	99448190	6	GASKET, THK. 0.12 mm
3	500378983	6	GASKET, THK. 0.14 mm
4	99455400	6	GASKET,
5	500337911	6	LINER, ENGINE CYLINDER, STD
6	16991370	2	PLUG, D=45 mm
7	16990870	3	PLUG, D=28 mm
8	16990670	6	PLUG, D=20 mm
9	98474481	3	PLUG,
10	98475100	1	PLUG, R3/4X12
11	98472271	3	PLUG,
12	500368916	1	DOWEL,
13	99455401	12	GASKET,
14	99433597	3	SCREW,
15	99489019	1	WASHER, SEALING, D=16X24 X1.5 mm
16	99467554	4	DOWEL, D=14 mm
17	500356932	1	PLUG, M30X3 - 1/2"
18	16992415	1	PLUG, M16X1.5

02-20 OIL SUMP & RELATED PARTS, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-20 OIL SUMP & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504025626	1	SUMP, - ASSY
2	99489022	1	WASHER, SEALING, D=22 mm
3	16992611	1	PLUG, M22X1,5
4	504024777	1	GASKET,
5	99449984	1	SPACER,
6	99449985	1	SPACER,
7	16587524	16	SCREW, M10X45 mm

02-21 FLYWHEEL CASE, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-21 FLYWHEEL CASE, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504076809	1	HOUSING,
2	504087515	1	SCREW, M8X1,25
3	16991915	2	PLUG, M24X1,5
4	40102693	1	GASKET,
5	16588125	6	SCREW, M12X1.75X35 mm
5	16593625	2	SCREW, M12X1.75X120 mm
5	16587225	2	SCREW, M10X30
5	16600025	2	BOLT, M12X160
5	16593425	8	SCREW, M12X100 mm
5	16679435	1	BOLT, M12X130
6	99489023	2	WASHER, LOCK, 2AX35X1,5
7	99472521	1	COVER,
8	98474305	2	WASHER, SEALING, D=10X17 X2,3 mm
9	17275610	2	DOWEL,
10	504092448	1	COVER,
11	16892924	1	WASHER, LOCK, 8X17X1,6
12	16597925	2	SCREW, M8X14 mm
13	500322294	1	PLATE,
14	99448739	1	GASKET,
15	17292381	1	GASKET,
16	504002590	5	SCREW,
17	17297081	1	O-RING, 88,26X5,33
18	16587025	4	M10X20
19	504092930	1	COVER,
20	17293681	1	O-RING, 190,3X3,53
21	16585625	6	BOLT, M6X12

02-22 ENGINE BLOCK FRONT COVER, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-22 ENGINE BLOCK FRONT COVER, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	500304671	1	COVER,
2	17292581	1	SEAL,
3	16586225	8	SCREW, M8X1.25X16 mm
4	40102683	1	SEAL,

02-23 ENGINE SUSPENSION, TJ380 / 430 & T9030 / 9040





02-23 ENGINE SUSPENSION, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504081162	1	MOUNT, ENGINE, - RIGHT
2	504081176	1	MOUNT, ENGINE, - LEFT
3	99484191	12	SCREW,
4	504076929	1	BRACKET, SUPPORTING,

02-24 ENGINE BREATHERS, TJ380 / 430 & T9030 / 9040



KIT ● = 1



TJ430 TRACTOR (1/06-) - Engine

02-24 ENGINE BREATHERS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	500382997	1	BREATHER,
2	500383037	1	COVER,
3	500382999	1	GASKET,
4	500383189	1	GASKET,
5	500383042	25	SCREW,
6	500383040	1	FILTER, OIL COOLER,
7	500398649	1	GASKET,
8	500383043	2	GASKET,

02-25 CYLINDER BARREL LUBRICATION NOZZLE, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-25 CYLINDER BARREL LUBRICATION NOZZLE, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504101758	6	NOZZLE, LUB. OIL JET,

02-26 CYLINDER HEAD & RELATED PARTS, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-26 CYLINDER HEAD & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504021866	1	CYLINDER HEAD,
2	99476929	6	CASE,
3	17279081	12	GASKET, D=26.7X1.7 mm
4	500390993	12	GUIDE, VALVE, INTAKE, STD
4	500390864	12	VALVE, INLET, OVERSIZE, + 0,2
4	500390866	12	VALVE, INLET, OVERSIZE, + 0,4
5	504007514	1	GASKET,
6	17275510	2	DOWEL, D=10 mm
7	16992411	2	PLUG, M16X1.5
8	500390994	12	GUIDE, VALVE, EXHAUST, STD
8	500390860	12	VALVE, EXHAUST, OVERSIZE, + 0,2
8	500390861	12	VALVE, EXHAUST, OVERSIZE, + 0,4
9	98495527	20	SCREW,
9	98495528	6	SCREW,
10	504002605	12	CROSSRAIL,
11	99489019	2	WASHER, SEALING, D=9.2X1.7mm
12	99450511	12	VALVE SEAT, STD
12	504020517	12	VALVE SEAT, + 0,20
13	14196370	48	COTTER, ROCKER ARM,
14	99450512	12	VALVE SEAT, STD
14	504020515	12	VALVE SEAT, + 0,20
15	98473050	24	PLATE, COTTERS,
16	504003914	6	BUSHING,
17	504003915	1	BUSHING,
18	98472271	6	PLUG,
18	500310146	1	PLUG,
19	504100000	24	SPRING,
20	99430692	1	PLUG,
21	16991370	2	PLUG, D=45 mm
22	16990870	13	PLUG, D=28 mm
23	16990570	12	PLUG, D=20 mm
24	17257074	1	PIN, ROLL,
25	40101874	12	GASKET,
26	500355778	12	VALVE, ENG EXHAUST, STD,
27	500355780	12	VALVE, ENG EXHAUST, STD,
28	504107641	24	CUP,

02-27 HEAD COVER, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-27 HEAD COVER, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504041315	1	COVER,
2	500309014	1	GASKET,
3	99446693	24	BUSHING,
4	98442027	1	CAP, - ASSY
5	500309013	24	SCREW,
6	98412146	1	GASKET,

02-28 SHAFT & ROCKER ARMS, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-28 SHAFT & ROCKER ARMS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	99475575	1	SHAFT, - ASSY
2	16988301	2	PLUG, D=20 mm
3	504137043	6	ROCKER ARM, - ASSY
4	98498411	1	SCREW,
5	504059553	3	NUT,
6	17084376	1	RING,
7	500300903	1	PAD, SLIDING,
8	500316732	6	ROCKER ARM, - ASSY
9	500314915	6	ROCKER ARM, - ASSY
10	98498410	1	SCREW,
11	99476802	6	LEVER,
12	99475580	7	SCREW,
13	500344277	7	CAP,
14	99444739	1	SCREW,
15	17084476	1	CIRCLIP,
16	99444740	1	BRIDGE,

02-29 EXHAUST MANIFOLD, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-29 EXHAUST MANIFOLD, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504046508	1	MANIFOLD, EXHAUST,
2	16731370	2	STUD, M10X30 mm
3	99443710	2	MANIFOLD, EXHAUST,
4	99443770	2	BUSHING,
5	99443769	2	BUSHING,
6	500305816	4	CLIP, HOSE,
7	504154280	6	GASKET,
8	99443210	24	SCREW,

02-30 CRANKSHAFT & RELATED PARTS, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-30 CRANKSHAFT & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	99438979	1	CRANKSHAFT, - ASSY
2	99437423	1	GEAR, DRIVING,
3	17275410	1	DOWEL, D=8 mm
4	2992137	6	SET OF MAIN BRGS.STD, - RED
4	2992138	6	SET OF MAIN BRGS.STD, - GREEN
4	2992139	6	SET OF CONN ROD BRGS U/S, - RED BLACK 0,127
4	2992140	6	SET OF CONN ROD BRGS U/S, - GREEN BLACK 0,127
4	2992141	6	SET OF MAIN BRGS -0.254, - RED
4	2992142	6	SET OF MAIN BRGS -0.508mm, - RED
5	2992143	1	SET, THRUST WASHERS (STD), - RED
5	2992144	1	SET, THRUST WASHERS (STD), - GREEN
5	2992145	1	SET, THRUST WASHERS +0.25, - RED
5	2992146	1	SET,THRUST WASHERS +0.508, - RED

02-31 CONNECTING ROD, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-31 CONNECTING ROD, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504028545	6	ROD, CONNECTING,
2	99431774	12	SCREW,
3	99460197	6	BUSHING,
4	2992158	6	SET, CONN ROD BRGS (STD), - RED
4	2992159	6	SET OF CONN ROD BRGS U/S, - GREEN
4	2992160	6	SET OF CONN ROD BRGS U/S, - GREEN - 0,127
4	2992161	6	SET OF CONN ROD BRGS U/S, - GREEN BLACK - 0,127
4	2992162	6	SET OF CONN ROD BRGS U/S, - RED
4	2992163	6	SET OF CONN ROD BRGS U/S, - GREEN
4	2992164	6	SET OF CONN ROD BRGS U/S, - RED
4	2992165	6	SET OF CONN ROD BRGS U/S, - GREEN

02-32 PISTON - ENGINE, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-32 PISTON - ENGINE, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	8094840	6	PISTON ASSY.,
2	504006110	1	PIN, PISTON,
3	16877276	2	RING, LOCKING,
4	8094839	1	KIT, PISTON RINGS,

02-33 FLYWHEEL, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-33 FLYWHEEL, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504095063	1	FLYWHEEL, ENGINE, - ASSY
2	99433386	1	GEAR, RING,
3	99430395	8	SCREW,

02-34 PULLEY - CRANSHAFT, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-34 PULLEY - CRANSHAFT, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504079721	1	TENSIONER,
2	504104314	1	PULLEY,
3	504078323	1	BODY,
4	504078066	1	BELT,
5	504078064	1	TENSIONER, BELT,
6	504077389	1	WASHER,
7	504079738	1	SPACER,
8	504079727	1	STUD,
9	16707134	1	SCREW, M8X20
10	16711235	5	SCREW, M10X1,25X70
11	16676635	1	SCREW, M10X1,5X60
12	16750335	1	M10
13	504078065	2	IDLER,
14	16680935	6	SCREW, M14X70
15	16673835	1	SCREW, M8 x 30

02-35 DAMPER, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-35 DAMPER, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504105489	1	DAMPER,
2	16712535	6	M14X50
3	504104316	1	SPACER,




11
12
7
4
8
9
10
6
5
3
1
2

ссылка	Номер детали	Кол-во	Описание
1	500339012	1	GEAR, IDLER, - ASSY
2	98475174	2	BUSHING,
3	500304182	1	PIN,
4	16679034	3	SCREW, M12X90 mm
5	500304181	1	BRACKET,
6	500356757	1	SCREW, M8X1.25X16 mm
7	500305012	1	WASHER, LOCK,
8	500304189	1	GEAR,
9	500304204	1	BUSHING,
10	500304187	1	PIN,
11	500305013	1	RING, LOCKING,
12	16679134	3	SCREW,

02-37 CAMSHAFT, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-37 CAMSHAFT, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504092859	1	CAMSHAFT,
2	500370033	1	GASKET,
3	500370032	1	COVER,
4	99431774	4	SCREW, M14X2X60
5	500336396	1	PLATE, M8X1.25X25 mm
6	16587124	6	SCREW, M10X25 mm
7	99450035	1	GEAR,
8	98496024	1	SPACER,
9	500397562	4	SCREW, M6X17
10	504093610	1	SCREW, M10X1,5




6
5
1
4
2
3

TJ430 TRACTOR (1/06-) - Engine

02-38 AIR LINES, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	16599325	4	SCREW, M10X150 mm
2	504026624	1	GASKET,
3	504074687	1	MANIFOLD,
4	16593125	2	SCREW, M10X100mm
5	17291281	1	GASKET, 94,84X3,53
6	99435103	1	COLLAR CLAMP,

02-39 TURBOCHARGER & RELATED PARTS, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-39 TURBOCHARGER & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504095094	1	TURBOCHARGER,
2	98453300	1	GASKET,
3	16731370	2	STUD, M10X30 mm
4	500300795	4	NUT, M10X1.5

02-40 TURBOBLOWER PIPES, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-40 TURBOBLOWER PIPES, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	61318365	1	ELBOW,
2	17284681	1	GASKET,
3	4800661	1	CLAMP, HOSE,

02-41 OIL LEVEL CHECK, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-41 OIL LEVEL CHECK, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	99489020	2	WASHER, SEALING,
2	504162598	1	NECK FILLER,
3	504124643	1	PIPE,
4	16691324	2	SCREW, M8X60 mm
5	98429552	1	CAP,
6	17283181	1	O-RING, D=37.77X2.62 mm
7	16992515	1	PLUG, M18X1.5
8	500349848	1	CLAMP,
9	11903211	1	PLUG, M12 x 1.25 x 12, Cl5.8, M12X1.5
10	99489017	1	GASKET,

02-42 OIL DIPSTICK, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-42 OIL DIPSTICK, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504124642	1	DIPSTICK, - ASSY
2	504027969	1	O-RING,

02-43 PUMP, ENGINE OIL & RELATED PARTS, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-43 PUMP, ENGINE OIL & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504149656	1	PUMP, ENGINE OIL,
2	500359679	1	VALVE, SAFETY,
3	99452273	1	GASKET,
4	16592525	3	SCREW, M8X70 mm
4	16586625	1	SCREW, M8X35 mm

02-44 PUMP, ENGINE OIL & RELATED PARTS, TJ380 / 430 & T9030 / 9040





02-44 PUMP, ENGINE OIL & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504155933	1	PUMP, ENGINE OIL,
2	500387958	1	GASKET,
3	16592425	1	SCREW, M8X65 mm
3	16286724	3	M8X40 mm

02-45 FILTER ENGINE OIL, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-45 FILTER ENGINE OIL, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504082382	2	FILTER, ENGINE OIL,
2	99431947	2	CONNECTOR, HYD., M30X20 mm
3	504066210	1	HEAD,
4	504015752	1	GASKET,
5	16592325	4	SCREW, M8X40
5	504064190	2	SCREW,
6	16993711	1	PLUG, M35X1.5
7	99469380	1	WASHER, SEALING,
8	16993611	2	PLUG, M32X1.5
9	99469379	2	WASHER, LOCK,
10	16994011	1	PLUG, M24X1.5
11	99489023	1	WASHER, LOCK,

02-46 OIL PRESSURE REGULATION VALVE, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-46 OIL PRESSURE REGULATION VALVE, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	500378929	1	VALVE,
2	17288881	1	GASKET, D=28.1X3.5 mm
3	16586325	2	SCREW, M8X1.25X20 mm

02-47 OIL PUMP PIPING, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-47 OIL PUMP PIPING, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	99475585	1	STRAINER, ELEMENT,
2	16586225	2	SCREW, M8X1,25X16 mm
3	17289481	1	O-RING, D=37.69 X3,53 mm
4	99475589	1	TUBE, RIGID,
5	500343518	1	GASKET,
6	16586524	2	SCREW, M8X30 mm
7	16592525	2	SCREW, M8X70 mm
8	16592225	2	SCREW, M8X55 mm
9	500388917	1	TUBE,
10	500388968	1	SEAL,
11	16586325	3	SCREW, M8X1,25X20
12	16597925	1	SCREW, M8X14

02-48 TURBOBLOWER PIPES, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-48 TURBOBLOWER PIPES, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504039847	1	
2	61318303	1	GASKET,
3	16586625	2	SCREW, M8X35 mm
4	504102835	1	TUBE, RIGID,
5	99475979	1	GASKET,
6	16586325	2	SCREW, M8X1.25X20 mm
7	98412509	1	GASKET,
8	41031569	1	FITTING,
9	99489019	1	WASHER, SEALING,
10	16586425	2	SCREW, M8X25

02-49 HEAT EXCHANGER, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-49 HEAT EXCHANGER, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504123494	1	COOLER, OIL, - ASSY
2	98498467	1	INTERNAL EXCHANGER UNIT,
3	17283581	2	O-RING, D=44.12X2.62 mm
4	16586625	3	SCREW, M8X35 mm
5	16586925	1	SCREW, M8X50 mm
6	98474303	4	WASHER, SEALING,
7	99433799	1	PLUG,
8	99433798	1	SPACER,
9	98498322	1	VALVE, HYDRAULIC,
10	98494952	1	GASKET,
11	16992415	1	PLUG, M16X1.5
12	99489019	1	WASHER, SEALING, D=6X24X1.5 mm
13	16993711	2	PLUG, M35X1.5
14	99469380	2	WASHER, SEALING, D=33 mm
15	16993511	2	PLUG, M28X1.5
16	99432291	2	WASHER, SEALING, D=28 mm
17	98497873	1	GASKET,
18	16586725	11	SCREW, M8X40 mm
18	16598224	2	SCREW, M8X190 mm
18	16586925	1	SCREW, M8X50 mm
18	504064192	2	SCREW,
18	16586425	3	SCREW, M8X25 mm

02-50 WATER PUMP & RELATED PARTS, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-50 WATER PUMP & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504102491	1	PUMP, WATER,
2	17292081	1	GASKET, D=120.24 mm
3	16586325	4	SCREW, M8X1.25X20 mm
4	87282333	1	BELT, Accessory Drive, Alternator, Water, & A/C

02-51 WATER PUMP PIPES, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-51 WATER PUMP PIPES, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	99478887	1	PIPE,
2	99466940	1	GASKET,
3	16674934	2	SCREW, M8X80 mm
3	16674434	1	SCREW, M8X45 mm

02-52 PIPING - ENGINE COOLING SYSTEM, TJ380 / 430 & T9030 / 9040





ссылка	Номер детали	Кол-во	Описание
1	16992515	2	PLUG, M18X1.5
2	99489020	2	WASHER, SEALING,
3	16992415	2	PLUG, M16X1.5
4	99489019	2	WASHER, SEALING,
5	16992611	1	PLUG, M22X1.5
6	99489022	1	WASHER, SEALING,
7	4665029	1	PLUG, M42X1.5
8	99469382	1	WASHER, SEALING,

02-53 TEMPERATURE CONTROL (THERMOSTAT, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-53 TEMPERATURE CONTROL (THERMOSTAT, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504115201	1	THERMOSTAT,
2	500304562	1	PLUG,
3	500362150	1	GASKET,
4	98475757	1	FITTING,
5	16586824	2	SCREW, M8X45 mm
5	500383813	5	SCREW, M8X105 mm

02-54 BELT PULLEY DRIVE & COVER, TJ380 / 430 & T9030 / 9040



KIT = 15



TJ430 TRACTOR (1/06-) - Engine

02-54 BELT PULLEY DRIVE & COVER, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	500353779	1	SUPPORT, - ASSY
2	98472270	1	PLUG,
3	4788087	2	BUSHING,
4	504030275	1	SHAFT, PTO,
5	500351319	1	WASHER, LOCK,
6	500382573	1	GEAR,
7	500382574	1	WASHER, LOCK,
8	17046231	1	NUT,
9	17292281	1	O-RING, D=126.59X3.53 mm
10	17281381	1	O-RING, D=9.19 mm
11	16588324	3	SCREW, M12X45 mm
12	500355018	1	GASKET,
13	500355019	1	COVER,
14	16587024	4	SCREW, M10X20 mm
15	500382578	1	SUPPORT, - ASSY

02-55 STARTER MOTOR, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-55 STARTER MOTOR, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504106753	1	MOTOR, STARTER,
2	16760524	3	STUD, M12
3	17044921	3	NUT, M12
4	504064332	1	
5	16587924	3	SCREW, m12x25

02-56 INTAKE MANIFOLD, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Engine

02-56 INTAKE MANIFOLD, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504154987	1	HEATER,
2	504026624	1	GASKET,
3	500343161	1	RELAY,
4	504031939	1	BRACKET,
5	16585724	4	SCREW, M6X16

02-57 ENGINE EXHAUST BRAKE, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-57 ENGINE EXHAUST BRAKE, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	500340761	1	PLUG, - ASSY
2	16586225	1	SCREW, M8X1.25X16mm
3	17277981	1	O-RING, D=9.2X1.7mm
4	16690524	12	SCREW, M8x20
5	500376911	6	SPRING,
6	504001460	6	SPACER,

02-58 HOOKS - ENGINE, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Engine

02-58 HOOKS - ENGINE, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504078127	1	LOAD HOOK,
2	500372844	1	LOAD HOOK,
3	16677734	3	SCREW, Hex Flg, M12 x 1.75 x 25, M12X25
4	16887624	2	WASHER,
5	16588625	2	BOLT, M12X60
5	16587925	1	BOLT, M12X25




4
7
6
2
7
3
1
5
8
7
6

TJ430 TRACTOR (1/06-) - Engine

02-59 ELECTRONIC INJECTION, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504122542	1	ELECTRONIC UNIT, CONTROL,
2	504097239	1	BRACKET,
3	504184521	1	GASKET,
4	99475194	1	SPACER,
5	16586024	8	SCREW, M6X30
6	16586824	3	SCREW, M8X45 mm
7	98498817	6	ISOLATOR,
8	504043102	1	PLUG,

02-60 MOTOR SENSORS, TJ380 / 430 & T9030 / 9040



TJ430 TRACTOR (1/06-) - Engine

02-60 MOTOR SENSORS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	4890193	1	SENDER UNIT, Oil Pressure &Temperature
2	16689325	1	SCREW, M6X25 mm
3	16992415	1	PLUG, M16X1,5
3	16887515	1	PLUG, M12X1,5
3	10300611	2	PLUG, M14 x 1.5 x 14, Cl5.8,
4	504073323	1	CONNECTOR, ELEC, Air Temperature / Pressure
5	504096645	1	SENDER UNIT,
6	99489019	1	WASHER, SEALING, 16X24X1,5
6	99489017	1	GASKET, 12X20X1,5
6	99489018	3	WASHER, SEALING, 14X22X1,5
7	4895477	1	O-RING,
8	500382599	2	SENSOR, Coolant Temperature
9	504084571	1	PLUG,
10	500346371	1	SENSOR, Plugged Fuel Filter Switch
11	16597224	1	SCREW, M6X18 mm
12	17277881	1	GASKET, 1,7X7,65
13	4899110	2	SCREW, Hex Flg, M6 x 1 x 20,
14	500346074	1	SENDER UNIT,
15	504163664	1	SPACER,




1


2



ссылка	Номер детали	Кол-во	Описание
1	504116158	1	HARNESS,
2	504149937	1	HARNESS, WIRE,

03-01 THROTTLE



TJ430 TRACTOR (1/06-) - Fuel System

03-01 THROTTLE

ссылка	Номер детали	Кол-во	Описание
1	414193A2	1	BRACKET, Throttle, With Power Shift Transmission, With Manual Shift Transmission with ARU
1	410029A2	1	BRACKET, Throttle, With Manual Shift Transmission without ARU
2	258734A2	1	SUPPORT,
3	259040A1	2	PAD, WEAR,
4	237486A1	1	WASHER,
5	86517328	1	WASHER, LOCK, M6,
6	393392	1	NUT, LOCK, M6 x 1, Cl 8,
7	88538	1	WASHER, LOCK, Ext-Int Tooth, 1/4",
9	239491A1	1	BUSHING,
10	9824051	1	O-RING, -025, 90 Duro, 1.176" ID x .070" Thk,
11	259012A1	1	POTENTIOMETER, , With Power Shift Transmission, With Manual Shift Transmission with ARU
11	402751A1	1	POTENTIOMETER, , With Manual Shift Transmission without ARU
12	385681	2	NUT, LOCK, M4 x .7, Cl 8,
13	86639303	1	SCREW, Hex Soc Flat Hd, M5 x 12, 10.9,
14	86639295	2	SCREW, Socket, M4 x 35; 8.8
15	86512441	1	BOLT, CARRIAGE, Short NK, M6 x 30, Cl8.8, Full Thd,
16	413805A1	1	HANDLE, Throttle, See Figure : 06-01, With Manual Shift Transmission with ARU
16	413804A2	1	HANDLE, Throttle, See Figure, 06-01, With Power Shift Transmission
16	431530A1	1	HANDLE, Throttle, See Figure(s) : 06-01, With Manual Shift Transmission without ARU
17	276352A1	1	HARNESS, Throttle, With Power Shift Transmission, With Manual Shift Transmission with ARU
8	9635806	1	CIRCLIP, #50, .392" Dia, E-Type,

03-02 THROTTLE - DECELARATOR CONTROL, ASN Z6F202011



03-02 THROTTLE - DECELARATOR CONTROL, ASN Z6F202011

ссылка	Номер детали	Кол-во	Описание
1	328353A2	1	ROD,
2	298842A1	1	SKID/SHOE,
3	255291A1	1	PIN,
4	256776A1	1	SPRING,
5	86625261	2	WASHER, M5 x 10 x 1, 5.5 x 10 x 1 mm
6	86632599	2	CIRCLIP, M5, E
7	300891A1	2	BEARING, Support
8	248844A1	1	LEVER,
9	278211A1	1	SPRING,
10	396-41028	1	WASHER, 6,6 x 25 x 1.6 mm
11	86508616	3	BOLT, Hex, M6 x 12, 10.9, Cap, HH, CL 10.9, M6 x 1 x 12
12	86624181	2	WASHER, M6, 6,6 x 12 x 1.6 mm
13	281115A1	1	BRACKET,
14	281125A1	1	ROD,
15	435473A1	2	RETAINER,
16	259012A1	1	POTENTIOMETER,
17	86639296	2	SCREW, M5 x 16; 8.8
18	300624	1	RING, SNAP, M12, Ext, Ext, M12
19	258524A2	1	BUSHING,
20	313273A2	1	PIN,
21	87545500	1	HARNESS, Decel


44
45
10
9
8
15
5
49
51
49
48
47
46
49
5
14
49
5
49
50
49
2
5
5
11
6
12
4
7
3
5
6
6
1
22
2
3
19
3
20
3
18
21
3
20
17
3
19
3
19
17
3
19
14
15
8
40
25
19
26
3
5
23
24
52
3
2
43
53
23
5
16
5
41
29
42
35
36
34
35
33
38
39
32
37
28
36
35
34
35
31
30
29

TJ430 TRACTOR (1/06-) - Fuel System

03-03 FUEL LINES, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87282080	1	PUMP, FUEL, Fuel
2	87362717	1	HOSE, Fuel Pump Supply, Out
3	86625263	15	WASHER, M8 x 20 x 1.6,
4	87362717	1	HOSE, Fuel Pump Supply, In
5	13021	10	CLAMP, HOSE, #08, 0.50/0.91 Type F Worm,
6	217-332	3	FITTING, 90є, 5/8" Hose x 3/8" NPTF Beaded,
7	832-10408	3	NUT, LOCK, M8 x 1.25, Cl 8,
8	244358	2	CLAMP, HOSE, #06, .44/.78 Type F Worm,
9	217-229	1	FITTING, 1/2" Hose X 1/4" NPTF Beaded, 1/2" ID x 1/4" nptf
10	86990397	1	FITTING,
11	87362697	1	HOSE, Fuel Supply
12	86990398	1	FITTING,
13	217-207	1	FITTING, 45, 5/8" ID x 3/8" nptf
14	296077A1	1	HOSE, Fuel Supply, Filter to Pump
15	31-3083	1	HOSE, Fuel Return
16	87308466	1	HOSE, Fuel Supply, Tank to Filter
17	86594406	3	CLAMP, 5/8", Insul, 3/8" Bolt, 15.9 mm
18	86624005	2	CLAMP, 3/4", Insul, 3/8" Bolt, 19 mm
19	43362	7	NUT, M8, Cl 10,
20	86639039	2	BOLT, M8 x 35, CL10.9
21	R54363	5	CLAMP, Double
22	87536383	1	Hose
23	86637720	2	FITTING, 90є, 5/8" Hose x 7/8"-14 ORB Beaded, Elbow, 90, 5/8" ID x 7/8"
24	87417445	1	BRACKET, Fuel Filter Mounting
25	426-616	4	BOLT, Hex, 3/8"-16 x 1", G8, Full Thd,
26	495-11041	4	WASHER, 3/8", SAE,
27	335041A2	1	LINE, Fuel Cross Over
28	242680	1	CONNECTOR, HYD., 7/8"-14, 37є x 1/2"-14, NPTF,
29	435446A1	2	VALVE, SHUT-OFF,
30	86637713	1	CONNECTOR, HYD., 1/2"-14 NPTF, Pipe, 1/2" nptf
31	86637792	1	TEE, 1/2" x 1/2" x 5/8"
32	349868A1	1	CHANNEL, Sight Guage
33	337240A1	1	HOSE, Sight Guage
34	352767A1	2	CONNECTOR, HYD., Sight Guage
35	337248A1	4	O-RING,
36	86511845	2	BOLT, Hex Flg, M10 x 35, 8.8,
37	402800A1	1	BRACKET, Mounting
38	86639037	1	BOLT, Hex, M6 x 16, 10.9,
39	86624181	1	WASHER, M6,
40	86637718	1	FITTING, 45є, 1/2" Hose x 1/2" NPTF Beaded, Elbow, 45, 1/2" ID x 1/2" nptf
41	86637716	1	FITTING, 45є, 5/8" Hose x 1/2" NPTF Beaded, Elbow, 45, 5/8" ID x 1/2" nptf
42	86637715	1	ELBOW, 90є, 1/2"-14 Male, Elbow, 90, 1/2" nptf
43	87413717	1	FILTER, FUEL,
44	327144A1	1	CLAMP,
44	435421A1	1	STRAP, SECURING,

ссылка	Номер детали	Кол-во	Описание
45	435545A1	1	BREATHER,
46	217-52	1	TEE, 3/8"-18 NPTF Fem x 3/8"-18 NPTF Male Run,
47	87365506	1	VALVE, CHECK,
48	515-23286	1	CLAMP, 1 1/8", Insul, 3/8" Bolt,
49	217-376	4	FITTING, 5/8" Hose X 3/8" NPTF Beaded,
50	895-11008	1	WASHER, M8 x 16 x 1.6,
51	217-12	1	TEE, 3/8"-18 NPTF Fem,
52	87417455	1	Head, Filter, Fuel Filter
53	87410185	1	BOWL, FILTER, Fuel

03-05 INJECTOR & RELATED PARTS, TJ380 / 430 & T9030 / 9040







TJ430 TRACTOR (1/06-) - Fuel System

03-05 INJECTOR & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	99435007	6	WASHER, LOCK,
2	16707734	6	SCREW, M8X50
3	99435006	6	BRACKET,
4	504128354	6	INJECTOR, FUEL SYSTEM, - ASSY
5	504140437	6	KIT, REPAIR,

03-06 FUEL FILTER & RELATED PARTS, TJ380 / 430 & T9030 / 9040









TJ430 TRACTOR (1/06-) - Fuel System

03-06 FUEL FILTER & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504046809	1	Head, Filter,
2	500304562	1	PLUG,
3	98498837	1	FITTING, M14X1.5 - M16X1.5
4	98472271	1	PLUG,
5	16587225	2	SCREW, M10X30 mm
6	84818744	1	FILTER, FUEL,

03-07 FUEL PUMP & RELATED PARTS, TJ380 / 430 & T9030 / 9040





03-07 FUEL PUMP & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504066263	1	PUMP, FUEL,
2	99447382	1	GASKET,
3	16586424	3	SCREW, M8X25

03-08 FUEL LINES & RELATED PARTS, TJ380 / 430 & T9030 / 9040





TJ430 TRACTOR (1/06-) - Fuel System

03-08 FUEL LINES & RELATED PARTS, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	500313907	1	TUBE, RIGID,
2	500352450	1	TUBE, RIGID,
3	504146519	1	TUBE,
4	500310076	1	FITTING,
5	500352447	1	TUBE, RIGID,
6	500314313	1	BLOCK, CONNECTING, - ASSY
7	98472271	2	PLUG,
8	500348306	1	ELBOW,
9	500328251	1	VALVE, PRESSURE RELIEF,
10	99489018	1	WASHER, SEALING, D=12 mm
11	99489019	10	WASHER, SEALING, D=16X24X1.5 mm
12	41031569	9	FITTING, M16X1.5 - M18X1.5
13	500350162	1	ELBOW,
14	4864084	3	BOLT, BANJO, M16X1.5
15	98474309	6	GASKET, D=16X24X1,9 mm
16	17316599	2	CLAMP,
17	17816211	2	
18	16586325	2	SCREW, M8X1,25X20
19	504112433	1	VALVE,
20	504125079	1	UNION,


26
31
22
25
23
24
36
30
41
1
10
7
40
39
38
37
2
6
3
4
16
17
18
8
19
28
20
9
35
33
27
21
29
13
12
7
14
11
15
32
34
34
5

ссылка	Номер детали	Кол-во	Описание
1	87314389	1	CONSOLE, Armrest Console, Right Hand, See Figure : 09-20
	87395318	1	CONTROL, Electronic, Inc. 2 - 4
2	230098A1	1	PLATE, Mounting
3	87395299	4	VALVE, CONTROL, Remote Auxiliary Valve
4	86637785	8	SCREW, Sltd Pan Hd, #8-32 x 3/8",
5	382247A1	1	SWITCH, Remote, Three Point Hitch
6	86639294	4	SCREW, Hex Soc Hd, M4 x 20, 8.8,
7	A39888	2	NUT, 5 Spool Application
8	86989947	1	SWITCH, Fifth Auxiliary Valve
9	256305A2	1	POTENTIOMETER, Flow Control, 5 Spool Application
10	276797A1	1	KNOB, Flow Control, 5 Spool Application
11	339735A1	1	PANEL, Secondary, With Three Point Hitch
11	238290A4	1	PANEL, Secondary, Without Three Point Hitch
12	276797A1	4	KNOB, Flow Control
13	187820A1	1	BUTTON, Remote Valve Timer Control
14	223433A1	2	KNOB, Electronic Draft Control, With Three Point Hitch
15	86639117	2	SCREW, SELF TAPPING, Pan Hd, M4.2 x 16,
16	406324A2	2	PLUG, Switch Hole
17	87361920	1	SWITCH, Rocker, Differential Lock, Rear
18	87361921	1	SWITCH, Rocker, Differential Lock, Front
19	86990406	1	SWITCH, Hitch Position
20	87329768	1	POTENTIOMETER, Three Point Hitch
21	411705A3	1	KNOB, Power Takeoff
22	87436077	1	WASHER, Stainless Steel
23	87435947	1	SPRING,
24	87435853	1	RING, Friction, Position Control
25	87435194	1	KNOB, Wheel, Indicator Position
26	87434770	1	KNOB, Knob, Hitch Position Control, With Reynolds Drawbar
27	86989951	1	SWITCH, Scraper, With Reynolds Drawbar
28	87422017	1	SWITCH, Head Land / Turn Sequence
29	414495A1	1	SWITCH, Power Takeoff
30	86625127	1	PLUG, Dome, .375" hole, Nylon, 3/8, Without Three Point Hitch
31	87435946	1	WASHER, , Without Three Point Hitch
32	87524858	1	CONTROL, Armrest Controller
33	87414465	1	SWITCH, Autoshift
34	87536486	6	SCREW, M4 x 10; 12.9
35	87414327	1	SWITCH, EDC, Slip Limit Control
35	87308327	1	SWITCH, Engine Brake
36	87435852	1	SPACER,
37	400161A3	4	KNOB, Remote Control, Black
38	400160A3	1	KNOB, Remote Control, Ginger
39	400159A3	1	KNOB, Remote Control, Blue
40	400158A3	1	KNOB, Remote Control, Green
41	87323840	1	SWITCH, Switch, Intellisteer, If Used


10
13
3
4
4
4
5
16
12
11
9
8
1
14
15
17
9
1
7
1
2
6
1
18
● =19
KIT
KIT

04-02 PANEL, CONTROL - COMPONENTS

ссылка	Номер детали	Кол-во	Описание
1	1331046C2	5	CAP, WASHER,
2	87454558	1	SWITCH, Climate Control
3	92100C2	1	SWITCH, Blower Motor
4	418107A1	AR	POTENTIOMETER,
5	345439A1	1	POTENTIOMETER, Vent Motor
6	87305994	1	SWITCH, Defog
7	87450974	1	DECAL, Climate Control, See Figure: 9-58
8	431230A1	1	DECAL, Light Panel, See Figures: 9-58
9	86989939	2	SWITCH, WINDSHIELD WIPER, Lower/Rear Wiper
10	177250A1	1	SWITCH, LIGHTS, Rotary
11	86989955	1	SWITCH, Cruise Control
12	87414325	1	SWITCH, Strobe Lamp
13	345262A1	1	SWITCH, Front Washer / Wiper
14	87442098	1	SWITCH, LIGHTS, Road Lamp / Flasher
15	330116A1	1	SWITCH, Auxiliary Power
16	86000535	4	PLUG, 1.427" x .62", Plastic,
17	86989953	1	SWITCH, Cruise Control, Increase/Decrease
18	1535219C1	1	COVER, , Without Radio
19	719518003	1	KIT, Rear Wiper / Washer, See Figure: 04-05


4
10
11
13
14
15
18
24
1
19
12
17
8
2
9
6
5
7
3
23
16
KIT
KIT
●=20
■=21
▲=22

04-03 RADIO AND SPEAKERS

ссылка	Номер детали	Кол-во	Описание
1	87552288	1	RADIO, AM / FM / WB
1	355623A2	1	RADIO, AM / FM / WB / Cassette
1	325061A2	1	RADIO, AM / FM / WB / Cassette / CD Changer Ready
2	258342A2	2	SPEAKER, Co-Axial
3	388445A1	1	HOUSING, Subwoofer
4	360215A1	1	NO DESCRIPTION,
5	388444A1	1	SPEAKER, Subwoofer, 8"
6	760-14316	4	SCREW, SELF TAPPING, Pan Hd, M4.2 x 16,
7	86505868	4	NUT, M8, Flg Ser,
8	177269A1	8	NUT, Special
9	1270741C1	8	SCREW, SELF TAPPING, Cross Pan Hd, #8 x 1", Pointed
10	360432A2	1	HARNESS, Antenna, Inc. 11
11	NSS	1	NOT SERVICED SEPARATELY, Grommet
12	317688A1	1	Player, Compact Disc, Delco, 6 Disc
13	86624181	1	WASHER, M6,
14	86625265	1	WASHER, LOCK, Ext Tooth, M6,
15	86639137	1	SCREW, SELF TAPPING, Hex Hd, M6.3 x 13,
16	1535219C1	1	COVER, , Without Radio
17	449071A1	1	HARNESS, CD Changer, 5486 mm (216 in)
18	388489A1	1	CLIP, ELECTRICAL,
18	435436A1	AR	MOUNT, RUBBER, Adhesive Backed
19	86625213	3	SCREW, Hex Soc Hd, M5 x 12, 8.8, Socket, M5 x 12
20	334229A1	1	KIT, AM / FM / WB / Cassette / CD, Inc. 1, 2, 8, 9
21	186158A1	1	KIT, AM / FM / WB, Inc. 1, 2, 8, 9
22	719582003	1	KIT, Single CD Player / Radio
23	440567A1	1	CABLE ASSY., Tie
23	435437A1	1	STRAP, CABLE, Tie, 7-1/4"
24	87343754	1	SPACER, , Austrailian Application


1
2
4
3

ссылка	Номер детали	Кол-во	Описание
1	87350680	1	MODULE, Basic, BSN Z6F2020903
1	87549277	1	MODULE, Basic, ASN Z6F2020903
1	87350681	1	MODULE, Deluxe, BSN Z6F2020903
1	87520583	1	MODULE, Deluxe, ASN Z6F2020903
2	NSS	1	NOT SERVICED SEPARATELY, Software, Not Illustrated, Download Software from Service Tool.
3	260-16516	4	SCREW, SELF TAPPING, Cross Pan Hd, #10 x 1",
4	177269A1	4	NUT, Spring

04-05 WIPER, WINDSHIELD - MOUNTING



04-05 WIPER, WINDSHIELD - MOUNTING

ссылка	Номер детали	Кол-во	Описание
	87408490	AR	WIPER MOTOR, Front, Upper, Inc. 2 - 20, 22, 24 - 29
	248812A4	1	WIPER MOTOR, Rear, Upper, Inc. 2 - 20, 22, 24 - 29
1	87307954	1	WIPER MOTOR, Repair, Front, Upper, Inc. 2 - 20
1	87308180	1	WIPER MOTOR, Upper, Rear, Inc. 2 - 20
1	87308226	1	WIPER MOTOR, Fonr, Lower, RH, Inc. 2 - 20
1	87308230	1	WIPER MOTOR, Front, Lower, LH, Inc. 2 - 20
2	87307958	1	WIPER MOTOR, Rear Upper
3	60-6633T1	1	SUPPORT, Support
4	87307957	1	ARM,
5	825-5148	1	NUT, M8, Flg Ser,
6	444867A1	3	SCREW, Button Hd
7	60-6581T91	1	DRIVE ASSY.,
8	NSS	1	NOT SERVICED SEPARATELY, Pin
9	NSS	1	NOT SERVICED SEPARATELY, Nut
10	281024	2	SCREW, Slotted Pan Hd, #10-32 x 1/2", Inc. Lock Washer
11	1-2684	2	WASHER,
12	1-2685	2	CLIP, Spring
13	1-2683	1	LINK,
14	V41916	1	WASHER, Fiber
15	495-81032	1	WASHER, 23/32" x 1 1/4" x .060", Steel
16	V23571	1	NUT,
17	V23568	1	CAP,
18	V23569	1	GUIDE, Knob, Knurled
19	60-6634T1	1	PLATE, LOCKING, Washer
20	60-6635T1	1	NUT,
21	87362320	1	PLATE, MOUNTING,
22	87362317	1	PLATE, MOUNTING, Upper / Lower, Left-Hand
23	87557932	AR	WIPER ARM, 20"
	435472A1	1	PIVOT ASSY., Pantograph, Inc. 24 - 27
24	NSS	1	NOT SERVICED SEPARATELY, Body, Pantograph
25	2-4190T1	1	GASKET, Mounting
26	2-4191T1	1	WASHER,
27	2-4192T1	1	NUT,
28	86637928	3	BOLT, Hex, 1/4"-28 x 1 1/2", G5,
29	87361	1	WASHER, 1/4", SAE,
30	334715A1	2	BLADE, Wiper, 660 mm (26"), Lower Front
30	353273A1	2	BLADE, Wiper, 559 mm (22"), Upper Front / Rear
31	86624184	10	WASHER, M8 x 16 x 1.6,
32	86528579	4	NUT, LOCK, M8 x 1.25, Cl 10,
33	126844A1	1	PLUG, Switch Hole, Not Illustrated
34	719518003	1	KIT, Rear Washer / Wiper, See Figure(s): 04-03, 04-17

04-06 WINDSHIELD WASHER



TJ430 TRACTOR (1/06-) - Electrical System

04-06 WINDSHIELD WASHER

ссылка	Номер детали	Кол-во	Описание
1	313576A1	1	RESERVOIR,
2	895-11008	4	WASHER, M8 x 16 x 1.6,
3	811-8030	4	BOLT, CARRIAGE, Short NK, M8 x 30, Cl8.8, Full Thd,
4	829-1408	7	NUT, M8, Cl 10,
5	1964696C2	3	PUMP,
6	398715A1	1	HOSE, 4775 mm (188 in), Front Wiper
7	398714A1	1	HOSE, 3302 mm (130 in), Rear Wiper
8	31-2422	2	HOSE, 254 mm (10 in), Cut From 4-1056
9	369708A1	4	CLAMP,
10	829-1410	AR	NUT, M10, Cl 10,
11	31-2364	4	FITTING, 3/16 x 7/64
12	31-2608	2	HOSE, 200 mm (8 in), Rear Wiper
13	435437A1	6	STRAP, CABLE, 7-1/4"
14	121414A1	1	FUSE, 20 Amp
14	121416A1	1	FUSE, 30 Amp
15	324203A1	2	VALVE, CHECK,
16	515-24349	1	CLAMP, 1 3/8", Insul, 7/16" Bolt,
17	515-2495	4	CLAMP, 3/8", Insul, 7/16" Bolt,
18	31-2866	1	HOSE, 160 mm (24 in), Cut From 4-1056T1
19	31-2363	3	TEE,
20	31-2936	1	HOSE, 4775 mm (188 in), Cut From 4-1056T1
21	384139A1	1	HOSE ASSY.,
22	384141A1	1	HOSE ASSY.,
23	384142A1	1	HOSE ASSY., 250 mm (10 in), Cut From 31-2607T1
24	384140A1	1	HOSE ASSY.,

04-07 ALTERNATOR - MOUNTING, TJ380 / 430 & T9030 / 9040





04-07 ALTERNATOR - MOUNTING, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504132109	1	ALTERNATOR, 175 Amp, with Pulley
2	87439319	1	ALTERNATOR, 175 Amp, without Pulley, Not Illustrated
3	16593025	1	BOLT, M10X90 mm
4	16596625	2	DOWEL, M10X1,5X125 mm
5	504080581	1	SCREW,
6	17095314	2	WASHER, D=12X24 mm
7	504154754	1	Support, Inc. 12
8	17038421	1	NUT, M12
9	16600025	1	BOLT, M12X160 mm
10	504080582	1	SPACER,
11	87282333	1	BELT, Accessory Drive, Alternator, Water Pump & A/C
12	98405462	2	DOWEL,

04-08 ALTERNATOR - MOUNTING, TJ480 / 530 & T9030 / 9040





04-08 ALTERNATOR - MOUNTING, TJ480 / 530 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87439314	1	ALTERNATOR, 150 Amp
1	87439319	1	ALTERNATOR, 175 Amp
2	87439321	1	PULLEY,
3	87366407	1	BELT, Acessory Drive, Alternator & A/C
4	NSS	1	NOT SERVICED SEPARATELY, Bolt, Mounting, Order From Your Cummins Engine Dealer
5	NSS	1	NOT SERVICED SEPARATELY, Nut, Flg, Order From Your Cummins Engine Dealer
6	NSS	1	NOT SERVICED SEPARATELY, Brace, Order From Your Cummins Engine Dealer
7	NSS	1	NOT SERVICED SEPARATELY, Bolt, Order From Your Cummins Engine Dealer
8	NSS	1	NOT SERVICED SEPARATELY, Bolt, Order From Your Cummins Engine Dealer
9	NSS	4	NOT SERVICED SEPARATELY, Nut, Order From Your Cummins Engine Dealer
10	NSS	1	NOT SERVICED SEPARATELY, Nut, Order From Your Cummins Engine Dealer

04-10 GROUND SPEED SENSOR



04-10 GROUND SPEED SENSOR

ссылка	Номер детали	Кол-во	Описание
	719571003	1	KIT, Ground Speed, Inc. 1 - 12
1	414936A1	1	SUPPORT,
2	228760A1	1	RADAR, Ground Speed
3	86624176	4	WASHER, M10 x 20 x 2,
4	140028	4	WASHER, LOCK, M10,
5	86624978	4	BOLT, Hex, M10 x 35, 10.9, Full Thd,
6	86500689	4	NUT, M10, Cl 10,
7	86624182	4	WASHER, M6 x 18 x 1.6,
8	86500688	4	NUT, M6, Cl 10,
9	86517328	4	WASHER, LOCK, M6,
10	86639208	4	BOLT, Hex, M6 x 100, 10.9,
11	121412A1	1	FUSE, 10 AMP
12	414937A1	4	SPACER,

04-11 ALARM - BACK-UP



04-11 ALARM - BACK-UP

ссылка	Номер детали	Кол-во	Описание
1	D121972	1	ALARM, Inc. Nuts
2	440134A1	1	BRACKET,
3	86639317	8	WASHER, M6 x 13 x 2, HT,
4	86624176	4	WASHER, M10 x 20 x 2,
5	86500688	4	NUT, M6, Cl 10,
6	86624176	4	WASHER, M10 x 20 x 2,
7	86624978	2	BOLT, Hex, M10 x 35, 10.9, Full Thd,
8	86500689	2	NUT, M10, Cl 10,
9	435437A1	2	STRAP, CABLE, 7 in
10	391364A1	1	HARNESS,
11	121410A1	1	FUSE, 5 amp

04-12 HARNESS - TRANSMISSION, POWER SHIFT



04-12 HARNESS - TRANSMISSION, POWER SHIFT

ссылка	Номер детали	Кол-во	Описание
1	87332140	1	HARNESS,
2	86625261	8	WASHER, M5 x 10 x 1,
3	A186004	1	SENSOR, Engine Speed
4	198456A1	1	CONNECTOR, ELEC, Sensor, System Pressure
5	87449451	3	SENSOR, Gear Speed
6	87351750	1	SPACER, 29.385 mm
7	87351748	2	SPACER, 15.217 mm
8	934120R1	4	NUT, Thin, M20 x 1.5, M20, CL10
9	627-8016	1	BOLT, Hex, M8 x 16, 10.9,

04-13 HARNESS - ENGINE, TJ380 / 430



04-13 HARNESS - ENGINE, TJ380 / 430

ссылка	Номер детали	Кол-во	Описание
1	87319922	1	HARNESS,
2	43233	9	BOLT, Hex, M8 x 20, 10.9,
3	86624184	9	WASHER, M8 x 16 x 1.6,
4	829-1408	2	NUT, M8, Cl 10,
5	87362573	1	CABLE, GROUND, Engine to Chassis Ground
6	86625255	1	WASHER, M13.5 x 24.5 x 3, HT,
7	337475	1	NUT, M12, Cl 10,
8	896-15018	1	WASHER, M18 x 41.5 x 5, HT,
9	87548591	1	CABLE, Heater Relay to Fuse
10	87548592	1	CABLE, Heater to Ground
11	87353517	1	CABLE, GROUND, A/C Ground Wire
12	293797A1	1	SWITCH, Air Restriction
13	86624181	5	WASHER, M6,
14	412250	5	NUT, LOCK, M8 x 1.25, Cl 8,
15	L11541	7	STRAP, Tie, 7 - 8"
16	87343611	1	CABLE, Alternator to Grid Heater
17	515-23254	1	CLAMP, 1", Insul, 3/8" Bolt,
18	87387734	1	BRACKET, Alternator Cable
19	515-23175	2	CLAMP, 11/16", Insul, 3/8" Bolt,
20	627-8025	1	BOLT, Hex, M8 x 25, 10.9,

04-15 HARNESS - MAIN CAB, DELUXE AND LUXURY CABS



04-15 HARNESS - MAIN CAB, DELUXE AND LUXURY CABS

ссылка	Номер детали	Кол-во	Описание
	87366657	1	MODULE, Electronics, Inc. 1, See Figure: 04-23, With Power Shift Transmission, BSN Z6F202001
	87557938	1	MODULE, Electronics, Inc. 1, See Figure: 04-23, With Power Shift Transmission, ASN Z6F202001
	87366658	1	MODULE, Electronics, Inc. 1, See Figure : 04-23, With Manual Shift Transmission, BSN Z6F202001
	87557939	1	MODULE, Electronis, Inc. 1, See Figure : 04-23, With Manual Shift Transmission, ASN Z6F202001
1	NSS	1	NOT SERVICED SEPARATELY, Harness, Main Cab, With Manual Shift Transmission
2	227739A2	3	CONNECTOR, ELEC, Power
3	383986A1	12	RIVET,
4	86639310	12	WASHER, M3,
5	435435A1	1	CIRCUIT BREAKER,
6	86624181	2	WASHER, M6,
7	86511829	2	SCREW, Cross Pan Hd, M6 x 16,
8	87541092	1	SWITCH, Differential Lock
9	87452321	1	OUTLET, Power
10	388810A1	1	ELEMENT, Pop-Out Lighter
11	L18331	1	STRAP, CABLE, Tie
12	84058092	1	CONNECTOR, TERMINAL, 120 Ohm Resistor,
13	388813A1	2	OUTLET, Power
14	388811A1	1	LIGHTER, CIGARETTE, Not Illustrated

04-16 HARNESS - CAB ROOF



04-16 HARNESS - CAB ROOF

ссылка	Номер детали	Кол-во	Описание
1	373457A1	1	HARNESS,
2	245483C1	2	CONNECTOR, ELEC, Two Cavity, Without Field Lights
3	225127C1	4	TERMINAL CONNECTOR, Type V4
4	408658A1	2	DECAL, Cover, Without Field Lights

04-17 HARNESS - FRONT FRAME



TJ430 TRACTOR (1/06-) - Electrical System

04-17 HARNESS - FRONT FRAME

ссылка	Номер детали	Кол-во	Описание
1	87332559	1	HARNESS, Front Frame, BSN Z6F202001
1	87550731	1	HARNESS, Front Frame, ASN Z6F202001
2	86624184	13	WASHER, M8 x 16 x 1.6,
3	43362	10	NUT, M8, Cl 10,
4	86624176	5	WASHER, M10 x 20 x 2,
5	86500689	4	NUT, M10, Cl 10,
6	330124A1	1	SWITCH, Temperature, Axle Lube
7	86639010	1	CLAMP, 3/8", Insul, 1/2" Bolt,
8	120103	3	BOLT, Hex, M8 x 16, 8.8,
9	L111928	5	CLAMP, Double
10	435437A1	2	STRAP, CABLE, Tie
10	L11541	2	STRAP, Tie, Steering Harness
11	86572009	1	CLAMP, 3/8", Insul, 3/8" Bolt,
12	86637995	1	CLAMP, 1 1/16", Insul, 3/8" Bolt,
13	87445193	1	HARNESS, Light Bar, T9030 / 9040, TJ380 /430
13	87369666	1	HARNESS, Light Bar, T9050 / 9060, TJ480 / 530
14	300506	2	BOLT, Hex, M6 x 25, 8.8,
15	237582A1	1	HORN, FC9
16	87332146	1	HARNESS, Manual Transmission
17	87450246	1	HARNESS, Power Shift Transmission
18	A186004	1	SENSOR, Transmission Gear Speed
19	934120R1	1	NUT, Thin, M20 x 1.5, Jam, M20, CL10
20	388113	1	BOLT, Hex, M12 x 16, 8.8, Full Thd,
21	86625255	1	WASHER, M13.5 x 24.5 x 3, HT,
22	371122A2	1	HARNESS, Lower Wipers
23	515-2295	1	CLAMP, 3/8", Insul, 5/16" Bolt,
24	339529A1	1	SWITCH, Pressure, Park Brake
25	515-25381	1	CLAMP, 1 1/2", Insul, 1/2" Bolt,
26	87539795	1	ELBOW, 90, M12 or x 14, Inc. 27
27	637-63093	1	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
28	375644A1	1	NO DESCRIPTION, Sensor, Pressure, Inc. 29
29	637-63113	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
30	87551744	2	HARNESS, WIRE, Steering Pressure Sensor

04-18 HARNESS - REAR FRAME, WITH ELECTRONIC REMOTE, WITHOUT THREE POINT HITCH



TJ430 TRACTOR (1/06-) - Electrical System

04-18 HARNESS - REAR FRAME, WITH ELECTRONIC REMOTE, WITHOUT THREE POINT HITCH

ссылка	Номер детали	Кол-во	Описание
1	87354881	1	HARNESS,
2	86624176	8	WASHER, M10 x 20 x 2,
3	86500689	8	NUT, M10, Cl 10,
4	515-23381	2	CLAMP, 1 1/2", Insul, 3/8" Bolt, 38.1 mm
5	481849C1	1	COVER,
6	86624184	12	WASHER, M8 x 16 x 1.6,
7	614-10030	4	BOLT, Hex, M10 x 30, 8.8,
8	86010402	2	CLAMP, 1/2", Insul, 3/8" Bolt,
9	43362	9	NUT, M8, Cl 10,
10	87434676	1	SENDER UNIT, Fuel Level, Inc. 18
11	895-11005	6	WASHER, M5 x 10 x 1,
12	614-5010	6	BOLT, Hex, M5 x 10, 8.8, Full Thd,
13	328265A1	3	GROMMET,
14	86624181	1	WASHER, M6,
15	120100	4	BOLT, Hex, M6 x 20, 8.8,
16	121645C1	1	SOCKET/RECEPTACLE,
17	86632602	1	WASHER, LOCK, Ext Tooth, M10,
18	104812C3	1	GASKET,
19	43234	2	BOLT, Hex, M8 x 25, 10.9,
20	515-2595	1	CLAMP, 3/8", Insul, 1/2" Bolt,
21	140028	1	WASHER, LOCK, M10,
22	86977726	1	BOLT, Hex, M6 x 12, 8.8,
23	440567A1	1	CABLE ASSY., Cable
24	392227A1	1	HARNESS, Differential Lock
25	435437A1	2	STRAP, CABLE, Tie, 184 mm (7-1/4 in)
26	245483C1	4	CONNECTOR, ELEC, , Without Field Lights
27	225127C1	8	TERMINAL CONNECTOR, Type V4

04-19 HARNESS - REAR FRAME, WITH ELECTRONIC REMOTE AND THREE POINT HITCH



04-19 HARNESS - REAR FRAME, WITH ELECTRONIC REMOTE AND THREE POINT HITCH

ссылка	Номер детали	Кол-во	Описание
1	87354879	1	HARNESS,
2	86624176	8	WASHER, M10 x 20 x 2,
3	86500689	8	NUT, M10, Cl 10,
4	515-23381	2	CLAMP, 1 1/2", Insul, 3/8" Bolt, 38.1 mm
5	481849C1	1	COVER,
6	86624184	12	WASHER, M8 x 16 x 1.6,
7	614-10030	4	BOLT, Hex, M10 x 30, 8.8,
8	86639003	1	CLAMP, 3/8", Insul, 7/16" Bolt,
9	43362	10	NUT, M8, Cl 10,
10	87434676	1	SENDER UNIT, Fuel Level, Inc. 18
11	895-11005	6	WASHER, M5 x 10 x 1,
12	614-5010	5	BOLT, Hex, M5 x 10, 8.8, Full Thd,
13	328265A1	3	GROMMET,
14	86624181	3	WASHER, M6,
15	120100	2	BOLT, Hex, M6 x 20, 8.8,
16	121645C1	1	SOCKET/RECEPTACLE,
17	86632602	1	WASHER, LOCK, Ext Tooth, M10,
18	104812C3	1	GASKET,
19	43234	5	BOLT, Hex, M8 x 25, 10.9,
20	86639010	1	CLAMP, 3/8", Insul, 1/2" Bolt, 3/4 ID
21	86500688	2	NUT, M6, Cl 10,
22	367322A1	1	CONNECTOR, Remote, Three Point Hitch
23	86010402	2	CLAMP, 1/2", Insul, 3/8" Bolt,
24	86977726	1	BOLT, Hex, M6 x 12, 8.8,
25	140028	1	WASHER, LOCK, M10,
26	440567A1	1	CABLE ASSY.,
27	392227A1	1	HARNESS, Differential Lock
28	225127C1	8	TERMINAL CONNECTOR, Type V4
29	245483C1	4	CONNECTOR, ELEC, , Without Field Lights
30	435437A1	2	STRAP, CABLE, Tie, 184 mm (7-1/4 in)
31	515-25254	1	CLAMP, 1", Insul, 1/2" Bolt,

04-20 HARNESS - FRONT CONSOLE



04-20 HARNESS - FRONT CONSOLE

ссылка	Номер детали	Кол-во	Описание
1	87332145	1	HARNESS, , With Manual Shift Transmission
1	87332137	1	HARNESS, , With Power Shift Transmission
2	87416177	1	SWITCH, IGNITION, Inc. 3
3	86502201	1	SET OF 2 KEYS,
	86993721	1	CONTROL, With Self-Cancel, Inc. 4, Also See Figure: 05-03, With Power Shift Transmission
	414332A1	1	CONTROL, With Self-Cancel, Inc. 4, Also See Figure: 05-02
4	375681A1	1	HARNESS, With Self-Cancel, With Power Shift Transmission
4	416123A1	1	HARNESS, WIRE, With Self-Cancel, With Manual Shift Transmission

04-21 HARNESS - FLEX CONTROL



04-21 HARNESS - FLEX CONTROL

ссылка	Номер детали	Кол-во	Описание
1	405029A2	1	HARNESS, Chassis
2	352506A1	1	CONNECTOR, ELEC,
3	459329C1	1	NUT,
4	459330C1	1	WASHER, LOCK,
5	405387A2	1	PLATE, Implement Connector
6	86632602	1	WASHER, LOCK, Ext Tooth, M10,
7	140028	2	WASHER, LOCK, M10,
8	86500689	2	NUT, M10, Cl 10,
9	86625251	7	WASHER, M10 x 18 x 1.6,
10	86624978	2	BOLT, Hex, M10 x 35, 10.9, Full Thd,
11	328265A1	1	GROMMET,
12	435437A1	3	STRAP, CABLE,
13	86598598	2	CLAMP, 3/4", Insul, 1/2" Bolt,
14	86509828	1	WASHER, LOCK, M5,
15	86509265	1	NUT, M5, Cl 10,
16	86632597	1	BOLT, Hex, M5 x 12, 8.8, Full Thd,
17	87364530	1	HARNESS, Cab
18	86632690	1	GROMMET, 3/4" ID x 1 7/16" Groove Dia, Str Cut,
19	284638A2	1	CONNECTOR, ELEC, Active
20	406450A1	2	FASTENER, Dual Lock
21	406449A1	2	FASTENER, Dual Lock
22	169850C2	2	ANCHOR,
23	405687A1	1	CABLE, Receiver
25	86624019	1	GROMMET, 3/8" ID x 5/8" Groove Dia, Str Cut,
26	87414764	1	HARNESS, Flex Control Jumper
27	245041C1	1	CAP,
24	86637652	2	PIN, SPLIT (COTTER), Int, 9/64" x .054",

04-22 BATTERIES



04-22 BATTERIES

ссылка	Номер детали	Кол-во	Описание
1	364590A1	1	CABLE, Circuit Breaker
2	88612	1	WASHER, #10,
3	86511323	6	WASHER, M10 x 20 x 2,
4	86500689	4	NUT, M10, Cl 10,
5	87825	1	NUT, #10-32,
6	87439131	1	CABLE, Starter, 24V
7	F925DSW	2	BATTERY, WET, 1000 cca, for purchase in the United States
7	9673907WDS	2	BATTERY, WET, 1000 cca, for purchase in Canada
8	87437207	1	SHIELD, Relay
9	9824259	4	WASHER, M6 x 12 x 1.6,
10	86639037	2	BOLT, Hex, M6 x 16, 10.9,
11	365035A6	1	BRACKET, Cab Harness
12	87426208	1	CABLE, Ground, Jump Start, 24V
13	A187583	1	STUD, Terminal, Jump Start
14	87427096	1	DECAL, Charging Post
15	87427317	1	DECAL, Negative (-) Post
16	87413792	1	SHIELD, Battery Terminals
17	43362	6	NUT, M8, Cl 10,
18	87417510	1	HARNESS, Relay 12 / 24V
19	86500688	2	NUT, M6, Cl 10,
20	9515003	2	BOLT, Hex, M10 x 30, 10.9, Full Thd,
21	80389120	1	SWITCH, ASSY, Relay, Inc. 40
22	86624177	1	WASHER, M12 x 24 x 2.5,
23	337475	1	NUT, M12, Cl 10,
24	87439132	1	CABLE, Ground, 12V
25	87418058	1	CABLE, Ground, 24V
26	86625038	3	CLAMP, 1", Insul, 1/2" Bolt,
27	9635082	2	NUT, 5/16"-18, G5,
28	86511315	11	WASHER, M8 x 16 x 1.6,
29	86639210	1	BOLT, Hex, M8 x 45, 10.9,
30	87362	2	WASHER, 5/16" SAE,
31	582785C91	1	CONNECTOR, TERMINAL, Jump Start
32	87425760	1	PLATE, Battery Hold Down, Side
33	87413678	2	ROD, Battery Hold Down
34	896-15008	4	WASHER, M8 x 21.5 x 2.5, HT,
35	412250	5	NUT, LOCK, M8 x 1.25, Cl 8,
36	87413679	1	CHANNEL, Battery Hold Down, Center
37	87437248	1	CABLE, Relay, Chasis Ground
38	43228	1	BOLT, Hex, M6 x 80, 10.9,
39	86639011	2	CLAMP, J, 3/4", Insul, 3/8" Bolt, 19mm
40	420580	2	PLATE,
41	R43926	1	CLAMP, 90 Twist
42	86639039	4	BOLT, M8 x 35, CL10.9
43	87417495	1	PLATE, Mounting
44	183038A1	1	SWITCH, SOLENOID, Switch, w/ Barrier

ссылка	Номер детали	Кол-во	Описание
45	178148A1	1	COVER,

04-23 ELECTRONIC MODULE ASSY



04-23 ELECTRONIC MODULE ASSY

ссылка	Номер детали	Кол-во	Описание
1	87416914	1	BRACKET,
2	435434A1	1	BLOCK, Junction
3	140028	1	WASHER, LOCK, M10,
4	9628503	1	NUT, 3/8"-16, G5,
5	86511826	2	SCREW, Cross Pan Hd, M5 x 16,
6	86625261	2	WASHER, M5 x 10 x 1,
7	86509265	2	NUT, M5, Cl 10,
8	397346A1	1	FLASHER UNIT, Interface Module
9	86624179	4	WASHER, M4,
10	86639307	4	WASHER, Lock, M4
11	86625075	4	NUT, LOCK, M4 x .7, Cl 8,
12	86511444	3	NUT, M6, Flg Ser,
	87366657	1	MODULE, Electronics, Inc. 13 - 34, Also See Figure: 04-15, With Power Shift Transmission, BSN Z6F202001
	87557938	1	MODULE, Electronics, Inc. 13 - 34, Also See Figure: 04-15, With Power Shift Transmission, ASN Z6F202001
	87366658	1	MODULE, Electronics, Inc. 13 - 34, Also See Figure: 04-15, With Manual Shift Transmission, BSN Z6F202001
	87557939	1	MODULE, Electronics, Inc. 13 - 34, Also See Figure: 04-15, With Manual Shift Transmission, ASN Z6F202001
13	87416914	1	BRACKET,
14	367147A1	3	BRACKET, Mounting
15	367145A1	5	BLOCK, Terminal
16	86639263	3	SCREW, Hex Wash Hd, M5 x 12,
17	43416	3	NUT,
18	430116A1	AR	LOCK,
19	191135A1	1	BASE,
20	86624181	4	WASHER, M6,
21	86500688	3	NUT, M6, Cl 10,
22	144417A1	3	BLOCK, CONNECTING,
23	144421A1	2	BLOCK, CONNECTING,
24	194319A1	1	TERMINAL,
25	300655A1	1	SOCKET, POWER,
26	349062A1	1	PAD, RUBBER,
27	310057A1	1	CONNECTOR, ELEC,
28	86639260	4	SCREW, M3 x 12; 4.8
29	86639310	4	WASHER, M3,
30	86508812	4	NUT, M3, Cl 8,
31	121416A1	AR	FUSE, 30 amp
31	121414A1	AR	FUSE, 20 amp
31	121413A1	AR	FUSE, 15 amp
31	121415A1	AR	FUSE, 25 amp
31	121412A1	AR	FUSE, 10 amp
31	121411A1	AR	FUSE, 5 amp
31	368224A1	2	DIODE, Mini, 1 amp, Differential Lock

04-23 ELECTRONIC MODULE ASSY

ссылка	Номер детали	Кол-во	Описание
32	87414866	AR	RELAY, 20 amp
33	368459A1	AR	RELAY, 70 amp
34	367146A1	4	WEDGE,
35	86624184	4	WASHER, M8 x 16 x 1.6,
36	86632602	2	WASHER, LOCK, Ext Tooth, M10,
37	86624176	4	WASHER, M10 x 20 x 2,
38	86500689	2	NUT, M10, Cl 10,
39	A187523	1	BLOCK, CONNECTING, Junction, With Manual Shift Transmission
39	190158A1	1	BLOCK, Block, With Power Shift Transmission
40	311430A1	1	BLOCK, Block
41	87354994	1	CONTROL UNIT, Three Point Hitch, Download Software from Service Tool.
42	313776A4	1	CONTROL UNIT, Auxiliary, Download Software from Service Tool.
43	840-1616	2	SCREW, Cross Pan Hd, M6 x 16,
44	87573403	1	MODULE, Transmission, Download Software from Service Tool., BSN Z6F202012
44	87587161	1	MODULE, Transmission, Download Software from Service Tool., ASN Z6F202012
45	43232	1	SCREW,
46	86625261	5	WASHER, M5 x 10 x 1,
47	80043362	3	NUT,
48	832-10405	2	NUT, LOCK, M5 x .8, Cl 8,
49	87537124	1	CONNECTOR, TERMINAL, Jumper, Can
50	86989612	1	MODULE, ISO ECU, If Used
51	832-10406	2	NUT, LOCK, M6 x 1, Cl 8,


1 ● ■
2 ● ■
3 ● ■
6 ● ■
4 ● ■
5 ● ■
7
8


KIT
● = 9
■ = 10

04-24 LAMPS - REAR FRAME, H.I.D.

ссылка	Номер детали	Кол-во	Описание
1	87419587	2	LAMP, Flood
1	87419591	2	LAMP, Trap
2	447742A1	AR	Ballast,
3	120098	8	BOLT, Hex, M5 x 20, 8.8, Full Thd,
4	9824326	8	WASHER, M5,
5	86639241	8	NUT, LOCK, M5 x .8, Cl 8,
6	87419583	AR	CABLE, Ballast to Rear Harness
7	86625256	8	WASHER, M12 x 28.5 x 4, HT,
8	86500689	4	NUT, M10, Cl 10,
9	719618003	1	KIT, FIP, H.I.D., Rear Flood, Inc. 1 - 6
10	719702013	1	KIT, FIP, H.I.D., Rear Trap, Inc. 1 - 6

04-25 LAMPS - REAR FRAME AND FIELD



04-25 LAMPS - REAR FRAME AND FIELD

ссылка	Номер детали	Кол-во	Описание
	92269C1	AR	LAMP, WORK, Inc. 1 - 4
1	1964806C1	1	BEZEL,
2	1312210C2	1	BULB, 12V, 55W
3	276498A1	1	LENS,
4	86637784	2	SCREW, SELF TAPPING, Cross Pan Hd, #6 x 3/4",
5	87030421	2-4	GROMMET, 3/8" ID x 1 1/4" Groove Dia, Str Cut, 1
6	86625256	4-8	WASHER, M12 x 28.5 x 4, HT,
7	86500689	2-4	NUT, M10, Cl 10,
	320246A1	4	LAMP, Warning / Hazard, Inc. 8 - 10
8	183748A1	1	LENS, Amber
9	529068	1	BULB, #1156, 12V,
10	NSS	1	NOT SERVICED SEPARATELY, Housing
	82026300	1	LAMP, TAIL, Rear Frame, Right Hand, Inc. 11 - 15
	82026301	1	LAMP, TAIL, Rear Frame, Left Hand, Inc. 11 - 15
11	87357815	1	LENS, LH, Red /Amber
11	87357816	1	LENS, RH, Red / Amber
12	14148090	1	BULB, Housing
13	14148190	1	BULB, 12V-21W
14	14144690	1	BULB, 12V-21/5W, Double Filament
15	87357827	1	GASKET, Rear Lamp

04-26 HEADLAMPS



04-26 HEADLAMPS

ссылка	Номер детали	Кол-во	Описание
1	395574A1	1	HEADLAMP, LH, Hi / Low, Road & Work Lamp, Front Grille, Inc. 13
2	395573A1	1	HEADLAMP, RH, Hi / Low, Road & Work Lamp, Front Grille, Inc. 13
3	395576A1	1	HEADLAMP, Center, Halogen, T9030 / 9040, TJ380 /430
3	395577A1	1	HEADLAMP, Center, High Intensity Discharge (H.I.D), TJ380 /430, T9030 / 9040
4	402631A1	2	HEADLAMP, Center, Halogen, TJ480 / 530, T9050 / 9060
4	402632A1	2	LIGHT, Center, High Intensity Discharge (H.I.D), T9050 / 9060, TJ480 / 530
5	87366792	2	BULB, 885-12V, Worklight / Headlamp
6	86517328	10	WASHER, LOCK, M6,
7	87366790	2	Ballast, Front Jumper, RH & LH Lamps
8	614-5020	AR	BOLT, Hex, M5 x 20, 8.8, Full Thd,
9	895-11005	AR	WASHER, M5 x 10 x 1,
10	832-10405	AR	NUT, LOCK, M5 x .8, Cl 8,
11	435437A1	4	STRAP, CABLE, Cable
12	87433036	1	BRACKET, Ballast, H.I.D., T9030 / 9040, TJ380 /430
13	323093A1	2	BULB, Halogen Worklamp, 885-12V
14	87448000	1	FIXING BRACKET, H.I.D Ballast, TJ480 / 530, T9050 / 9060
15	87369663	1	HARNESS, Light Bar, TJ380 /430, T9030 / 9040
15	87369666	1	HARNESS, H.I.D. Light Bar, T9050 / 9060, TJ480 / 530
16	87325207	1	BOX, Light, TJ480 / 530, T9050 / 9060
17	86500688	10	NUT, M6, Cl 10,
18	719511026	1	KIT, H.I.D. Front Corner, Inc. 4, T9050 / 9060, TJ480 / 530
19	719511036	1	KIT, H.I.D. Front Corners, Inc. 5, 8 - 11, 14, TJ480 / 530, T9050 / 9060
20	719619026	1	KIT, H.I.D. Front Corners, Inc. 5, 8 - 12, T9030 / 9040, TJ380 /430


14
12
22
8
2
18
22
8
9
8
1
8
11
8
11
13
15
10
17
11
8
1
8
8
11
9
3
4
20
13
19
13
21
16
7
5
6

04-27 LAMPS - MARKER

ссылка	Номер детали	Кол-во	Описание
1	402164A2	2	BRACKET,
2	402085A1	1	SUPPORT,
3	402090A1	1	TUBE,
4	86639265	2	SCREW, Hex Flat Hd, M5 x 12, 4.8,
5	362496A1	1	BRACKET,
6	367321A1	1	LAMP, Warning, See Figure: 04-28
7	86509265	2	NUT, M5, Cl 10,
8	86624176	16	WASHER, M10 x 20 x 2,
9	9515003	4	BOLT, Hex, M10 x 30, 10.9, Full Thd,
10	43233	2	BOLT, Hex, M8 x 20, 10.9,
11	86500689	8	NUT, M10, Cl 10,
12	87520424	1	HARNESS, Marker Lights
13	86624184	2	WASHER, M8 x 16 x 1.6,
14	86637782	2	GROMMET, 3/8" ID x 1" Groove Dia, Str Cut, Rubber, 1
15	86528579	2	NUT, LOCK, M8 x 1.25, Cl 10,
16	297221A1	4	DECAL, Red and Orange
17	297223A1	4	DECAL, Yellow
18	402168A1	1	CHANNEL,
19	413188A1	1	CHANNEL,
20	43362	4	NUT, M8, Cl 10,
21	86639210	2	BOLT, Hex, M8 x 45, 10.9,
22	9515003	4	BOLT, Hex, M10 x 30, 10.9, Full Thd,

04-28 LAMPS - SIDE MARKER WARNING



04-28 LAMPS - SIDE MARKER WARNING

ссылка	Номер детали	Кол-во	Описание
	367321A1	1	LAMP, Warning, Inc. 1 - 4
1	232212A1	2	LENS, Amber
2	222136A1	1	CONNECTOR, ELEC,
3	233561A1	2	O-RING,
4	529068	1	BULB, #1156, 12V,

04-29 LAMP - STROBE



04-29 LAMP - STROBE

ссылка	Номер детали	Кол-во	Описание
1	383983A1	1	BRACKET, Mounting
2	86639305	1	SET SCREW, Hex Soc, M6 x 6, Cup Pt,
3	175048A1	1	BEACON, Strobe, Inc. 4
4	323095A1	1	BULB,
5	387938A2	1	SUPPORT ASSY., Mounting, Europe Option
6	253105A1	2	U-BOLT, M8, Europe Option
7	412250	4	NUT, LOCK, M8 x 1.25, Cl 8, , Europe Option
8	396484A1	1	HARNESS, Beacon Light, Europe Option
8	87325934	1	HARNESS, Beacon Light
9	244106A1	1	CONNECTOR, ELEC, Tube Support
10	L18331	1	STRAP, CABLE, Tie

04-30 WIRING - MEGA FLOW HYDRAULIC CONTROLS



ссылка	Номер детали	Кол-во	Описание
1	430834A1	1	HARNESS, Cab
2	430835A1	1	HARNESS,
3	86598598	6	CLAMP, 3/4", Insul, 1/2" Bolt,
4	86624176	3	WASHER, M10 x 20 x 2,
5	86500689	1	NUT, M10, Cl 10,
6	412027A2	2	CLAMP, Pipe
7	86642446	4	SCREW, Socket, M6 x 20, CL8.8
8	435437A1	2	STRAP, CABLE, Cable
9	87518269	1	CONTROL UNIT, Box Assy., See Figure: 04-31
	719576003	1	KIT, Mega Flow, Inc. 6, See Figure: 04-31


2
3
15
12
2
3
1
4
4
5
6
7
17
16
20
18
21
22
19
18
8
9
11
11
10
13
9
14
14

04-31 MEGA FLOW HYDRAULIC CONTROLS

ссылка	Номер детали	Кол-во	Описание
	87518269	1	CONTROL UNIT, Box Assy., Inc. 1 - 9 & 11 - 22
1	418147A4	1	COVER ASSY,
2	276797A1	4	KNOB, Flow Control
3	444868A1	8	NUT, 3/4
4	256305A2	4	POTENTIOMETER, Draft Control
5	413148A1	1	SWITCH,
6	NSS	1	NOT SERVICED SEPARATELY, Plate, Mounting
7	444867A1	4	SCREW,
8	86639294	4	SCREW, Hex Soc Hd, M4 x 20, 8.8,
9	100012	4	NUT, M4, Cl 8,
10	86639292	2	SCREW, Socket, M4 x 10; 8.8
11	87395299	2	VALVE, CONTROL, Electrohydraulic
12	409724A2	2	KNOB,
13	418148A2	1	COVER, Plate
14	86642445	4	SCREW, Socket, M6 x 12; 8.8
15	438237A1	1	DECAL, Flow Control
16	411981A3	1	BRACKET, Mounting
17	412295A1	5	SPACER,
18	404287A1	12	INSERT,
19	47112222	5	SCREW, M4 x 6
20	25-HT00012	5	SCREW,
21	NSS	1	NOT SERVICED SEPARATELY, Software
22	412070A1	1	BOARD, PRINTED CIRCUIT,
	719576003	1	KIT, Mega Flow, Inc. 1 - 9, 11 - 22, See Figure: 04-30

04-32 MOUNTING - FLEX CONTROL



ссылка	Номер детали	Кол-во	Описание
1	279293A2	1	SUPPORT, Bracket, Beacon
2	D135342	4	ISOLATOR,
3	14305221	4	SCREW, Hex Soc Hd, M6 x 16, 8.8,
4	87414515	1	MOUNTING PARTS, AFS Display
5	19-6258	2	U-BOLT,
6	425-104	4	NUT, 1/4"-20, G5,

04-33 INTELLISTEER, GPS - MOUNTING



04-33 INTELLISTEER, GPS - MOUNTING

ссылка	Номер детали	Кол-во	Описание
1	87304763	1	MOUNTING PARTS,
2	87304768	1	BRACKET, Antenna Mounting
3	87568855	1	PLATE, MOUNTING, Receiver Carrying
4	374897	4	SCREW, Hex Flat Hd, M8 x 25, 4.8,
5	87308224	1	MODULE, Receiver
6	9861444	4	BOLT, Hex, M10 x 20, 10.9, Full Thd,
7	87304771	3	SPACER,
8	86500689	7	NUT, M10, Cl 10,
9	43362	4	NUT, M8, Cl 10,
10	86624184	7	WASHER, M8 x 16 x 1.6,
11	86624176	7	WASHER, M10 x 20 x 2,
12	827-10055	3	BOLT, Hex, M10 x 55, 10.9,
13	814-8060	3	BOLT, Hex, M8 x 60, 8.8,
14	895-11006	6	WASHER, M6,
15	825-5146	3	NUT, M6, Flg Ser,
16	87528080	1	PLATE, BASE, GPS Antenna, Inc. 17 - 19
17	87528045	1	PLATE, BASE,
18	87308870	1	LATCH,
19	87308841	2	RIVET, Pop, 5/32" x .425",

04-34 INTELLISTEER - VIRTUAL TERMINAL & RELEATED PARTS



04-34 INTELLISTEER - VIRTUAL TERMINAL & RELEATED PARTS

ссылка	Номер детали	Кол-во	Описание
1	87580504	1	HARNESS, Auto Guidance, Cab Roof
2	87566063	1	HARNESS, Mounting, Inc. 3, 4, 36 & 37
3	NSS	1	NOT SERVICED SEPARATELY, Harness, Virtual Terminal
4	NSS	1	NOT SERVICED SEPARATELY, Tube, Mounting
5	43233	3	BOLT, Hex, M8 x 20, 10.9,
6	43362	3	NUT, M8, Cl 10,
7	NSS	1	NOT SERVICED SEPARATELY, Monitor, Intelliview Plus, Wide Color Virtual Terminal, Order from INTELLISTEER Pricebook.
8	895-11008	3	WASHER, M8 x 16 x 1.6,
9	87428367	1	BRACKET, Mounting
10	87428366	1	MODULE, Radio, RDL
11	87584843	1	HARNESS, Cab
12	284638A2	2	CONNECTOR, ELEC, Active Terminator
13	L11541	15	STRAP, Tie
14	406450A1	4	FASTENER, Velcro
15	87428369	1	SET, Bolt
16	87428396	1	CABLE ASSY., RTK Radio to Antenna
17	87331556	1	HARNESS, Chassis
18	719631026	1	KIT, Virtual Terminal Display, Inc. 7, 30, 31
19	A64737	1	SLEEVE, Protective
20	87365742	1	SWITCH, Optical
21	87454709	1	KNOB, Encoder
22	87453959	1	SWITCH, Escape
23	87453957	1	SWITCH, Home
24	87325557	1	PLATE, MOUNTING, Ball Joint
25	82038414	1	PROTECTION CAP, Ball
26	87353504	1	KNOB,
27	82039389	1	WASHER, CUP, Cup, Ball Joint
28	896-15012	1	WASHER, M12 x 28.5 x 4, HT,
29	814-12050	1	BOLT, Hex, M12 x 50, 8.8,
30	87325765	1	COVER, Ball Joint
31	87536486	6	SCREW, M4 x 16, CL12.9
32	87555071	1	DIA KIT, TRACTOR, Mounting, Inc. 2, 5 - 8, 20 - 29 & 31
33	87423195	4	SPACER,
34	440570A1	4	STUD,
35	87346979	1	CONTROL, Module, NAV II
36	87588663	1	COVER, CAP, USB
37	440-1044	2	SCREW, Cross Oval Hd, #4-40 x 1/4",
38	87593934	1	USB Mount, Not Illustrated

04-35 SENSOR - HITCH POSITION



04-35 SENSOR - HITCH POSITION

ссылка	Номер детали	Кол-во	Описание
1	283659A1	1	SENSOR, Hitch Position
2	305020A2	1	BUSHING,
3	86639027	3	BOLT, Hex, M5 x 45, 8.8, Full Thd,
4	86625261	3	WASHER, M5 x 10 x 1,
5	86639241	3	NUT, LOCK, M5 x .8, Cl 8,
6	353926A1	1	ARM,
7	86639141	2	CIRCLIP, M10, Retaining
8	358978A1	1	ROD, Tie
9	80681	2	WASHER, LOCK, 5/16",
10	43362	2	NUT, M8, Cl 10,

04-36 HARNESS - ISO IMPLEMENT



04-36 HARNESS - ISO IMPLEMENT

ссылка	Номер детали	Кол-во	Описание
1	87566384	1	HARNESS, ISO Cab
2	87342623	1	HARNESS, ISO Chasis
3	284638A2	1	CONNECTOR, ELEC, Active Terminator
4	406450A1	2	FASTENER, Dual Lock
5	406449A1	1	FASTENER, Dual Lock
6	328265A1	1	GROMMET,
7	87359272	1	BRACKET, Connector
8	627-10035	2	BOLT, Hex, M10 x 35, 10.9, Full Thd,
9	895-18010	2	WASHER, M10 x 18 x 1.6,
10	893-11010	2	WASHER, LOCK, Ext Tooth, M10, Tooth
11	892-11010	2	WASHER, LOCK, M10, Spring
12	829-1410	2	NUT, M10, Cl 10,
13	87418273	1	CONNECTOR, ELEC, Receptacle Box
14	895-11006	4	WASHER, M6,
15	779-14625	4	SCREW, SELF TAPPING,
16	435437A1	11	STRAP, CABLE, Tie, 175 - 200 mm

05-01 STEERING WHEEL AND COLUMN



TJ430 TRACTOR (1/06-) - Steering System

05-01 STEERING WHEEL AND COLUMN

ссылка	Номер детали	Кол-во	Описание
1	87387459	1	STEERING COLUMN, Steering, See Figure: 05-04
2	895-11010	9	WASHER, M10 x 20 x 2,
3	829-1410	7	NUT, M10, Cl 10,
4	1977448C2	1	WASHER, Support
5	220056A1	4	SCREW, Hex Soc Flat Hd, M10 x 20, 8.8,
6	87448525	1	BRACKET, Mounting, Steering Column
7	87309685	1	BRACKET, Mounting, Column / Pump
8	614-10030	2	BOLT, Hex, M10 x 30, 8.8,
9	87448446	1	PEDAL, with Steering Adjustment
10	86639231	1	NUT, M8, Cl 10,
11	86637961	1	BOLT, Hex, M8 x 30, 8.8, Full Thd,
12	86639111	1	PIN, CLEVIS, M8 x 45, M8 x 45
13	282892A1	2	BUSHING, Nylon
14	86639115	1	PIN, SPLIT (COTTER), M2 x 12,
15	311812A1	1	SPRING, Extension
16	323657A1	1	PAD, Foot Release Pedal
17	301200A1	1	WHEEL (STEERING), , Deluxe Cab
17	359033A1	1	WHEEL (STEERING), , Luxury Cab
18	86625266	1	WASHER, M17.5 x 30 x 4, HT,
19	86639148	1	NUT, M14 x 1.5, Cl 8,
20	399142A1	1	CAP,
21	86993721	1	CONTROL, Transmission, with Self Cancel, See Figure: 05-03, Power Shift Transmission
22	414332A1	1	CONTROL, Transmission, with Self Cancel, See Figure: 05-02, Manual Shift Transmission
23	253679A1	1	RING, Magnetic
24	87426127	1	STEERING HYDRAULIC, Steering Control, See Figure: 05-12

05-02 TRANSMISSION CONTROL ASSY - MANUAL SHIFT TRANSMISSION



05-02 TRANSMISSION CONTROL ASSY - MANUAL SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
	414332A1	1	CONTROL, Transmission, Inc. 1 - 3, 5 - 10, 12 & 13, With Self Cancel
1	325362A1	1	CHASSIS,
2	NSS	1	NOT SERVICED SEPARATELY, Housing, Lower
3	284777A1	1	SWITCH, , With Self Cancel
4	325068A1	1	BELLOWS,
5	414330A1	1	DECAL,
6	86585706	7	SCREW, Cross Pan Hd, M4 x 10,
7	NSS	1	NOT SERVICED SEPARATELY, Housing, Upper
8	303466A1	1	SYMBOLS, Right-Hand
9	303467A1	1	SYMBOLS, Left-Hand
10	86639307	7	WASHER, Lock, M4
11	905974R1	2	SCREW, SELF TAPPING, Pan Hd, M2.9 x 13,
12	303465A2	1	LAMP, Flasher, With Self Cancel

05-03 TRANSMISSION CONTROL ASSY - POWER SHIFT TRANSMISSION



05-03 TRANSMISSION CONTROL ASSY - POWER SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
	86993721	1	CONTROL, Transmission, Inc. 1 - 3, 5 - 15, 17 - 19, With Self Cancel
1	325362A1	1	CHASSIS,
2	325065A1	1	HOUSING, Lower
3	284777A1	1	SWITCH, , With Self Cancel
4	435437A1	1	STRAP, CABLE, 7 in
5	447256A2	1	SWITCH, FNRP, Without Nuetral Start
6	86585706	7	SCREW, Cross Pan Hd, M4 x 10,
7	325064A1	1	HOUSING, Upper
8	303466A1	1	SYMBOLS, Right-Hand
9	303467A1	1	SYMBOLS, Left-Hand
10	86639307	7	WASHER, Lock, M4
11	325363A1	1	LEVER,
12	250939A1	1	SPRING,
13	325068A1	1	BELLOWS,
14	325066A2	1	GUARD,
15	303465A2	1	LAMP, Flasher
16	392699A1	1	FASTENER,
17	325533A1	1	HANDLE,
18	905974R1	2	SCREW, SELF TAPPING, Pan Hd, M2.9 x 13,
19	358353A1	1	SYMBOLS, FNRP

05-04 STEERING COLUMN ASSEMBLY



05-04 STEERING COLUMN ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
	87387459	1	STEERING COLUMN, Steering, Inc. 1 - 27
	87377005	1	KIT, SERVICE, Renovation, Inc. 1 - 17
1	NSS	1	NOT SERVICED SEPARATELY, Washer, Lock
2	NSS	1	NOT SERVICED SEPARATELY, Washer, Lock
3	NSS	1	NOT SERVICED SEPARATELY, Bushing, Telescoping Spring
4	NSS	2	NOT SERVICED SEPARATELY, Bearing, Axial
5	NSS	1	NOT SERVICED SEPARATELY, Arm, Regulating
6	NSS	1	NOT SERVICED SEPARATELY, Spring, Tilt Return
7	NSS	1	NOT SERVICED SEPARATELY, Spring, Telescoping
8	NSS	2	NOT SERVICED SEPARATELY, Plate, Tilt Position
9	NSS	2	NOT SERVICED SEPARATELY, Stop, Tilt, 24"
10	NSS	1	NOT SERVICED SEPARATELY, Clevis, Pin
11	NSS	1	NOT SERVICED SEPARATELY, Screw, Hook
12	NSS	2	NOT SERVICED SEPARATELY, Screw, M6 x 18
13	NSS	3	NOT SERVICED SEPARATELY, Nut, Locking, M6
14	NSS	1	NOT SERVICED SEPARATELY, Bushing, Catch
15	NSS	1	NOT SERVICED SEPARATELY, Spring, Catch
16	NSS	1	NOT SERVICED SEPARATELY, Spring, Seat
17	NSS	2	NOT SERVICED SEPARATELY, Catch
	87377007	1	KIT, SERVICE, Cover, Inc. 18 - 20
18	NSS	1	NOT SERVICED SEPARATELY, Cover, Upper
19	NSS	1	NOT SERVICED SEPARATELY, Cover, Lower
20	NSS	2	NOT SERVICED SEPARATELY, Screw, M5 x 16
	87377012	1	KIT, SERVICE, Boot, Inc. 21 - 23
21	NSS	1	NOT SERVICED SEPARATELY, Plate, Support
22	NSS	1	NOT SERVICED SEPARATELY, Wire, Support
23	NSS	1	NOT SERVICED SEPARATELY, Boot
	87377013	1	KIT, SERVICE, Release Lever, Inc. 24 - 27
24	NSS	1	NOT SERVICED SEPARATELY, Tie, Cable
25	NSS	1	NOT SERVICED SEPARATELY, Retainer, Cable
26	NSS	1	NOT SERVICED SEPARATELY, Lever, Release
27	NSS	1	NOT SERVICED SEPARATELY, Cable


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
A
B
C
D

TJ430 TRACTOR (1/06-) - Steering System

05-05 HYDRAULICS - STEERING

ссылка	Номер детали	Кол-во	Описание
1	87426127	1	STEERING HYDRAULIC, Orbital, Steering Control, See Figure: 05-08
2	700-446	6	ELBOW, 45є, 11/16"-18 ORFS x M18 x 1.5 ORB, 45, M18 or x 11/16 fc sl, Inc. 3 & 4
3	637-64236	6	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
4	238-6012	6	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
5	87312091	1	TUBE, Port 'P'
6	87312093	1	TUBE, Port 'T'
7	87312089	1	TUBE, Port 'L'
8	87312087	1	TUBE, Port 'R'
9	87312095	2	HOSE, 838 mm (33")
10	87312096	1	HOSE, 785 mm (31")
11	87347856	1	BRACKET, Tube Holder
12	86624184	24	WASHER, M8 x 16 x 1.6,
13	412250	14	NUT, LOCK, M8 x 1.25, Cl 8,
14	43234	6	BOLT, Hex, M8 x 25, 10.9,
15	87403324	1	BRACKET, SUPPORTING, Tube Mounting
16	87436024	1	MOUNTING PARTS, Mounting
17	86625005	2	BOLT, Hex, M8 x 60, 10.9,
18	87439775	1	TUBE ASSY., Return
19	435413A1	1	HOSE, 38 mm (1-1/2")
20	86624194	2	CLAMP, HOSE, #36, 1.81/2.75 Type F Worm,
21	9992069	2	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
22	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
23	86579676	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 24 & 25
24	86639043	1	O-RING, 90 Duro, 15.3 ID x 2.2 thk
25	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
26	86579691	4	ELBOW, 90є, 13/16"-18 ORFS x M18 x 1.5 ORB, Includes 24 & 25
27	86579673	2	CONNECTOR, HYD., 11/16"-16 ORFS x M18 x 1.5 ORB, Inc. 3 & 4
28	87304378	1	BRACKET, Mounting
29	86625255	3	WASHER, M13.5 x 24.5 x 3, HT,
30	337475	3	NUT, M12, Cl 10,
31	515-25508	1	CLAMP, 2", Insul, 1/2" Bolt,
32	398792	1	BOLT, Hex, M12 x 25, 10.9,
33	87304379	1	HOSE ASSY.,
34	87439175	1	HOSE ASSY., 1257 mm (49-1/2")
35	242563A1	1	CLAMP,
36	412123	1	WASHER, LOCK, M12,
37	364967A1	1	TEE, M18 or x 12 fc sl, Inc. 38 & 39
38	86639043	1	O-RING, 90 Duro, 15.3 ID x 2.2 thk
39	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
40	178889A1	1	FITTING, Diagnostic, Inc. 41 - 43
41	86502604	1	DUST CAP,
42	NSS	1	NOT SERVICED SEPARATELY, Fitting
43	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
44	86639080	2	TEE, 13/16"-16 ORFS, Blkd Run, Inc. 39
45	86639083	2	NUT, LOCK, 13/16"-16, ORFS Blkhd,

ссылка	Номер детали	Кол-во	Описание
46	87439172	1	HOSE ASSY., 991 mm (39")
47	87312871	1	HOSE, 1170 mm (46")
48	367243A1	1	HOSE ASSY., 1605 mm (63")
49	86637996	1	CLAMP, 1 1/8", Insul, 3/8" Bolt,
50	86625263	2	WASHER, M8 x 20 x 1.6,
51	43362	2	NUT, M8, Cl 10,
52	367244A1	1	HOSE, 550 mm (21-1/2")
53	435470A1	4	CLAMP,
54	435468A1	4	PLATE, Cover
55	86556137	2	BOLT, Hex, M8 x 70, 10.9,
56	435506A1	2	PIN,
57	86624189	4	WASHER, 21/32" x 1 5/16" x .150",
58	374835	4	BOLT, Hex, M16 x 40, 10.9,
59	435501A1	4	SPACER,
60	406999A1	2	CYLINDER STEERING,
61	87312097	1	HOSE, 892 mm (35")
62	87442925	1	VALVE, CONTROL, Priority / EHPS, See Figure: 08-12, BSN Z7F202170
62	87585897	1	VALVE, HYDRAULIC, Priority / EHPS, See Figure: 08-12, ASN Z7F202170
63	515-23206	6	CLAMP, 13/16", Insul, 3/8" Bolt,
64	87438129	1	BRACKET, SUPPORTING, Priority Valve, BSN Z7F202275
64	87550230	1	BRACKET, Priority Valve, ASN Z7f202275
65	627-8020	3	BOLT, Hex, M8 x 20, 10.9, , Used on Power Shift Models
65	627-8016	3	BOLT, Hex, M8 x 16, 10.9, , Used with Manual Shift Models
66	895-11010	2	WASHER, M10 x 20 x 2,
67	829-1410	2	NUT, M10, Cl 10,

05-06 CYLINDER ASSY - ARTICULATION



TJ430 TRACTOR (1/06-) - Steering System

05-06 CYLINDER ASSY - ARTICULATION

ссылка	Номер детали	Кол-во	Описание
1	409685A1	2	JOINT,
2	D95143	8	SEAL,
3	435504A1	2	PIN,
4	435501A1	2	SPACER,
5	86529976	2	BOLT, Hex, M16 x 35, 10.9,
6	86625266	2	WASHER, M17.5 x 30 x 4, HT,
7	86637724	2	PLUG, Hex Soc, 1/8"-27 NPTF, Hex Socket, 1/8 PT
8	80717	1	NIPPLE, LUBE, 45є, 1/8" NPT x 7/8" lg,
9	84015293	1	ELBOW, 90є, 1/8"-27 Female x 1/8"-27 Male, 90, 1/8 PT x fem PT
10	F53473	1	NUT,
11	86636814	1	NIPPLE, LUBE, 1/4"-28 x .52" lg, 1/4 x 1/2 special, Grease
12	1339090C1	1	HOSE, 838 mm (33 in)
	406999A1	1	CYLINDER STEERING, Inc. 13 - 26
13	NSS	1	NOT SERVICED SEPARATELY, Barrel
14	387652A1	1	CAP CYLINDER END,
15	NSS	1	NOT SERVICED SEPARATELY, Ring
16	NSS	1	NOT SERVICED SEPARATELY, O-Ring
17	NSS	1	NOT SERVICED SEPARATELY, Seal
18	NSS	1	NOT SERVICED SEPARATELY, Wiper
19	387650A1	1	ROD, PISTON,
20	387648A1	1	PISTON,
21	86016798	1	NUT, LOCK, 1 1/4"-12, GC,
22	NSS	1	NOT SERVICED SEPARATELY, O-Ring
23	NSS	1	NOT SERVICED SEPARATELY, Ring, Piston
24	NSS	1	NOT SERVICED SEPARATELY, Seal, Piston
25	NSS	2	NOT SERVICED SEPARATELY, Ring, Wear
26	NSS	1	NOT SERVICED SEPARATELY, Screw
	387654A1	1	PACKAGE, SEALS, Inc. 15 - 18, 22 - 26

05-07 LOCK ARTICULATION





TJ430 TRACTOR (1/06-) - Steering System

05-07 LOCK ARTICULATION

ссылка	Номер детали	Кол-во	Описание
1	345096A2	1	LOCK, 214mm (8 in), With Stops
1	403817A2	1	LOCK, Without Stops
1	344882A2	1	LOCKING-DEVICE, , Scraper Model
2	440518A1	1	DECAL,
3	86637938	1	PIN, CLEVIS, 1/2" x 3 1/4", Clevis, 1/2 x 3-1/2
4	435425A1	1	PIN, 1/8
5	370865A1	4	STOP, Articulation
6	86625034	2	CLAMP, HOSE, #64, 3.56/4.50 Type F Worm, 3-9/16 - 4-1/2 in dia.
7	321232A1	2	BUSHING,
8	896-15012	1	WASHER, M12 x 28.5 x 4, HT,
9	406390A1	1	HANDLE,

05-08 STEERING CONTROL VALVE



TJ430 TRACTOR (1/06-) - Steering System

05-08 STEERING CONTROL VALVE

ссылка	Номер детали	Кол-во	Описание
1	87426127	1	STEERING HYDRAULIC, Steering Control Orbital, Inc. 2 - 22
2	NSS	1	NOT SERVICED SEPARATELY, Housing
3	NSS	1	NOT SERVICED SEPARATELY, Spool
4	NSS	1	NOT SERVICED SEPARATELY, Sleeve
5	NSS	1	NOT SERVICED SEPARATELY, Valve, Check
6	NSS	1	NOT SERVICED SEPARATELY, Seal, Dust Ring
7	NSS	1	NOT SERVICED SEPARATELY, Bushing
8	NSS	1	NOT SERVICED SEPARATELY, Ball
9	NSS	1	NOT SERVICED SEPARATELY, O-Ring
10	NSS	1	NOT SERVICED SEPARATELY, Bearing Assy.
11	NSS	1	NOT SERVICED SEPARATELY, Ring
12	NSS	1	NOT SERVICED SEPARATELY, Pin, Cross
13	NSS	6	NOT SERVICED SEPARATELY, Springs
14	NSS	1	NOT SERVICED SEPARATELY, Shaft, Cardan
15	NSS	3	NOT SERVICED SEPARATELY, O-Ring
16	NSS	1	NOT SERVICED SEPARATELY, Plate, Distributor
17	NSS	1	NOT SERVICED SEPARATELY, Gear Wheel, Set
18	NSS	1	NOT SERVICED SEPARATELY, Cover, End
19	NSS	7	NOT SERVICED SEPARATELY, Washer
20	NSS	1	NOT SERVICED SEPARATELY, Screw, with Pin
21	NSS	6	NOT SERVICED SEPARATELY, Screw
22	NSS	1	NOT SERVICED SEPARATELY, Plate, Name
23	87345879	1	KIT, Includes Ref. 6, 9, 15, & 19


1
3
2
4
5
6
6
7
8
4
9
3
20
13
19
12
10
11
13
14
12
28
29
27
16
22
37
11
12
13
39
38
13
42
41
40
12
26
25
24
22
23
36
33
35
34
16
27
29
30
31
36
33
35
34
32
12
18
13
11
12
21
13
11
12
16
27
29
30
28
29
27
16
13
20
13
15
17
13
21
14
16
15
17
16
18
18

TJ430 TRACTOR (1/06-) - Steering System

05-09 INTELLISTEER - HYDRAULIC, STEERING

ссылка	Номер детали	Кол-во	Описание
1	87426127	1	STEERING HYDRAULIC, Steering, See Figure: 05-08
2	700-446	1	ELBOW, 45є, 11/16"-18 ORFS x M18 x 1.5 ORB, 45, M18 or x 11/16" fc sl, Inc. 3 & 4
3	637-64236	6	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
4	238-6012	6	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
5	87312091	1	TUBE, Port, 'P'
6	87347199	1	HOSE,
7	87452749	1	SWITCH, PRESSURE, In-Line Flow
8	87347197	1	HOSE,
9	700-106	1	CONNECTOR, HYD., 11/16"-16 ORFS x M18 x 1.5 ORB, Inc. 3 & 4
10	87436468	1	VALVE, CONTROL, EHPS / Priority, See Figure: 08-12, BSN Z7F202186
10	87585898	1	VALVE, HYDRAULIC, EHPS / Priority, See Figure: 08-12, ASN Z7F202186
11	700-305	4	ELBOW, 90є, 13/16"-18 ORFS x M18 x 1.5 ORB, Inc. 12 & 13
12	637-63153	1	O-RING, Cl 6, 15.3MM ID x 2.2 Thk,
13	238-6014	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
14	87439175	1	HOSE ASSY., 1257 mm (49-1/2")
15	701-423	2	TEE, 13/16"-16 ORFS, Blkd Run, Inc. 13
16	50-2551T1	4	CLAMP,
17	701-903	2	NUT, LOCK, 13/16"-16, ORFS Blkhd,
18	87439172	1	HOSE ASSY., 991 mm (39")
19	700-102	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 12 & 13
20	87304379	1	HOSE ASSY.,
21	367244A1	1	HOSE, 550 mm (21-1/2")
22	367243A1	1	HOSE ASSY., 1605 mm (63")
23	87312871	1	HOSE, 1170 mm (45")
24	242563A1	1	CLAMP,
25	892-11012	1	WASHER, LOCK, M12,
26	829-1412	3	NUT, M12, Cl 10,
27	435468A1	4	PLATE, Cover
28	86556137	2	BOLT, Hex, M8 x 70, 10.9,
29	895-11008	4	WASHER, M8 x 16 x 1.6,
30	832-10408	2	NUT, LOCK, M8 x 1.25, Cl 8,
31	87529571	1	CYLINDER STEERING, Articulation, with Sensor, See Figure: 05-10, BSN Z7F202169
31	87552147	1	CYLINDER STEERING, Articulation, with Sensor, See Figure: 05-10 (01), ASN Z7F202169
32	406999A1	1	CYLINDER STEERING, Articulation, See Figure: 05-06
33	435506A1	2	PIN, 9-1/2"
34	627-16040	4	BOLT, Hex, M16 x 40, 10.9,
35	496-21066	4	WASHER, 21/32" x 1 5/16" x .150",
36	435501A1	4	SPACER,
37	515-23206	1	CLAMP, 13/16", Insul, 3/8" Bolt,
38	364967A1	1	TEE, M18 or x 12 fc sl, Inc. 12 & 13
39	178889A1	1	FITTING, Diagnostic, Inc. 40 - 42
40	86502604	1	DUST CAP, Dust
41	NSS	1	NOT SERVICED SEPARATELY, Fitting
42	637-63113	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,

05-10 INTELLISTEER - CYLINDER ASSY., ARTICULATION, WITH SENSOR, BSN Z7F202169



TJ430 TRACTOR (1/06-) - Steering System

05-10 INTELLISTEER - CYLINDER ASSY., ARTICULATION, WITH SENSOR, BSN Z7F202169

ссылка	Номер детали	Кол-во	Описание
	87529571	1	CYLINDER STEERING, Inc. 1 - 20
1	87397776	1	CASE, Barrel
2	87328593	1	CYLINDER, Rod Sensor, Rear Articulation
3	NSS	1	NOT SERVICED SEPARATELY, O-Ring
4	NSS	1	NOT SERVICED SEPARATELY, SEAL, Piston
5	NSS	1	NOT SERVICED SEPARATELY, RING, Wear
6	87397773	1	PISTON,
7	NSS	1	NOT SERVICED SEPARATELY, O-Ring
8	87397775	1	SHAFT, Rod
9	NSS	1	NOT SERVICED SEPARATELY, WIPER
10	NSS	1	NOT SERVICED SEPARATELY, SEAL, U-Cup
11	87397774	1	HEAD,
12	NSS	1	NOT SERVICED SEPARATELY, O-Ring
13	NSS	1	NOT SERVICED SEPARATELY, RING, Backup
14	NSS	1	NOT SERVICED SEPARATELY, O-Ring
15	NSS	1	NOT SERVICED SEPARATELY, Set Screw
16	NSS	1	NOT SERVICED SEPARATELY, SCREW, Set, 1/4" x 3/8"
17	NSS	1	NOT SERVICED SEPARATELY, O-Ring
18	87397843	1	MAGNET,
19	87397844	2	SPACER,
20	87532453	1	RING, SNAP, Retaining
21	435504A1	2	PIN,
22	87397777	1	KIT, SEALS, Inc. 3 - 5, 7, 9, 10, 12 - 14, 17
23	435501A1	2	SPACER,
24	86625266	2	WASHER, M17.5 x 30 x 4, HT,
25	86529976	2	BOLT, Hex, M16 x 35, 10.9,
26	217-429	2	PLUG, Hex Soc, 1/8"-27 NPTF, Socket Hd, 1/8"
27	80717	1	NIPPLE, LUBE, 45є, 1/8" NPT x 7/8" lg,
28	84015293	1	ELBOW, 90є, 1/8"-27 Female x 1/8"-27 Male, 90, 1/8" NPTF Male x Female
29	1339090C1	1	HOSE,
30	F53473	1	NUT,
31	87364410	1	CONNECTOR, ELEC, Socket, 4 Pin
32	87022296	4	SCREW, Cross Pan Hd, M3 x 8,
33	86636814	1	NIPPLE, LUBE, 1/4"-28 x .52" lg,
34	409685A1	2	JOINT,
35	D95143	8	SEAL, Wiper, Rod

05-10(01) INTELLISTEER - CYLINDER ASSY., ARTICULATION, WITH SENSOR, ASN Z7F202169



05-10(01) INTELLISTEER - CYLINDER ASSY., ARTICULATION, WITH SENSOR, ASN Z7F202169

ссылка	Номер детали	Кол-во	Описание
	87552147	1	CYLINDER STEERING, Inc. 1 - 20
1	87397776	1	CASE, Barrel
2	87552145	1	SENSOR, Rod Sensor, Rear Articulation
3	NSS	1	NOT SERVICED SEPARATELY, O-Ring
4	NSS	1	NOT SERVICED SEPARATELY, SEAL, Piston
5	NSS	1	NOT SERVICED SEPARATELY, RING, Wear
6	87397773	1	PISTON,
7	NSS	1	NOT SERVICED SEPARATELY, O-Ring
8	87397775	1	SHAFT, Rod
9	NSS	1	NOT SERVICED SEPARATELY, WIPER
10	NSS	1	NOT SERVICED SEPARATELY, SEAL, U-Cup
11	87397774	1	HEAD,
12	NSS	1	NOT SERVICED SEPARATELY, O-Ring
13	NSS	1	NOT SERVICED SEPARATELY, RING, Backup
14	NSS	1	NOT SERVICED SEPARATELY, O-Ring
15	NSS	1	NOT SERVICED SEPARATELY, Set Screw
16	NSS	1	NOT SERVICED SEPARATELY, SCREW, Set, 1/4" x 3/8"
17	NSS	1	NOT SERVICED SEPARATELY, O-Ring
18	87397843	1	MAGNET,
19	87397844	2	SPACER,
20	87532453	1	RING, SNAP, Retaining
21	70-6013T2	2	PIN,
22	87397777	1	KIT, SEALS, Inc. 3 - 5, 7, 9, 10, 12 - 14, 17
23	435501A1	2	SPACER,
24	86625266	2	WASHER, M17.5 x 30 x 4, HT,
25	86529976	2	BOLT, Hex, M16 x 35, 10.9,
26	217-429	2	PLUG, Hex Soc, 1/8"-27 NPTF, Socket Hd, 1/8"
27	80717	1	NIPPLE, LUBE, 45є, 1/8" NPT x 7/8" lg,
28	84015293	1	ELBOW, 90є, 1/8"-27 Female x 1/8"-27 Male, 90, 1/8" NPTF Male x Female
29	1339090C1	1	HOSE,
30	F53473	1	NUT,
31	276426A1	1	CONNECTOR, ELEC, Socket, 4 Pin
32	87022296	4	SCREW, Cross Pan Hd, M3 x 8,
33	219-20	1	NIPPLE, LUBE, 1/4"-28 x .52" lg,
34	409685A1	2	JOINT,
35	D95143	8	SEAL, Wiper, Rod
36	87552166	1	SEAL, Boot


2
6
1
5
4
3

ссылка	Номер детали	Кол-во	Описание
	413804A2	1	HANDLE, Throttle, with skip-shift button, Inc. 1 - 3, With Power Shift Transmission
	431530A1	1	HANDLE, Throttle, Inc. 1 - 3, With Manual Shift Transmission without ARU
	413805A1	1	HANDLE, Throttle, Inc. 1 - 3, With Manual Shift Transmission with ARU
1	NSS	1	NOT SERVICED SEPARATELY, Handle
2	414628A1	1	DECAL,
3	235676A1	2	CONNECTOR, , With Manual Shift Transmission with ARU, With Power Shift Transmission
3	276424A1	1	CONNECTOR, WIRE, , With Manual Shift Transmission without ARU
4	435437A1	2	STRAP, CABLE, 7"
5	414193A2	1	BRACKET, , With Power Shift Transmission, With Manual Shift Transmission with ARU
5	410029A2	1	BRACKET, , With Manual Shift Transmission without ARU
6	86642447	1	SCREW, Socket, M5 x 12

06-02 TRANSMISSION SHIFT CONTROLS, MANUAL SHIFT TRANSMISSION



ссылка	Номер детали	Кол-во	Описание
1	REF	1	INSTRUCTION, Box, See Figure: 06-03
	387647A1	1	BELLCRANK, Bell, Inc. 2 - 18
2	396435A2	1	SUPPORT,
3	396444A1	1	CRANK, Linkage Pivot
4	396445A1	1	CRANK, Linkage Pivot
5	396446A1	1	CRANK, Linkage Pivot
6	396447A1	1	CRANK, Linkage Pivot
7	402749A1	8	BALL JOINT,
8	431198A1	4	ROD,
9	9515003	4	BOLT, Hex, M10 x 30, 10.9, Full Thd,
10	403749A1	4	NUT, Lock, M10; 8
11	431052A1	6	BUSHING,
12	398870A1	2	BUSHING,
13	86500689	4	NUT, M10, Cl 10,
14	412355A1	1	BELLOWS,
15	430415A1	1	PIN ASSY.,
16	430546A1	1	SPACER,
17	86624182	1	WASHER, M6 x 18 x 1.6,
18	86505530	1	BOLT, Hex, M6 x 20, 10.9,
	431209A1	1	ROD, Inc. 19, 24-26
	431210A1	1	ROD, Inc. 20, 24-26
	431211A1	1	ROD, Inc. 21, 24-26
	431213A1	1	ROD, Inc. 22, 24-26
	431212A1	1	ROD, Inc. 23, 24-26
19	NSS	1	NOT SERVICED SEPARATELY, Rod, 487 mm (19 in)
20	NSS	1	NOT SERVICED SEPARATELY, Rod, 806 mm (32 in)
21	NSS	1	NOT SERVICED SEPARATELY, Rod, 789 mm (31 in)
22	NSS	1	NOT SERVICED SEPARATELY, Rod, 638 mm (25 in)
23	NSS	1	NOT SERVICED SEPARATELY, Rod, 594 mm (23 in)
24	NSS	1	NOT SERVICED SEPARATELY, Nut, M10; 10
25	402749A1	1	BALL JOINT, Right Hand
26	404639A1	1	BALL JOINT, Left Hand
27	86624978	9	BOLT, Hex, M10 x 35, 10.9, Full Thd,
28	403749A1	13	NUT, Lock, M10; 8
29	86624978	4	BOLT, Hex, M10 x 35, 10.9, Full Thd,
30	86625263	5	WASHER, M8 x 20 x 1.6,
31	43235	5	BOLT, Hex, M8 x 30, 10.9,
32	408566A1	3	INSERT, Threaded
33	86624182	2	WASHER, M6 x 18 x 1.6,
34	120100	2	BOLT, Hex, M6 x 20, 8.8,
35	404287A1	1	INSERT,
36	430415A1	1	PIN ASSY.,
37	86505530	1	BOLT, Hex, M6 x 20, 10.9,
38	430546A1	1	SPACER,
39	410845A4	1	SHROUD,

ссылка	Номер детали	Кол-во	Описание
40	412354A2	2	BELLOWS,
41	418038A1	1	GRIP, Gear Shifter
42	418039A1	1	GRIP, Range Shifter
43	86639303	2	SCREW, Hex Soc Flat Hd, M5 x 12, 10.9,
44	369929A1	2	FASTENER, Christmas Tree
45	449068A1	2	STUD,
46	829-1408	2	NUT, M8, Cl 10,
47	357564A1	2	FASTENER, Velcro

06-03 SHIFTING UNIT ASSEMBLY, WITH MANUAL SHIFT TRANSMISSION



TJ430 TRACTOR (1/06-) - Power Train

06-03 SHIFTING UNIT ASSEMBLY, WITH MANUAL SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	404630A3	1	PANEL, SIDE, Mounting, Left-Hand
2	404632A3	1	PANEL, SIDE, Mounting, Center, Left-Hand
3	404633A3	1	PANEL, SIDE, Mounting, Center, Right-Hand
4	404631A3	1	PANEL, SIDE, Mounting, Right-Hand
5	43235	2	BOLT, Hex, M8 x 30, 10.9,
6	86511855	4	SCREW, Hex Flat Hd, M6 x 12, 4.8,
7	430841A1	1	PIN ASSY.,
8	409795A2	2	CLIP, SPRING, Spring
9	404635A1	2	SPACER,
10	86500688	6	NUT, M6, Cl 10,
11	120100	2	BOLT, Hex, M6 x 20, 8.8,
12	409796A2	2	CLIP, SPRING, Spring
13	404634A1	2	SPACER,
14	86516527	2	BOLT, Hex, M8 x 110, 10.9,
15	300624	1	RING, SNAP, M12, Ext, Ext, M12
16	409790A4	1	LEVER ASSY., Gear Shifter
17	409793A3	1	LEVER ASSY., Range Shifter
18	404644A2	2	LEVER ASSY., Shift, Left Handed
19	419660A2	2	LEVER, Shift, Right Hand
20	86508568	16	BOLT, Hex, M6 x 16, 8.8,
21	398870A1	4	BUSHING,
22	86639312	2	WASHER, M12 x 20 x 2,
23	419737A1	4	GUIDE,
24	419597A2	2	LINKAGE, Shifter
25	431052A1	8	BUSHING,
26	86639189	4	BOLT, Hex, M6 x 60, 10.9,
27	86516395	2	BOLT, Hex, M8 x 90, 10.9,
28	86528579	2	NUT, LOCK, M8 x 1.25, Cl 10,
29	409797A1	2	TORSION SPRING,
30	396431A1	2	TUBE, Mounting, Square
31	412250	4	NUT, LOCK, M8 x 1.25, Cl 8,
32	87426775	1	BRACKET, Shifter Shroud

06-04 CLUTCH PEDAL, MANUAL SHIFT TRANSMISSION



TJ430 TRACTOR (1/06-) - Power Train

06-04 CLUTCH PEDAL, MANUAL SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	222462A2	1	PEDAL,
2	281093A1	2	WASHER,
3	435476A1	1	CABLE,
4	370002	1	RING, SNAP, M25, Ext,
5	278210A1	1	SPRING,
6	397144A1	1	CLEVIS,
7	86637937	1	PIN, CLEVIS, 3/8" x 11/16",
8	280250	1	PIN, SPLIT (COTTER), 3/32" x 3/4",
9	86637933	3	NUT, Jam, 5/16"-24, G5,
10	86637780	1	GROMMET, 5/8" ID x 1 1/4" Groove Dia, Str Cut,
11	435431A1	1	NUT, Jam
12	86521550	2	BOLT, Hex Flg, 1/4"-20 x 3/4", G5, Full Thd,
13	435547A1	1	FLANGE, Flange
14	43362	1	NUT, M8, Cl 10,
15	86639039	1	BOLT, M8 x 35; 10.9
16	417927A1	1	SWITCH, Plunger
17	281893A1	1	BEARING, Pivot
18	43139	2	SCREW,
19	321961A1	2	MOLDING,
20	87448885	1	SUPPORT,
21	435546A1	1	SLEEVE,
22	86643106	2	PIN, SPLIT (COTTER), 1/32" x 3/4",
23	NSS	1	NOT SERVICED SEPARATELY, Clutch Valve
24	435428A1	1	PIN,
25	437369A1	1	BRACKET,
26	413187A1	1	CLAMP,
27	43234	1	BOLT, Hex, M8 x 25, 10.9,
28	86624184	1	WASHER, M8 x 16 x 1.6,
29	86625130	1	PLUG, Dome, 1.250" hole, Nylon, Clutch Cable Clearance Hole

06-05 CLUTCH PEDAL, POWER SHIFT TRANSMISSION



TJ430 TRACTOR (1/06-) - Power Train

06-05 CLUTCH PEDAL, POWER SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	222462A2	1	PEDAL,
2	281093A1	2	WASHER,
3	87448885	1	SUPPORT,
4	370002	1	RING, SNAP, M25, Ext,
5	278210A1	1	SPRING,
6	86625130	1	PLUG, Dome, 1.250" hole, Nylon, Clutch Cable Clearance Hole
7	283659A1	1	SENSOR, Clutch Position
8	305155A2	1	BUSHING,
9	86502967	2	SCREW, Cross Pan Hd, M5 x 30,
10	322409A1	1	PIN,
11	222463A2	1	LINK,
12	435473A1	2	RETAINER, Clip
13	3991509	1	RING, SNAP, M10, Ext, Retaining, M10
14	43362	1	NUT, M8, Cl 10,
15	86639039	1	BOLT, Hex, M8 x 35, 8.8, Full Thd
16	355341A1	1	SWITCH, Plunger
17	281893A1	1	BEARING, Pivot
18	43139	2	SCREW,
19	321961A1	2	MOLDING,

06-06 WHEELS SINGLE AND DUALS WITH SPACERS



TJ430 TRACTOR (1/06-) - Power Train

06-06 WHEELS SINGLE AND DUALS WITH SPACERS

ссылка	Номер детали	Кол-во	Описание
1	402881A1	4	RIM, DW27TB x 32, Single, For Tires: 30.5L-32
2	395702A1	AR	RIM, MW23Ax42, Single or Dual, For Tires: 710/70R42
2	395694A1	AR	RIM, MW23Ax38, Single or Dual, For Tires: 710/70R38, 750/65-38, 710/70R38, 710/65-38
2	395705A1	AR	RIM, W16A x 46, Single or Dual, For Tires: 480/80R46, 520/85R46, 18.4R46
2	395693A1	AR	RIM, WH18A x 38, Single or Dual, For Tires: 520/85R38, 20.8R38
2	395698A1	AR	RIM, WH18A x 42, Single or Dual, For Tires: 520/85R42, 20.8R42
2	395700A1	AR	RIM, MW20A x 42, Single or Dual, For Tires: 620/70R42
2	402882A1	AR	RIM, MW28A x 42, Single or Dual, For Tires: 900/50R42, 850/55-42
2	409213A1	AR	RIM, MW25 x 38, Single or Dual, For Tires: 800/70R38
2	395697A1	AR	RIM, W16A x 42, Single or Dual, For Tires: 480/80R42, 18.4R42
2	402880A1	AR	RIM, W12 x 54, Single or Dual, For Tires: 380/90R54
2	395704A1	AR	RIM, W13 x 46, Single or Dual, For Tires: 420/80R46, 14.9R46
2	87451221	AR	WHEEL, 46 x FDW20A, Single or Dual, For Tires: 620/70R46
3	87312788	4	WHEEL, 32 x DWM44, Used with Single Wheel Dual Hub Application, Scraper Model, For Tires: 76 x 50-32
4	405822A1	1	SPACER, 127 mm (5 in)
5	405823A1	1	SPACER, 254 mm (10 in)
6	405824A1	1	SPACER, 330 mm (13 in)
7	86639173	10	BOLT, Hex, M22 x 150, 10.9, M22x160
8	827-22080	10	BOLT, Hex, M22 x 80, 10.9, Full Thd,
9	86639171	10	BOLT, Hex, M22 x 130, 10.9,
10	86639318	10	WASHER, 24 x 44 x 4 mm
11	A20058	AR	VALVE STEM,
12	412398	64	BOLT, Hex, M16 x 50, 10.9, , Scraper Model, Used with Single Wheel Dual Hub Application
13	86625266	64	WASHER, M17.5 x 30 x 4, HT, , Used with Single Wheel Dual Hub Application, Scraper Model

06-07 WHEELS TRIPLES WITH SPACERS



06-07 WHEELS TRIPLES WITH SPACERS

ссылка	Номер детали	Кол-во	Описание
1	395705A1	12	RIM, W16Ax46, For Tires: 480/80R46, 520/85R46, 18.4R46
1	395698A1	12	RIM, WH18Ax42, For Tires: 520/85R42, 20.8R42
2	409987A1	1	SPACER, 711 mm (28 in)
3	86639318	10	WASHER, 24 x 44 x 4 mm
4	86639172	10	BOLT, Hex, M22 x 140, 10.9,
5	A20058	AR	VALVE STEM,
6	827-22080	10	BOLT, Hex, M22 x 80, 10.9, Full Thd,

06-08 HUB ASSEMBLY MOUNTING



06-08 HUB ASSEMBLY MOUNTING

ссылка	Номер детали	Кол-во	Описание
	405821A1	1	HUB, Inc. 1-5
1	405812A1	1	HUB,
2	405816A1	1	BUSHING, 115 mm (4-1/2 in)
3	396-31081	6	WASHER, 13/16" x 1 1/2" x .219", HDN,
4	228273A1	6	BOLT, CL 10.9, M20 x 110
5	303401A1	3	PLUG, Plastic
6	86977782	4	PIN, LOCK, 1/4" x 1/2", Slotted,
7	A63219	4	KEY, 3/4 x 6
8	86639318	40	WASHER, 24 x 44 x 4 mm
9	827-22080	40	BOLT, Hex, M22 x 80, 10.9, Full Thd,

06-09 DRIVE SHAFT MOUNTING



ссылка	Номер детали	Кол-во	Описание
1	87440506	1	SHAFT, DRIVE, Input, 8C, See Figure: 6-10, with 450 Series Axle, With Manual Shift Transmission
1	87440505	1	SHAFT, DRIVE, Input, 8C, See Figure: 6-10, with 450 Series Axle, With Power Shift Transmission
1	87440503	1	SHAFT, DRIVE, Input, 8C, See Figure: 6-10, With Power Shift Transmission, with 500 Series Axle
2	378758A2	1	DAMPER, Vibration, Also Order 86639139
3	86639139	12	SCREW, 12 Pt Flg, Hd, 7/16"-14 x 1, Flange, 7/16 x 1; 8
4	496-81010	12	WASHER,
5	88685	10	BOLT, Hex, 5/8"-11 x 1 1/2", G8, Full Thd,
6	337476	24	BOLT, Hex, M12 x 50, 10.9, , with 450 Series Axle
6	43263	24	BOLT, Hex, M12 x 60, 10.9, , 500 Series Axle
7	402186A1	1	SHAFT, DRIVE, Front Axle, See Figure: 06-10, 450 Series Axle
7	402191A1	1	SHAFT, DRIVE, Front Axle, See Figure: 06-10, with 500 Series Axle
8	402187A1	1	SHAFT, DRIVE, Articulation, See Figure: 06-10, with 450 Series Axle
8	402192A1	1	SHAFT, DRIVE, Articulation, See Figure: 06-10, 500 Series Axle
9	402188A1	1	SHAFT, DRIVE, Rear Axle, See Figure: 06-10, with 450 Series Axle
9	402193A1	1	SHAFT, DRIVE, Rear Axle, See Figure: 06-10, with 500 Series Axle
10	451767A1	1	BEARING, Support, Pillow Block, See Figure: 06-10
11	86639168	2	BOLT, Hex, M20 x 250, 10.9,
12	86639327	2	WASHER, 22 x 44 x 5 mm
13	9847024	2	NUT, M20, Cl 10,
14	406056A1	1	SPACER,


3
5
2
6
4
1
13
14
15
12
14
13
11
18
19
17
23
20
21
22
16
9
10
8
10
9
7

ссылка	Номер детали	Кол-во	Описание
1	87440506	1	SHAFT, DRIVE, Input, 8C, Inc. 2 - 6, with 450 Series Axle, With Manual Shift Transmission
1	87440505	1	SHAFT, DRIVE, Input, 8C, Inc. 2 - 6, with 450 Series Axle, With Power Shift Transmission
1	87440503	1	SHAFT, DRIVE, Input, 8,5C, Inc. 2 - 6, With Power Shift Transmission, with 500 Series Axle
2	NSS	1	NOT SERVICED SEPARATELY, Shaft, Slip Yoke
3	NSS	1	NOT SERVICED SEPARATELY, Shaft, Flanged
4	337476	4	BOLT, Hex, M12 x 50, 10.9, , with 450 Series Axle
4	43263	4	BOLT, Hex, M12 x 60, 10.9, , with 500 Series Axle
5	404151A1	1	SEAL, Dust
6	86000308	1	KIT, 8C, with 450 Series Axle
6	309093A1	1	SPIDER ASSY., 8,5C, with 500 Series Axle
7	402186A1	1	SHAFT, DRIVE, Front Axle, Inc. 8 - 10, with 450 Series Axle
7	402191A1	1	SHAFT, DRIVE, Front Axle, Inc. 8 - 10, with 500 Series Axle
8	NSS	1	NOT SERVICED SEPARATELY, Shaft
9	337476	8	BOLT, Hex, M12 x 50, 10.9, , with 450 Series Axle
9	43263	8	BOLT, Hex, M12 x 60, 10.9, , with 500 Series Axle
10	431621A1	2	SPIDER ASSY., 8C, with 450 Series Axle
10	309093A1	2	SPIDER ASSY., 8,5C, with 500 Series Axle
11	402187A1	1	SHAFT, DRIVE, Articulation, Inc. 12 - 15, with 450 Series Axle
11	402192A1	1	SHAFT, DRIVE, Articulation, Inc. 12 - 15, with 500 Series Axle
12	NSS	1	NOT SERVICED SEPARATELY, Shaft
13	337476	8	BOLT, Hex, M12 x 50, 10.9, , with 450 Series Axle
13	43263	8	BOLT, Hex, M12 x 60, 10.9, , with 500 Series Axle
14	431621A1	2	SPIDER ASSY., 8C, with 450 Series Axle
14	309093A1	2	SPIDER ASSY., 8,5C, with 500 Series Axle
15	404151A1	1	SEAL,
16	402188A1	1	SHAFT, DRIVE, Rear Axle, Inc. 17 - 18, with 450 Series Axle
16	402193A1	1	SHAFT, DRIVE, Rear Axle, Inc. 17 - 18, with 500 Series Axle
17	NSS	1	NOT SERVICED SEPARATELY, Shaft
18	337476	4	BOLT, Hex, M12 x 50, 10.9, , with 450 Series Axle
18	43263	4	BOLT, Hex, M12 x 60, 10.9, , with 500 Series Axle
19	431621A1	1	SPIDER ASSY., 8C, with 450 Series Axle
19	309093A1	1	SPIDER ASSY., 8,5C, with 500 Series Axle
20	404451A1	1	YOKE, 8C, with 450 Series Axle
20	407633A1	1	YOKE, 8,5C, with 500 Series Axle
21	86637815	1	WASHER, 1 5/16" x 2 1/2" x .150",
22	86637649	1	NUT, LOCK, 1 1/4"-18,
23	451767A1	1	BEARING, Support, Pillow Block

06-11 POWER TAKEOFF - CLUTCH LUBRICATION, MANUAL SHIFT TRANSMISSION



06-11 POWER TAKEOFF - CLUTCH LUBRICATION, MANUAL SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	84989383	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Inc. 2
2	9992298	4	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
3	435901A1	1	BRACKET,
4	435596A1	1	TUBE ASSY.,
5	86579686	2	ELBOW, 90є, 11/16"-18 ORFS x M14 x 1.5 ORB, Inc. 6, 7
6	9993141	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
7	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
8	86579691	1	ELBOW, 90є, 13/16"-18 ORFS x M18 x 1.5 ORB, Includes 2, 10
9	435902A1	1	TUBE ASSY.,
10	86639043	1	O-RING, 15,3 ID x 2,2
11	401365A2	1	BRACKET,
12	86625255	1	WASHER, M13.5 x 24.5 x 3, HT,
13	86529976	1	BOLT, Hex, M16 x 35, 10.9,
14	86579676	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 2, 15
15	86639045	1	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
16	86642463	1	WASHER, 17.5 x 30 x 3.0 mm
17	435598A1	1	TUBE ASSY.,
18	401398A1	1	BRACKET,
19	9706748	2	CLAMP, 5/8", Insul, 5/16" Bolt,
20	86625036	3	CLAMP, 1/2", Insul, 5/16" Bolt,
21	43235	2	BOLT, Hex, M8 x 30, 10.9,
22	43362	1	NUT, M8, Cl 10,
23	355788	2	BOLT, Hex, M10 x 70, 10.9,
24	413944A1	1	VALVE, Control, P.T.O., See Figure: 6-13
25	14457081	5	O-RING, -112, Cl 7, .487" ID x .103" Thk,
26	86624184	8	WASHER, M8 x 16 x 1.6,
27	43260	1	BOLT, Hex, M12 x 30, 10.9,

06-12 POWER TAKEOFF - CLUTCH LUBRICATION, POWER SHIFT TRANSMISSION



сылка	Номер детали	Кол-во	Описание
1	86579671	2	CONNECTOR, HYD., 11/16"-16 ORFS x M14 x 1.5 ORB, Inc. 2, 3
3	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
4	87436852	1	TUBE ASSY.,
5	86625036	1	CLAMP, 1/2", Insul, 5/16" Bolt,
6	43233	1	BOLT, Hex, M8 x 20, 10.9,
7	43362	1	NUT, M8, Cl 10,
8	86579691	2	ELBOW, 90є, 13/16"-18 ORFS x M18 x 1.5 ORB, Includes 9, 10
9	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
10	86639043	1	O-RING, 15.3 ID x 2.2 W
11	355788	2	BOLT, Hex, M10 x 70, 10.9,
12	413944A1	1	VALVE, P.T.O., See Figure: 06-13
13	14458081	5	O-RING, -122, Cl 7, 1.112" ID x .103" Thk,
14	414550A1	1	TUBE ASSY.,
15	414553A1	1	BRACKET,
16	86637978	1	CLAMP, 3/8", Insul, 5/16" Bolt,
2	9993141	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,

06-13 VALVE ASSY POWER TAKE OFF



TJ430 TRACTOR (1/06-) - Power Train

06-13 VALVE ASSY POWER TAKE OFF

ссылка	Номер детали	Кол-во	Описание
	413944A1	1	VALVE, Control, Power Takeoff, Inc. 1 - 24
1	NSS	1	NOT SERVICED SEPARATELY, Body
2	221578A1	4	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 3
3	86639043	4	O-RING, 15.3 ID x 2.2
	318822A1	1	VALVE, SOLENOID, Solenoid, Inc. 4 - 9
4	NSS	1	NOT SERVICED SEPARATELY, Coil
5	NSS	1	NOT SERVICED SEPARATELY, Valve, Solenoid
6	NSS	1	NOT SERVICED SEPARATELY, Nut
7	128825	1	O-RING, 8-1, 90 Duro, .644" ID x .087" Thk,
8	130282	1	O-RING, -014, 70 Duro, .489" ID x .070" Thk,
9	129270	1	O-RING, 5-1, 90 Duro, .414" ID x .072" Thk,
	315514A1	1	PLUG, Inc. 10 - 13
10	NSS	1	NOT SERVICED SEPARATELY, Plug
11	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
12	272217	1	O-RING, -013, 90 Duro, .426" ID x .070" Thk,
13	128825	1	O-RING, 8-1, 90 Duro, .644" ID x .087" Thk,
	345794A1	1	PLUG, Inc. 14, 15
14	NSS	1	NOT SERVICED SEPARATELY, Plug
15	86639045	1	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
16	319664A1	1	SLEEVE,
17	319665A1	1	PISTON,
18	319661A1	1	SPRING, Inner
19	319660A1	1	SPRING, Outer
20	221576A1	1	PLUG, Hex Soc, M14 x 1.5, ORB, Includes 21
21	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
22	320036A1	1	SPOOL,
23	322118A1	1	NUT, Special
24	319659A1	1	SPRING,

06-14 POWER TAKEOFF - LUBRICATION



ссылка	Номер детали	Кол-во	Описание
1	86632602	4	WASHER, LOCK, Ext Tooth, M10,
2	9846677	4	BOLT, Hex, M10 x 25, 10.9, Full Thd,
3	86992408	1	FITTING, Flange
4	86579676	3	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 14, 15
5	86639043	1	O-RING, 15,3 ID x 2,2
6	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
7	86994526	1	HOSE ASSY., 1270 mm (50 in)
8	86579680	1	CONNECTOR, HYD., 1"-14 ORFS x M22 x 1.5 ORB, Includes 9, 11
9	86642449	1	O-RING, Cl 6, 13.3MM ID x 2.2 Thk,
10	86994525	1	HOSE ASSY., 3251 mm (128 in), 450 Series Axle
10	87400234	1	HOSE ASSY., 1803 mm (71 in), 500 Series Axle
11	9992069	2	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
12	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,

06-15 POWER TAKEOFF - DRIVE SHAFT MOUNTING



06-15 POWER TAKEOFF - DRIVE SHAFT MOUNTING

ссылка	Номер детали	Кол-во	Описание
1	404798A1	1	SHAFT, Articulation, See Figure: 06-16
2	L116943	8	CLAMP,
3	86639301	16	SCREW, 12 Pt Hd, M10 x 20, 12.9,
4	NSS	1	NOT SERVICED SEPARATELY, Bearing Assy, Hanger, See Figure: 06-16
5	404604A1	1	BRACKET,
6	86577946	4	BOLT, Hex, M16 x 80, 10.9, , with 450 Series Axle
6	86521733	4	BOLT, Hex, M16 x 90, 10.9, , with 500 Series Axle
7	86625266	4	WASHER, M17.5 x 30 x 4, HT,
8	404799A1	1	SHAFT, DRIVE, Rear, See Figure: 06-16

06-16 POWER TAKEOFF - DRIVE SHAFT ASSEMBLIES



06-16 POWER TAKEOFF - DRIVE SHAFT ASSEMBLIES

ссылка	Номер детали	Кол-во	Описание
1	404798A1	1	SHAFT, Articulation, Inc. 2 - 6
2	NSS	1	NOT SERVICED SEPARATELY, Yoke, Slip
3	NSS	1	NOT SERVICED SEPARATELY, Shaft
4	443088A1	1	RETAINER, SEAL,
5	S300313	2	SPIDER ASSY., Inc. 6
6	S92378	4	SNAP RING, Retaining
7	399447A1	1	HOUSING, BEARING, Hanger
8	399446A1	1	SHAFT,
9	435535A1	2	BEARING, CUP, Cup
10	435536A1	2	BEARING, CONE, Cone
11	435537A1	2	SEAL,
12	398554A1	2	YOKE,
13	435427A1	2	WASHER, 5/8 x 2-3/4 x 1/2
14	374835	2	BOLT, Hex, M16 x 40, 10.9,
15	80717	1	NIPPLE, LUBE, 45є, 1/8" NPT x 7/8" lg,
16	404799A1	1	SHAFT, DRIVE, Rear, Inc. 17 - 21
17	NSS	1	NOT SERVICED SEPARATELY, Shaft
18	NSS	1	NOT SERVICED SEPARATELY, Yoke, Slip
19	443088A1	1	RETAINER, SEAL,
20	S300313	2	SPIDER ASSY., Inc. 21
21	S92378	4	SNAP RING, Retaining

06-17 POWER TAKEOFF - SAFETY SHEILDS



TJ430 TRACTOR (1/06-) - Power Train

06-17 POWER TAKEOFF - SAFETY SHEILDS

ссылка	Номер детали	Кол-во	Описание
1	403073A1	1	GEARBOX ASSY, Transfer, See Figure: 06-18
2	405394A1	2	BRACE,
3	827-12055	4	BOLT, Hex, M12 x 55, 10.9, , With Three Point Hitch
4	412123	4	WASHER, LOCK, M12,
5	337475	4	NUT, M12, Cl 10,
6	405396A1	1	COVER, RH
7	405395A1	1	COVER, LH
8	405397A1	1	SHIELD, Flip-up
9	86625255	10	WASHER, M13.5 x 24.5 x 3, HT,
10	43260	6	BOLT, Hex, M12 x 30, 10.9, , With Three Point Hitch
10	43260	10	BOLT, Hex, M12 x 30, 10.9, , Without Three Point Hitch
11	365853A1	2	SPRING,
12	86625263	2	WASHER, M8 x 20 x 1.6,
13	86639115	2	PIN, SPLIT (COTTER), M2 x 12,
14	327567A3	1	DECAL, Safety, See Figure: 09-54
15	86639032	2	BOLT, Hex, M16 x 25, 10.9, Full Thd,
16	405398A1	1	BRACKET, If Used
17	383716A1	1	SHIELD, Shaft, PTO
18	9515003	2	BOLT, Hex, M10 x 30, 10.9, Full Thd,
19	86625260	4	WASHER, M20 x 37.5 x 4, HT,
20	827-20230	4	BOLT, Hex, M20 x 230, 10.9,
21	259389A1	2	PLATE,
22	435501A1	2	SPACER,
23	86625266	2	WASHER, M17.5 x 30 x 4, HT,

06-18 POWER TAKEOFF TRANSFER CASE ASSEMBLY



06-18 POWER TAKEOFF TRANSFER CASE ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
	403073A1	1	GEARBOX ASSY, Transfer, Inc. 1 - 24
1	375500A1	1	HOUSING, Rear
2	375501A1	1	HOUSING, Front
3	428183A1	5	BEARING,
4	375502A1	1	GEAR, Input
5	375503A1	1	BEARING,
6	375504A1	AR	SHIM,
6	375505A1	AR	SHIM,
6	375506A1	AR	SHIM,
6	375507A1	AR	SHIM,
7	375508A1	1	GEAR, Idler
8	428665A1	AR	SHIM, 0,10 mm (0,004 in)
8	428666A1	AR	SHIM, 0,30 mm (0,012 in)
8	428667A1	AR	SHIM, 0,50 mm (0,020 in)
8	428668A1	AR	SHIM, 0,70 mm (0,027 in)
8	428669A1	AR	SHIM, 0,15 mm (0,006 in)
9	375509A1	1	SHAFT, Output
10	S2240S00F	1	SNAP RING, Retaining
11	375510A1	1	GEAR, Output
12	375511A1	1	SPACER,
13	S8820S00F	1	SEAL, OIL,
14	398447A1	1	YOKE,
15	375512A1	1	O-RING,
16	S9950S00F	AR	SHIM, 0,10 mm (0,004 in)
16	S9960S00F	AR	SHIM, 0,30 mm (0,012 in)
16	S9970S00F	AR	SHIM, 0,51 mm (0,020 in)
16	S9980S00F	AR	SHIM, 0,71 mm (0,027 in)
17	S8860S00F	1	WASHER, THRUST,
18	86637960	1	BOLT, Hex, M16 x 1.5 x 35, 10.9, Full Thd,
19	375514A1	1	SEAL, OIL,
20	427530A1	2	DOWEL, Dowel
21	86589753	3	PLUG, M18 x 15, Inc. 22
22	86639043	3	O-RING, 15.3 ID x 2.2
23	375515A1	4	PLUG,
24	86637969	10	BOLT, Hex, M12 x 1.25 x 25, 8.8, Full Thd,

06-19 POWER TAKEOFF CLUTCH ASSEMBLY



TJ430 TRACTOR (1/06-) - Power Train

06-19 POWER TAKEOFF CLUTCH ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
1	375550A1	1	HOUSING,
2	375551A1	1	HOUSING,
3	375552A1	1	HOUSING,
4	375553A1	1	GASKET, Housing
5	220064A1	9	PLUG, M14 x 1.5, ORB, M14 - 1,5, Inc. 6
6	86639042	9	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
7	S9910S00F	AR	SHIM, 0,10 mm (0,004 in)
7	S9920S00F	AR	SHIM, 0,30 mm (0,012 in)
7	S9930S00F	AR	SHIM, 0,50 mm (0,020 in)
7	S9940S00F	AR	SHIM, 0,70 mm (0,027 in)
8	S8860S00F	1	WASHER, THRUST,
9	S9950S00F	AR	SHIM, 0,10 mm (0,004 in)
9	S9960S00F	AR	SHIM, 0,30 mm (0,012 in)
9	S9970S00F	AR	SHIM, 0,51 mm (0,020 in)
9	S9980S00F	AR	SHIM, 0,71 mm (0,027 in)
10	375512A1	1	O-RING,
11	398447A1	1	YOKE,
12	S8820S00F	1	SEAL, OIL,
13	ST293	1	BEARING, BALL,
14	375554A1	1	GEAR, Driven
15	375555A1	1	SHAFT, Output
16	375559A1	1	BEARING, BALL, Roller
17	375560A1	1	SNAP RING, Snap
18	375556A1	1	GASKET, Cover
19	427530A1	4	DOWEL,
20	SM8124208	2	BOLT,
21	86642436	4	SCREW, M12 x 1,5; 8.8
22	86642440	2	BOLT, M12 x 1,25; 8.8
23	43128	5	BOLT, Hex, M8 x 30, 8.8,
24	86637960	1	BOLT, Hex, M16 x 1.5 x 35, 10.9, Full Thd,
25	86642437	2	BOLT, M12 x 1,25; 8.8
26	86642439	7	BOLT, M12 x 1,25; 8.8
27	428660A1	1	SLEEVE, , Used on Power Shift Models
28	300647	1	RING, SNAP, M47, Int, Int, M47, Used on Power Shift Models
29	NSS	1	NOT SERVICED SEPARATELY, 7, Input, See Figure: 06-20
30	376972A1	1	TROUGH,
31	86977726	2	BOLT, Hex, M6 x 12, 8.8,

06-20 POWER TAKEOFF INPUT SHAFT ASSEMBLY



06-20 POWER TAKEOFF INPUT SHAFT ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
1	S3070S00F	2	RING, Seal
2	S8730S00F	1	BEARING, ROLLER,
3	375523A1	4	BOLT,
4	375525A1	1	PLATE,
5	375527A1	1	PLATE,
6	375528A1	2	DISC, CLUTCH, Face, 7
7	S2080S00F	8	DISC, CLUTCH, 2,4 mm
8	375529A1	7	DISC, CLUTCH, Face, 7
9	375530A1	1	HUB,
10	375531A1	16	SPRING, COIL, Brake Return
11	375532A1	16	PIN,
12	375533A1	1	PISTON,
13	352834A1	1	RING, Seal
14	375534A1	2	PLATE, BRAKE, Steel Brake
15	375535A1	2	PLATE, BRAKE, Brake Face
16	375536A1	1	PLATE, BRAKE, Steel Brake
17	375538A1	1	DRUM,
18	S2240S00F	1	SNAP RING, Retaining
19	S2220S00F	4	WASHER, THRUST, 2,4 mm
20	572182R1	2	BEARING, THRUST,
21	S5510S00F	1	RING,
22	375540A1	1	PINION,
23	86637966	10	BOLT, Hex, M10 x 1.25 x 35, 8.8, Full Thd,
24	375541A1	2	RETAINER, SEAL, Seal
25	375542A1	1	SHAFT, Input
26	375543A1	1	BEARING,
27	375544A1	1	RING, SNAP, Retaining
28	375545A1	1	WASHER,
29	375546A1	1	BEARING, CUP,
29	186621A1	1	BEARING, CONE,
30	375547A1	AR	RING, SNAP, Retaining
30	375548A1	AR	RING, SNAP, Retaining
30	375544A1	AR	RING, SNAP, Retaining

06-21 TRANSMISSION MOUNTING - MANUAL SHIFT



ссылка	Номер детали	Кол-во	Описание
1	388851A1	2	PLATE, Mounting, LH
2	397581A1	1	PLATE, Mounting, RH
3	86639318	4	WASHER, 24 x 44 x 4 mm
4	86642453	4	BOLT, M22 x 190; 10.9
5	76088717	8	WASHER,
6	340967A1	4	MOUNT, RUBBER,
7	86642454	4	NUT, Lock, M22; 8
8	9843495	8	BOLT, Hex, M20 x 60, 10.9,
9	86511674	4	BOLT, Hex, M20 x 120, 10.9,

06-22 TRANSMISSION MOUNTING - POWER SHIFT



06-22 TRANSMISSION MOUNTING - POWER SHIFT

ссылка	Номер детали	Кол-во	Описание
1	408706A1	1	PLATE, Mounting, LH
2	87335427	1	PLATE, MOUNTING, Mounting, RH
3	86639318	4	WASHER, 24 x 44 x 4 mm
4	86642453	4	BOLT, M22 x 190; 10.9
5	76088717	8	WASHER,
6	340967A1	4	MOUNT, RUBBER,
7	86642454	4	NUT, M22; 10
8	9843495	1	BOLT, Hex, M20 x 60, 10.9,

06-23 TRANSMISSION LUBRICATION, WITH MANUAL SHIFT TRANSMISSION



TJ430 TRACTOR (1/06-) - Power Train

06-23 TRANSMISSION LUBRICATION, WITH MANUAL SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	370546A1	1	PUMP,
2	86637709	2	CLAMP, HOSE, 1.25/2.625 HD Worm,
3	427140A1	1	HOSE,
4	418735A1	1	TUBE ASSY.,
5	86637769	1	O-RING, -228, 90 Duro, 2.234" ID x .139" Thk,
6	A14141	2	FLANGE,
7	9824642	4	BOLT, Hex, M12 x 35, 10.9,
8	86579685	1	CONNECTOR, HYD., 1 11/16"-12 ORFS x M42 x 2 ORB, Inc. 9, 10
9	9824051	1	O-RING, -025, 90 Duro, 1.176" ID x .070" Thk,
10	86639047	4	O-RING, Cl 6, 38.6MM ID x 2.9 Thk,
11	414480A2	1	TUBE ASSY., Transmission Fill
12	325737A1	1	CAP,
13	700-105	1	CONNECTOR, HYD., 1 7/16"-12 ORFS x M22 x 2 ORB, Inc. 10, 15
14	416102A1	1	SUPPORT, Bracket
15	238-6021	5	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
16	86580179	1	CONNECTOR, HYD., 1 7/16"-12 ORFS x M22 x 2 ORB, Includes 10, 15
17	87305825	1	TUBE ASSY., Transmission Pump to Filter
18	87338377	1	TUBE, HYD, Filter to Transmission Return
19	87305990	1	HOSE ASSY., 851 mm (33 - 1/2 in), Supply
20	87305991	1	HOSE ASSY., 866 mm (34 in), Outlet
21	86580179	1	CONNECTOR, HYD., 1 7/16"-12 ORFS x M22 x 2 ORB, Includes 10, 15
22	9827902	4	CLAMP, 1", Insul, 3/8" Bolt,
23	438240A1	1	TUBE ASSY.,
24	43233	2	BOLT, Hex, M8 x 20, 10.9,
25	86500689	2	NUT, M10, Cl 10,
26	86624176	2	WASHER, M10 x 20 x 2,
27	86639002	1	CLAMP, 1 3/8", Insul, 7/16" Bolt, 1-3/8 ID
28	43362	4	NUT, M8, Cl 10,
29	86624184	6	WASHER, M8 x 16 x 1.6,
30	L116247	1	GAUGE, Inc. Hardware
31	S14701960	1	BALL,
32	370551A1	1	TUBE ASSY.,
33	412160	2	BOLT, Hex, M10 x 1.25 x 30, Cl8.8, Full Thd,
	186135A1	1	KIT, Transmission Heater, Inc. 34 - 36
34	367930A1	1	ADAPTER,
35	385486A1	1	HEATER ASSY., 120 V, with Cord Set
35	387062A1	1	HEATER UNIT, 240 V, with Cord Set
36	435437A1	5	STRAP, CABLE, 7 in
37	427516A1	1	SNAP RING,
38	427523A1	1	ADAPTER,
39	86639140	1	RING, SNAP, M50 Int, Snap
40	427521A1	1	COUPLING,
41	419491A3	1	HOSE,
42	86624176	4	WASHER, M10 x 20 x 2,
43	412141	2	NUT, LOCK, M10 x 1.5, Cl 8,

ссылка	Номер детали	Кол-во	Описание
44	86508618	2	BOLT, Hex, M10 x 45, 10.9,
45	507586	1	CLAMP, HOSE, #20, 0.81/1.75 Type F Worm,
46	84674	1	CLAMP, HOSE, #28, 1.31/2.25 Type F Worm,
47	429193A1	1	TUBE ASSY.,

06-24 TRANSMISSION LUBRICATION, WITH POWER SHIFT TRANSMISSION



TJ430 TRACTOR (1/06-) - Power Train

06-24 TRANSMISSION LUBRICATION, WITH POWER SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	370546A1	1	PUMP,
2	86637709	2	CLAMP, HOSE, 1.25/2.625 HD Worm,
3	435454A1	1	HOSE, 102 mm (4 in)
4	408581A1	1	TUBE,
5	86637769	1	O-RING, -228, 90 Duro, 2.234" ID x .139" Thk,
6	A14141	2	FLANGE,
7	9824642	4	BOLT, Hex, M12 x 35, 10.9,
8	86579685	1	CONNECTOR, HYD., 1 11/16"-12 ORFS x M42 x 2 ORB, Inc. 9, 10
9	9824051	1	O-RING, -025, 90 Duro, 1.176" ID x .070" Thk,
10	86639046	3	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
11	419491A3	1	HOSE, Transmission Fill
12	325737A1	1	CAP,
13	86580180	1	ELBOW, 90є, 1 7/16"-12 ORFS x M33 x 2 ORB, Includes 10, 15
14	412141	2	NUT, LOCK, M10 x 1.5, Cl 8,
15	9824050	4	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
16	87305825	1	TUBE ASSY., Transmission Pump to Filter
17	87338377	1	TUBE, HYD, Filter to Transmission Return
18	9827902	3	CLAMP, 1", Insul, 3/8" Bolt,
19	87305833	1	HOSE ASSY., 775 mm (30-1/2 in), Supply
20	87305831	1	HOSE ASSY., 1399 mm (55 in), Outlet
21	86580179	3	CONNECTOR, HYD., 1 7/16"-12 ORFS x M22 x 2 ORB, Includes 22, 23
22	86508618	2	BOLT, Hex, M10 x 45, 10.9,
23	86624184	4	WASHER, M8 x 16 x 1.6,
24	43362	3	NUT, M8, Cl 10,
25	86500689	2	NUT, M10, Cl 10,
26	86624184	4	WASHER, M8 x 16 x 1.6,
27	515-24317	8	CLAMP, 1 1/4", Insul, 7/16" Bolt,
28	43362	2	NUT, M8, Cl 10,
29	86624184	3	WASHER, M8 x 16 x 1.6,
30	L116247	1	GAUGE, Inc. Hardware
31	S14701960	1	BALL,
32	370551A1	1	TUBE ASSY.,
33	412160	2	BOLT, Hex, M10 x 1.25 x 30, Cl8.8, Full Thd,
	186135A1	1	KIT, Transmission Heater, Inc. 34 - 36
34	367930A1	1	ADAPTER,
35	385486A1	1	HEATER ASSY., 120 V, with Cord Set
35	387062A1	1	HEATER UNIT, 240 V, with Cord Set
36	435437A1	5	STRAP, CABLE, 7 in
37	432444A1	1	SPACER,
38	84674	1	CLAMP, HOSE, #28, 1.31/2.25 Type F Worm,
39	414480A2	1	TUBE ASSY., Fill
40	178889A1	1	FITTING, Diagnostic, Inc. 41 - 43
41	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
42	NSS	1	NOT SERVICED SEPARATELY, Fitting
43	86502604	1	DUST CAP, Dust

06-24 TRANSMISSION LUBRICATION, WITH POWER SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
44	214-1420	1	CLAMP, HOSE, #20, 0.81/1.75 Type F Worm,
45	429193A1	1	TUBE ASSY., Fitting, 1-1/4" barb x 1-11/16" fc sl

06-25 MANUAL SHIFT TRANSMISSION - VALVE ASSEMBLY MOUNTING



06-25 MANUAL SHIFT TRANSMISSION - VALVE ASSEMBLY MOUNTING

сылка	Номер детали	Кол-во	Описание
1	428114A1	1	VALVE, High / Low
2	428123A1	1	GASKET, Mounting
3	331175	4	BOLT, Hex, M8 x 75, 8.8,
4	428091A1	1	VALVE, Control, Lockout, See Figure: 06-38
5	427594A1	2	SCREW, Socket
6	427593A1	2	SCREW, Socket
7	428083A1	1	VALVE, See Figure: 06-37
8	86637965	2	BOLT, Hex, M10 x 90, 8.8,
9	86637968	2	BOLT, Hex, M10 x 1.25 x 120, 8.8,
10	427581A1	1	GASKET, Mounting
11	428096A1	1	VALVE, Regulator, See Figure: 06-39
12	86639028	5	BOLT, Hex, M8 x 65, 8.8, Full Thd,
13	86639029	3	BOLT, Hex, M8 x 75, 8.8, Full Thd,
14	S1150S02F	1	GASKET, Mounting
	371737A1	1	VALVE, SOLENOID, Three-way, Inc. 15 - 17
15	NSS	4	NOT SERVICED SEPARATELY, O-Ring
16	370600A1	1	VALVE, SOLENOID, Pilot Assy.
17	371739A1	1	COIL,


11
12
13
14
49
3
4
5
6
52
7
22
21
8
47
48
57
58
59
53
17
50
15
16
10
9
18
20
19
42
24
23
51
2
1
27
25
30
31
29
26
55
54
28
43
44
46
45
33
34
35
36
37
38
39
40
41

ссылка	Номер детали	Кол-во	Описание
1	427538A1	1	HOUSING, Rear
2	427588A1	1	HOUSING, Front
3	427539A1	1	PLATE, RETAINING,
4	427560A1	AR	SHIM, 0.10 mm (0,004 in)
4	427561A1	AR	SHIM, 0.30 mm (0,012 in)
4	427562A1	AR	SHIM, 0.70 mm (0,028 in)
5	510207	1	O-RING, -327, 90 Duro, 1.725" ID x .210" Thk,
6	373136A1	1	COUPLING FLANGE, 8C, Input, with 450 Series Axle
6	362563A1	1	COUPLING FLANGE, 8.5C, Input, with 500 Series Axle
7	428159A1	1	SEAL, OIL,
8	428098A1	1	RETAINER, Input
9	428099A1	1	GASKET, Mounting
10	427564A1	AR	SHIM, 0.1 mm (0,004 in)
10	427565A1	AR	SHIM, 0.15 mm (0,006 in)
10	427566A1	AR	SHIM, 0.3 mm (0,012 in)
10	427567A1	AR	SHIM, 0.5 mm (0,020 in)
10	427568A1	AR	SHIM, 0.7 mm (0,028 in)
11	362566A1	1	ADAPTER, Pump
12	301642	1	RING, SNAP, M28, Int,
13	362567A1	1	COUPLING,
14	86639140	1	RING, SNAP, M50 Int, Snap
15	428126A1	1	RETAINER, Second Shaft
16	428100A1	1	GASKET, Mounting, Second Shaft
17	427592A1	1	PLATE, RETAINING,
18	427591A1	1	GASKET, Mounting
19	427557A1	1	RETAINER, Third Shaft
20	427582A1	1	GASKET, Mounting, Third Shaft
21	412160	12	BOLT, Hex, M10 x 1.25 x 30, Cl8.8, Full Thd,
22	427569A1	1	WASHER, Retaining
23	86637971	4	BOLT, Hex, M12 x 1.25 x 30, 8.8, Full Thd,
24	427559A1	2	SCREW,
25	428149A1	1	O-RING,
26	427586A1	1	PLATE ASSY., Ditch
27	427583A1	1	GASKET, Mounting
28	427556A1	1	RETAINER, Fourth Shaft
29	86637963	5	BOLT, Hex, M10 x 1.25 x 40, 8.8, Full Thd,
30	86589753	1	PLUG, M18 x 15, Inc. 31
31	86639043	1	O-RING,
32	86642451	1	CIRCLIP, Snap
33	427515A1	2	PLATE, RETAINING,
34	427517A1	AR	SHIM, 0,10 mm (0,004 in)
34	427519A1	AR	SHIM, 0,30 mm (0,012 in)
35	428165A1	2	O-RING,
36	427551A1	1	YOKE, 8C, Output, with 450 Series Axle
36	427550A1	1	YOKE, 8,5C, Output, with 500 Series Axle

ссылка	Номер детали	Кол-во	Описание
37	427549A1	1	RING,
38	427514A1	2	SEAL, OIL,
39	427563A1	1	RETAINER, Output
40	427547A1	1	GASKET, Mounting
41	373138A1	1	COUPLING FLANGE, 8C, Output, with 450 Series Axle
41	362604A1	1	COUPLING FLANGE, 8,5C, Output, with 500 Series Axle
42	427558A1	1	COVER, Power Takeoff
43	303493A1	2	PLUG, Hex Soc, M42 x 2, ORB, Drain; M42 orb x 2; Inc. 44
44	86639047	2	O-RING, Cl 6, 38.6MM ID x 2.9 Thk,
45	375456A1	1	PLUG, DRAIN, M42 orb x 2; Inc. 46
46	86639047	1	O-RING, Cl 6, 38.6MM ID x 2.9 Thk,
47	220064A1	3	PLUG, M14 x 1.5, ORB, M14 - 1.5; Inc. 50
48	86639042	3	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
49	428181A1	3	BOLT,
50	428180A1	6	BOLT, M10 x 35
51	86637972	1	BOLT, Hex, M12 x 1.25 x 20, 8.8, Full Thd,
52	86637967	2	BOLT, Hex, M10 x 1.25 x 45, 8.8, Full Thd,
53	86637964	4	BOLT, Hex, M10 x 1.25 x 50, 8.8, Full Ths,
54	16043224	2	BOLT, Hex, M8 x 16, 8.8, Full Thd,
55	86637970	6	BOLT, Hex, M12 x 1.25 x 35, 8.8, Full Thd,
56	86637974	4	BOLT, Hex, M12 x 1.25 x 25, 8.8, Full Thd,
	178889A1	2	FITTING, Diagnostic; Inc. 57, 58
57	86502604	1	DUST CAP, Dust
58	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 59
59	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,

06-27 MANUAL SHIFT TRANSMISSION - REAR HOUSING



ссылка	Номер детали	Кол-во	Описание
1	427666A1	7	SCREW, Socket
2	428151A1	2	DOWEL, Dowel
3	427664A1	1	SHAFT, Idler
4	427662A1	2	BEARING, ROLLER, TAPERED,
5	427659A1	1	GEAR, IDLER, Reverse
6	S9950S00F	AR	SHIM,
6	S9960S00F	AR	SHIM,
6	S9970S00F	AR	SHIM,
6	S9980S00F	AR	SHIM,
7	427661A1	1	WASHER, Retaining
8	86637960	1	BOLT, Hex, M16 x 1.5 x 35, 10.9, Full Thd,
9	86977726	7	BOLT, Hex, M6 x 12, 8.8,
10	427578A1	1	TROUGH,
11	427616A1	1	PLATE, SUPPORT,
12	428172A1	12	WASHER, Lock
13	86637970	12	BOLT, Hex, M12 x 1.25 x 35, 8.8, Full Thd,
14	427553A1	1	SCREW, Socket
15	427554A1	1	WASHER, Retaining
16	86637966	3	BOLT, Hex, M10 x 1.25 x 35, 8.8, Full Thd,
17	427576A1	1	TROUGH,
18	427538A1	1	HOUSING,
19	86639257	1	PIN, LOCK, M5 x 18, Slotted,
20	427579A1	1	TROUGH, First Gear
21	427580A1	1	TROUGH, Second Gear
22	428157A1	1	O-RING,
23	427615A1	1	SHAFT,
24	427613A1	2	BEARING, ROLLER, TAPERED,
25	427614A1	1	GEAR, IDLER,
26	427570A1	AR	SHIM, 0,10 mm (0,004 in)
26	427571A1	AR	SHIM, 0,15 mm (0,006 in)
26	427572A1	AR	SHIM, 0,30 mm (0,012 in)
26	427573A1	AR	SHIM, 0,70 mm (0,028 in)
27	428152A1	2	DOWEL, Dowel
28	428144A1	1	LEVER, 1-R Gears
29	428146A1	1	LEVER, A-B Range
30	428140A1	1	SUPPORT, Lever, 1-R Gears
31	412159	4	BOLT, Hex, M10 x 1.25 x 25, 8.8, Full Thd,
32	SM831050	3	PIN,
33	428128A1	4	BEARING, NEEDLE,
34	428129A1	2	SEAL, OIL,
35	428127A1	2	LEVER, Range / Gear Shifter
36	428142A1	1	SUPPORT, Lever, A-B Range
37	427546A1	1	BAFFLE, Oil
38	86637962	2	BOLT, Hex, M10 x 1.25 x 20, 8.8, Full Thd,
39	86624176	2	WASHER, M10 x 20 x 2,

ссылка	Номер детали	Кол-во	Описание
40	86637974	2	BOLT, Hex, M12 x 1.25 x 25, 8.8, Full Thd,
41	427548A1	1	STRAP, Left-Hand
42	SM8911240	2	NUT,
43	427545A1	1	STRAP, Right-Hand


1
2
3
4
5
6
16
7
8
14
12
11
13
10
14
9
14
10
15
11
13

ссылка	Номер детали	Кол-во	Описание
1	86977726	7	BOLT, Hex, M6 x 12, 8.8,
2	427575A1	1	BAFFLE,
3	427574A1	1	GASKET,
4	428156A1	1	PLUG,
5	427524A1	1	BREATHER,
6	370632A1	1	TUBE, Breather
7	428145A1	1	LEVER, 2-3 Gears
8	428147A1	1	LEVER, C-D Range
9	428127A1	2	LEVER, Range / Gear Shift
10	SM831050	2	PIN,
11	412159	4	BOLT, Hex, M10 x 1.25 x 25, 8.8, Full Thd,
12	428141A1	1	SUPPORT, Lever, 2-3 Gears
13	428129A1	2	SEAL, OIL,
14	428128A1	4	BEARING, NEEDLE,
15	428143A1	1	SUPPORT, Lever, C-D Range
16	427588A1	1	HOUSING, Front

06-29 MANUAL SHIFT TRANSMISSION - SHAFT ASSY AND SHIFTER FORKS



06-29 MANUAL SHIFT TRANSMISSION - SHAFT ASSY AND SHIFTER FORKS

ссылка	Номер детали	Кол-во	Описание
1	86637975	13	BOLT, Hex, M12 x 1.25 x 60, 8.8, Full Thd,
2	427530A1	2	DOWEL, Dowel
3	427577A1	1	TROUGH, Reverse Idler
4	86977726	2	BOLT, Hex, M6 x 12, 8.8,
5	428120A1	1	SHAFT ASSY., Input, See Figure : 06-31
6	427681A1	1	SHAFT ASSY., Fourth, See Figure : 06-35
7	427647A1	2	SHAFT ASSY., Third, See Figure : 06-34
8	427690A1	1	SHAFT ASSY., Fifth, See Figure : 06-36
9	86637962	2	BOLT, Hex, M10 x 1.25 x 20, 8.8, Full Thd,
10	428138A1	1	PLATE,
11	427588A1	1	HOUSING, Front
12	86637969	16	BOLT, Hex, M12 x 1.25 x 25, 8.8, Full Thd,
13	428121A1	1	SHAFT ASSY., Second, See Figure : 06-33
14	427538A1	1	HOUSING, Rear
15	428130A1	1	FORK, SHIFTER, 1-R Gears, See Figure : 06-30
15	428131A1	1	FORK, SHIFTER, 2-3 Gears, See Figure : 06-30
15	428133A1	1	FORK, SHIFTER, C-D Range, See Figure : 06-30
15	428132A1	1	FORK, SHIFTER, A-B Range, See Figure : 06-30


1
2
3
4
5
6
7
8
9
10
11
12
13

ссылка	Номер детали	Кол-во	Описание
1	428130A1	1	FORK, SHIFTER, 1-R Gears
2	428155A1	4	BALL,
3	428139A1	4	SPRING,
4	428154A1	4	PLUG,
5	428135A1	1	ROD, Speed Shaft
6	428134A1	1	PLATE, Interlock
7	86639258	2	PIN, LOCK, M8 x 60, Slotted,
8	428150A1	2	BALL,
9	428137A1	2	O-RING,
10	428131A1	1	FORK, SHIFTER, 2-3 Gears
11	428133A1	1	FORK, SHIFTER, C-D Range
12	428132A1	1	FORK, SHIFTER, A-B Range
13	428136A1	1	ROD, Range Shift


1
2
3
4
3
8
9
8
7
6
17
18
16
15
9
5
14
13
9
12
11
10
19
26
25
20
21
21
22
28
27
23
24
29
16
31
30

TJ430 TRACTOR (1/06-) - Power Train

06-31 MANUAL SHIFT TRANSMISSION - INPUT SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
	428120A1	1	SHAFT ASSY., Input, 7, Inc. 1-31, See Figure: 06-32
1	427643A1	AR	RING, SNAP, 2,4 mm
1	427644A1	AR	RING, 2,5 mm
1	427645A1	AR	RING, 2,6 mm
1	427646A1	AR	RING, 2,7 mm
2	427613A1	1	BEARING, ROLLER, TAPERED,
3	427620A1	2	WASHER, THRUST,
4	427617A1	1	BEARING, THRUST,
5	427619A1	1	COLLAR,
6	427610A1	1	GEAR, Input
7	427608A1	1	SNAP RING,
8	427612A1	2	BEARING, NEEDLE,
9	S5040S00F	3	RING, Retaining
10	S5230S00F	1	WASHER, THRUST,
11	A75158	1	BEARING, THRUST,
12	427618A1	2	WASHER, THRUST,
13	S14701960	1	BALL,
14	428101A1	1	SHAFT, High / Low Input
15	427621A1	AR	WASHER, 5,10 mm
15	427622A1	AR	WASHER, 5,15 mm
15	427623A1	AR	WASHER, 5,20 mm
15	427624A1	AR	WASHER, 5,25 mm
15	427625A1	AR	WASHER, 5,30 mm
15	427626A1	AR	WASHER, 5,35 mm
15	427627A1	AR	WASHER, 5,40 mm
15	427628A1	AR	WASHER, 5,45 mm
15	427629A1	AR	WASHER, 5,50 mm
15	427630A1	AR	WASHER, 5,55 mm
15	427631A1	AR	WASHER, 5,60 mm
15	427632A1	AR	WASHER, 5,65 mm
15	427633A1	AR	WASHER, 5,70 mm
15	427634A1	AR	WASHER, 5,75 mm
15	427635A1	AR	WASHER, 5,80 mm
15	427636A1	AR	WASHER, 5,85 mm
15	427637A1	AR	WASHER, 5,90 mm
15	427638A1	AR	WASHER, 5,95 mm
15	427639A1	AR	WASHER, 6,0 mm
15	427640A1	AR	WASHER, 6,05 mm
15	427641A1	AR	WASHER, 6,10 mm
15	427642A1	AR	WASHER, 6,15 mm
16	428112A1	2	BEARING ASSY,
17	412160	10	BOLT, Hex, M10 x 1.25 x 30, Cl8.8, Full Thd,
18	427595A1	1	COVER,
19	427602A1	AR	DISC, CLUTCH, Steel, If Used
19	427603A1	AR	DISC, CLUTCH, Steel, If Used

06-31 MANUAL SHIFT TRANSMISSION - INPUT SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
20	427601A1	8	DISC, CLUTCH, Faced
21	427606A1	32	SPRING, Clutch Separator
22	S4410S00F	2	RING,
23	427600A1	1	SEALRING,
24	427599A1	1	SEALRING,
25	427605A1	12	GUIDE,
26	427607A1	1	DRUM, Clutch
27	427596A1	12	SPRING,
28	427604A1	1	PISTON, Clutch
29	427597A1	4	GUIDE,
30	428119A1	1	GEAR, High
31	86637963	12	BOLT, Hex, M10 x 1.25 x 40, 8.8, Full Thd,

06-32 MANUAL SHIFT TRANSMISSION - INPUT SHAFT ASSY



ссылка	Номер детали	Кол-во	Описание
	428120A1	1	SHAFT ASSY., Input, 7, Inc. 1 -19, See Figure: 06-31
1	428108A1	1	SNAP RING,
2	428104A1	1	PLATE, Clutch End
3	428110A1	2	DISC, CLUTCH, Faced Clutch
4	S4070S00F	AR	DISC, CLUTCH, If Used
4	S4110S00F	AR	DISC, CLUTCH, If Used
5	427534A1	3	DISC, CLUTCH, Faced Clutch
6	428109A1	1	PLATE, Spring Return
7	S2640S00F	12	SPRING,
8	428111A1	1	PISTON, Clutch
9	S2630S00F	1	RING,
10	428106A1	1	DRUM, High / Low Clutch
11	428163A1	1	SNAP RING, Retaining
12	428107A1	1	O-RING,
13	428105A1	1	GEAR,
14	428103A1	2	BEARING, ROLLER, TAPERED,
15	427674A1	AR	SHIM, 2,5 mm
15	427675A1	AR	SHIM, 2,6 mm
15	427676A1	AR	SHIM, 2,7 mm
15	427678A1	AR	SHIM, 2,8 mm
15	427679A1	AR	SHIM, 2,9 mm
15	427680A1	AR	SHIM, 3,0 mm
16	428102A1	5	RING, SNAP,
17	412160	10	BOLT, Hex, M10 x 1.25 x 30, Cl8.8, Full Thd,
18	S5040S00F	1	RING,
19	S4410S00F	1	RING,

06-33 MANUAL SHIFT TRANSMISSION - SECOND SHAFT ASSY



ссылка	Номер детали	Кол-во	Описание
	428121A1	1	SHAFT ASSY., Second, Inc. 1-27
1	428183A1	1	BEARING,
2	428163A1	1	SNAP RING, Retaining
3	428115A1	1	WASHER, Retaining
4	428116A1	1	GEAR, 42T, High Clutch
5	428125A1	2	BEARING, NEEDLE,
6	428124A1	2	SNAP RING,
7	428117A1	1	WASHER,
8	S5040S00F	1	RING, Retaining
9	428108A1	1	SNAP RING,
10	428104A1	1	PLATE, Clutch End
11	428110A1	2	DISC, CLUTCH, Faced Clutch
12	S4070S00F	AR	DISC, CLUTCH, If Used
12	S4110S00F	AR	DISC, CLUTCH, If Used
13	427534A1	3	DISC, CLUTCH, Faced Clutch
14	428109A1	1	PLATE, Spring Return
15	S2640S00F	12	SPRING,
16	428111A1	1	PISTON, Clutch
17	S2630S00F	1	RING,
18	S4410S00F	1	RING,
19	428153A1	1	BALL,
20	428118A1	1	NEEDLE,
21	428113A1	1	SHAFT ASSY.,
22	428107A1	1	O-RING,
23	428106A1	1	DRUM,
24	428122A1	1	GEAR, Input
25	428103A1	1	BEARING, ROLLER, TAPERED,
26	S3070S00F	3	RING,
27	428178A1	10	BOLT,

06-34 MANUAL SHIFT TRANSMISSION - THIRD SHAFT ASSY



ссылка	Номер детали	Кол-во	Описание
	427647A1	1	SHAFT ASSY., Third, Inc. 1-20
1	427668A1	AR	SNAP RING, 2,5 mm
1	427669A1	AR	SNAP RING, 2,6 mm
1	427670A1	AR	SNAP RING, 2,7 mm
1	427671A1	AR	SNAP RING, 2,8 mm
1	427672A1	AR	SNAP RING, 2,9 mm
1	427673A1	AR	SNAP RING, 3,0 mm
2	428074A1	1	BEARING, ROLLER, TAPERED,
3	427656A1	1	GEAR,
4	S5040S00F	2	RING, Retaining
5	372071A1	1	GEAR, First
6	427663A1	4	DISC, Synchro Speed
7	427654A1	4	SNAP RING,
8	SM832508	16	PIN,
9	427653A1	1	SNAP RING,
10	S5070S00F	1	BEARING, NEEDLE,
11	427667A1	2	SLEEVE ASSY, Synchro Speed
12	S5090S00F	4	SNAP RING, Retaining
13	372073A1	2	GEAR-SET, Clutch
14	427657A1	1	GEAR, Reverse
15	427660A1	1	BEARING, NEEDLE,
16	427648A1	1	SHAFT, Speed
17	372072A1	1	GEAR, Second
18	427658A1	1	GEAR, Third
19	427651A1	1	SPACER,
20	427649A1	1	BEARING, ROLLER, TAPERED,

06-35 MANUAL SHIFT TRANSMISSION - FOURTH SHAFT ASSY



06-35 MANUAL SHIFT TRANSMISSION - FOURTH SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
	427681A1	1	SHAFT ASSY., Fourth, Inc. 1-11
1	427674A1	AR	SHIM, Retaining, 2,5 mm
1	427675A1	AR	SHIM, Retaining, 2,6 mm
1	427676A1	AR	SHIM, Retaining, 2,7 mm
1	427678A1	AR	SHIM, Retaining, 2,8 mm
1	427679A1	AR	SHIM, Retaining, 2,9 mm
1	427680A1	AR	SHIM, Retaining, 3,0 mm
2	427649A1	2	BEARING, ROLLER, TAPERED,
3	427684A1	1	GEAR, A Range
4	427685A1	1	GEAR, First
5	427682A1	1	SHAFT, Center
6	427686A1	1	GEAR, B Range
7	427687A1	1	GEAR, Second
8	S5090S00F	1	SNAP RING, Retaining
9	S5040S00F	1	RING, Retaining
10	427688A1	1	GEAR, Third
11	427689A1	1	GEAR, D Range


1
2
3
2
4
5
6
8
7
10
11
10
9
7
6
8
14
13
12
6
8
7
9
10
11
10
6
7
8
18
17
16
15

ссылка	Номер детали	Кол-во	Описание
	427690A1	1	SHAFT ASSY., Fifth, Inc. 1-18
1	428074A1	1	BEARING, ROLLER, TAPERED,
2	S5230S00F	2	WASHER, THRUST,
3	A75158	1	BEARING, THRUST,
4	S5070S00F	2	BEARING, NEEDLE,
5	428076A1	1	GEAR, A Range
6	428081A1	4	DISC, Synchro Range
7	427654A1	8	SNAP RING,
8	SM832508	16	PIN,
9	428082A1	2	SLEEVE ASSY, Synchro Range
10	S5090S00F	4	SNAP RING, Retaining
11	428075A1	2	HUB, Clutch Range
12	428077A1	1	GEAR, B Range
13	427691A1	1	SHAFT, Output
14	428079A1	1	GEAR, C Range
15	428080A1	1	GEAR, D Range
16	427649A1	1	BEARING, ROLLER, TAPERED,
17	427683A1	1	RING, Carrier Ring
18	S4150S00F	2	RING, Seal

06-37 MANUAL SHIFT TRANSMISSION - CONTROL VALVE ASSY



06-37 MANUAL SHIFT TRANSMISSION - CONTROL VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
	428083A1	1	VALVE, Inc. 1-24
1	S6170S00F	1	PLUG, Inc. 2
2	S6180S00F	1	O-RING,
3	S6260S00F	8	SCREW,
4	S6010S00F	1	SPOOL,
5	S6220S00F	11	PLUG,
6	S6020S00F	1	COVER,
7	S6030S00F	1	GASKET, Valve Cover
8	S6040S00F	1	SPOOL,
9	S6160S00F	1	PIN,
10	S6240S00F	1	ORIFICE,
11	S6230S00F	2	ORIFICE,
12	428084A1	1	BODY, VALVE,
13	S6060S00F	1	SEAT, SPRING,
14	S6210S00F	1	SPRING,
15	S6080S00F	1	LINK, CONNECTING,
16	S6150S00F	1	SPRING,
17	S6140S00F	AR	SHIM,
18	S6200S00F	1	SPACER,
19	S6130S00F	1	PIN, ROLL,
20	S6100S00F	1	HOUSING, Control
21	427537A1	1	GASKET,
22	428085A1	1	COVER, Control Stem
23	S6120S00F	1	O-RING,
24	S6110S00F	1	SEAL,

06-38 MANUAL SHIFT TRANSMISSION - LOCKOUT VALVE ASSY



06-38 MANUAL SHIFT TRANSMISSION - LOCKOUT VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
	428091A1	1	VALVE, Lockout, Inc. 1-9
1	428090A1	1	PLUG,
2	428086A1	2	O-RING,
3	428094A1	1	PLUG,
4	428089A1	1	SPOOL,
5	428088A1	1	SPRING,
6	428092A1	1	BODY, VALVE,
7	428087A1	1	PLUG,
8	428093A1	5	O-RING,
9	428095A1	1	ORIFICE,

06-39 MANUAL SHIFT TRANSMISSION - REGULATOR VALVE ASSY



06-39 MANUAL SHIFT TRANSMISSION - REGULATOR VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
	428096A1	1	VALVE, Regulator, Inc. 1-14
1	428097A1	1	BODY,
2	220064A1	2	PLUG, M14 x 1.5, ORB, M 14, Inc. 3
3	86639042	2	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
4	S7090S00F	1	GASKET,
5	S7110S00F	1	COVER,
6	120104	5	BOLT, Hex, M8 x 20, 8.8,
7	S7030S01F	1	VALVE, Pressure Regulator
8	S7010S00F	AR	SHIM,
9	S7120S00F	1	SPRING,
10	S7050S00F	2	SPRING,
11	S7020S00F	1	STEM, Pressure Regulator
12	S7080S00F	AR	SHIM,
13	S7060S00F	2	VALVE, Lube
14	S7070S00F	1	SPRING,

06-40 POWER SHIFT TRANSMISSION - VALVE AND PUMP MOUNTING



ссылка	Номер детали	Кол-во	Описание
1	87351408	1	GASKET,
2	87350388	1	VALVE, Regulator, See Figure: 06-52
3	86637968	5	BOLT, Hex, M10 x 1.25 x 120, 8.8,
4	120108	3	BOLT, Hex, M8 x 80, 8.8, Full Thd,
5	87362227	10	BOLT, M10 x 90, CL8.8
6	87350421	1	VALVE, Control, Range Selector, See Figure: 06-53
7	87335429	1	COVER, Solenoid

06-41 POWER SHIFT TRANSMISSION - COVERS AND YOKES



06-41 POWER SHIFT TRANSMISSION - COVERS AND YOKES

ссылка	Номер детали	Кол-во	Описание
1	87350466	1	TRANSMISSION HOUSING, Rear
2	87350479	1	HOUSING, Front
3	427539A1	1	PLATE, RETAINING,
4	427560A1	AR	SHIM, 0,10 mm (0,004 in)
4	427561A1	AR	SHIM, 0,30 mm (0,012 in)
4	427562A1	AR	SHIM, 0,50 mm (0,020 in)
5	428162A1	1	O-RING,
6	373136A1	1	COUPLING FLANGE, 8C, Input, with 450 Series Axle
6	362563A1	1	COUPLING FLANGE, 8.5C, Input, with 500 Series Axle
7	428159A1	1	SEAL, OIL,
8	362564A1	1	RETAINER, Input
9	362565A1	1	GASKET, Mounting
10	359242A1	AR	SHIM, 0,1 mm (0,004 in)
10	359243A1	AR	SHIM, 0,15 mm (0,006 in)
10	359244A1	AR	SHIM, 0,3 mm (0,012 in)
10	359251A1	AR	SHIM, 0,5 mm (0,020 in)
11	362566A1	1	ADAPTER,
12	800-2128	1	RING, SNAP, M28, Int,
13	362567A1	1	COUPLING,
14	428681A1	1	SNAP RING,
15	87542516	1	RETAINER, Second Shaft
16	362569A1	1	GASKET, Mounting, Second Shaft
17	87351326	1	PLATE,
18	87351331	1	GASKET, Mounting
19	87351392	1	PLATE, Ditch
20	87351393	1	GASKET, Mounting, Third Shaft
21	362574A1	1	O-RING,
23	87362252	1	RETAINER, Bearing, Third Shaft
24	359252A1	AR	SHIM, 0,1 mm (0,004 in)
24	359253A1	AR	SHIM, 0,15 mm (0,006 in)
24	362576A1	AR	SHIM, 0,3 mm (0,012 in)
24	362577A1	AR	SHIM, 0,5 mm (0,020 in)
25	100-2156	1	RING, SNAP, 0.562", Int, #56,
26	87351399	1	VALVE, MANIFOLD, Clutch
27	362580A1	1	GASKET, Mounting
28	427564A1	AR	SHIM, 0,10 mm (0,004 in)
28	427565A1	AR	SHIM, 0,15 mm (0,006 in)
28	427566A1	AR	SHIM, 0,30 mm (0,012 in)
28	427567A1	AR	SHIM, 0,50 mm (0,020 in)
28	427568A1	AR	SHIM, 0,70 mm (0,027 in)
29	86637974	4	BOLT, Hex, M12 x 1.25 x 25, 8.8, Full Thd,
30	87351325	1	SEAL, OIL, Oil
31	614-8020	2	BOLT, Hex, M8 x 20, 8.8,
32	87351402	1	PLATE, Valve Retainer
33	427515A1	2	PLATE, RETAINING,

ссылка	Номер детали	Кол-во	Описание
34	427517A1	AR	SHIM, 0,10 mm (0,004 in)
34	427519A1	AR	SHIM, 0,30 mm (0,012 in)
35	428165A1	2	O-RING,
36	373137A1	1	COUPLING FLANGE, 8C, Output, with 450 Series Axle
36	362598A1	1	COUPLING FLANGE, 8,5C, Output, with 500 Series Axle
37	362601A1	1	RING,
38	427514A1	2	SEAL, OIL,
39	362602A1	1	RETAINER, Output
40	362603A1	1	GASKET, Mounting
41	87351323	1	YOKE, 8C, Output, with 450 Series Axle
41	87351322	1	YOKE, 8,5C, Output, with 500 Series Axle
42	427558A1	1	COVER, Power Takeoff
43	303493A1	2	PLUG, Hex Soc, M42 x 2, ORB, M42 orb x 2, Inc. 44
44	86639047	3	O-RING, Cl 6, 38.6MM ID x 2.9 Thk,
45	375456A1	1	PLUG, DRAIN, M42 orb x 2, Inc. 46
46	87350436	1	VALVE, CHECK, 4,45 mm
47	220064A1	14	PLUG, M14 x 1.5, ORB, M14 - 1,5, Inc. 50
48	637-63113	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
49	514-915	2	BOLT, Hex, M14 x 1.5 x 35, 8.8, Full Thd,
50	86637966	24	BOLT, Hex, M10 x 1.25 x 35, 8.8, Full Thd,
51	140028	6	WASHER, LOCK, M10,
52	412159	2	BOLT, Hex, M10 x 1.25 x 25, 8.8, Full Thd,
53	86642434	4	BOLT, M10 x 60
54	120106	2	BOLT, Hex, M8 x 40, 8.8, Full Thd,
55	86642438	6	BOLT, Hex, M12 x 1.25 x 35, 10.9, Full Thd,
	178889A1		FITTING, Diagnostic, Inc. 56, 57
56	H434163	1	CAP,
57	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 62
58	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
59	427559A1	2	SCREW,
60	87357396	1	VALVE, SOLENOID, Pulse with Modulation, Inc. 61 - 63
61	87014033	1	O-RING, -019, Cl 7, .801" ID x .070" Thk,
62	238-7016	1	O-RING, -016, Cl 7, .614" ID x .070" Thk,
63	238-7015	1	O-RING, -015, Cl 7, .551" ID x .070" Thk,

06-42 POWER SHIFT TRANSMISSION - REAR HOUSING



06-42 POWER SHIFT TRANSMISSION - REAR HOUSING

ссылка	Номер детали	Кол-во	Описание
1	428156A1	1	PLUG,
2	427524A1	1	BREATHER,
3	370632A1	1	TUBE, Breather
4	838-51040	1	PIN, LOCK, M10 x 40, Slotted, Roll
5	87350473	1	GUTTER, Oil
6	86637974	2	BOLT, Hex, M12 x 1.25 x 25, 8.8, Full Thd,
7	370634A1	1	TROUGH, Second
8	86977726	9	BOLT, Hex, M6 x 12, 8.8,
9	370635A2	1	BAFFLE, Air
10	87350466	1	TRANSMISSION HOUSING, Rear
11	222008	2	NUT, LOCK, M10
12	370637A1	2	BRACKET,
13	87350496	1	BAFFLE, Transmission Oil
14	86624176	2	WASHER, M10 x 20 x 2,
15	86637962	2	BOLT, Hex, M10 x 1.25 x 20, 8.8, Full Thd,
16	87350470	1	RETAINER, Output, Rear
17	514-712	6	BOLT, Hex, M10 x 1.25 x 25, 8.8, Full Thd,
18	87350468	1	COVER, Rear
19	514-730	6	BOLT, Hex, M10 x 1.25 x 35, 8.8, Full Thd,

06-43 POWER SHIFT TRANSMISSION - HOUSING AND CLUTCHES



06-43 POWER SHIFT TRANSMISSION - HOUSING AND CLUTCHES

сылка	Номер детали	Кол-во	Описание
1	87350479	1	HOUSING, Front
2	87350228	1	SHAFT, CLUTCH INPUT, Input, 8C, (8" Yoke) See Figure: 06-44 & 06-45, BSN Z6F202012
2	87552053	1	SHAFT, CLUTCH INPUT, Input, 8C, (8" Yoke) See Figure: 06-44 & 06-45, ASN Z6F202012
2	87350227	1	SHAFT, CLUTCH INPUT, Input, 8,5C, (8.5" Yoke) See Figure: 06-44 & 06-45, BSN Z6F202012
2	87552050	1	SHAFT, CLUTCH INPUT, Input, 8,5C, (8.5" Yoke) See Figure(s): 06-44 & 06-45, ASN Z6F202012
3	87350268	1	SHAFT, CLUTCH INPUT, Second, 8C, (8" Yoke) See Figure: 06-46
3	87350264	1	SHAFT, CLUTCH INPUT, Second, 8,5C, (8.5" Yoke) See Figure: 06-46
4	REF	1	INSTRUCTION, Shaft, Third, See Figure: 06-47
5	87350312	1	SHAFT, CLUTCH INPUT, Fourth, 8C, (8" Yoke) See Figure(s): 06-48 & 06-49
5	87350309	1	SHAFT, CLUTCH INPUT, Fourth, 8,5C, (8.5" Yoke) See Figure(s): 06-48 & 06-49
6	87350349	1	SHAFT, CLUTCH INPUT, Fifth, 8C, (8" Yoke) See Figure(s): 06-50 & 06-51
6	87350342	1	SHAFT, CLUTCH INPUT, Fifth, 8,5C, (8.5" Yoke) See Figure(s): 06-50 & 06-51
7	427530A1	2	DOWEL,
8	87350466	1	TRANSMISSION HOUSING, Rear
9	86642455	4	PIN, Roll
10	370025	4	RING, SNAP, M12, Int, Retaining
11	86625261	4	WASHER, M5 x 10 x 1,
12	370542A1	4	SHIM,
13	370543A1	4	SPRING,
14	370544A1	4	SPOOL,
15	370545A1	4	CAP,
16	86642435	25	BOLT, Hex, M12 x 1.25 x 45, 8.8, Full Thd,

06-44 POWER SHIFT TRANSMISSION - INPUT SHAFT ASSY



06-44 POWER SHIFT TRANSMISSION - INPUT SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
1	87350228	1	SHAFT, CLUTCH INPUT, 8C, (8" Yoke) Inc. 2 - 28, Also See Figure: 06-45, BSN Z6F202012
1	87552053	1	SHAFT, CLUTCH INPUT, 8C, (8" Yoke) Inc. 2 - 28, Also, See Figure: 06-45, ASN Z6F202012
1	87350227	1	SHAFT, CLUTCH INPUT, 8,5C, (8.5" Yoke) Inc. 2 - 28, Also See Figure: 06-45, BSN Z6F202012
1	87552050	1	SHAFT, CLUTCH INPUT, 8,5C, (8.5" Yoke) Inc. 2 - 28, Also See Figure: 06-45, ASN Z6F202012
2	352378A1	AR	SNAP RING, 2,5 mm
2	352394A1	AR	SNAP RING, 2,6 mm
2	352397A1	AR	SNAP RING, 2,7 mm
2	352400A1	AR	SNAP RING, 2,8 mm
2	352815A1	AR	SNAP RING, 2,9 mm
2	352816A1	AR	SNAP RING, 3,0 mm
3	428183A1	1	BEARING, Cone
4	E135785	4	BEARING, Roller
5	352818A1	AR	SHIM, 0,15 mm
5	352819A1	AR	SHIM, 0,18 mm
5	352820A1	AR	SHIM, 0,20 mm
5	352821A1	AR	SHIM, 0,25 mm
5	352822A1	AR	SHIM, 0,30 mm
5	352823A1	AR	SHIM, 0,50 mm
6	352825A1	1	SPACER,
7	87350229	1	GEAR, 1R
8	87350230	2	PLATE, Springs
9	362616A1	32	SPRING, Return
10	352829A1	2	SNAP RING,
11	87350231	2	PLATE, Clutch End, 8C
11	87431390	2	PLATE, Clutch End, 8,5C
12	352831A1	4	DISC, CLUTCH, Face, 7"
13	S2080S00F	AR	DISC, CLUTCH, 2,4 mm, If Used
13	S2090S00F	AR	DISC, CLUTCH, 2,1 mm, If Used.
14	352832A1	11-13	DISC, CLUTCH, Face, 7"
15	87350236	2	PISTON, 7"
16	87431391	2	RING, Seal
17	S2610S00F	2	RING, Piston
18	87350255	1	SHAFT, Drum, Input, 8C
18	87350251	1	SHAFT, Drum, Input, 8,5C
19	428163A1	1	SNAP RING, Retaining
20	353059A1	1	WASHER, THRUST,
21	353060A1	2	BEARING, THRUST, Needle
22	87350258	1	GEAR, 1M
23	87350260	1	BEARING, NEEDLE, Cone
24	358866A1	1	SNAP RING,
25	358867A1	1	SPACER,
26	358908A1	1	WASHER, THRUST, Thrust
27	S14701960	1	BALL,
28	87431394	2	RING, Seal

06-45 POWER SHIFT TRANSMISSION - INPUT SHAFT ASSY



06-45 POWER SHIFT TRANSMISSION - INPUT SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
1	87350228	1	SHAFT, CLUTCH INPUT, 8C, (8" Yoke) Inc. 2 - 25, Also See Figure: 06-44, BSN Z6F202012
1	87552053	1	SHAFT, CLUTCH INPUT, 8C, (8" Yoke) Inc. 2 - 25, Also See Figure: 06-44, ASN Z6F202012
1	87350227	1	SHAFT, CLUTCH INPUT, 8,5C, (8.5" Yoke) Inc. 2 - 25, Also See Figure: 06-44, BSN Z6F202012
1	87552050	1	SHAFT, CLUTCH INPUT, 8,5C, (8.5" Yoke) Inc. 2 - 25, Also See Figure: 06-44, ASN Z6F202012
2	358918A1	1	DRUM, 1F, Clutch, BSN Z6F202012
2	87552054	1	DRUM, 1F, Clutch, ASN Z6F202012
3	86642451	1	CIRCLIP, Snap, BSN Z6F202012
4	S3220S00F	1	SHIM, 0,70 mm (0,028 in), BSN Z6F202012
5	S3210S00F	1	SPRING, , BSN Z6F202012
6	S3200S00F	1	VALVE, DRAIN, , BSN Z6F202012
7	87431393	1	RING, Seal, BSN Z6F202012
7	87431391	1	RING, Seal, ASN Z6F202012
8	358970A1	1	PISTON, , BSN Z6F202012
8	87552055	1	PISTON, , ASN Z6F202012
9	S5510S00F	1	RING,
10	358971A1	12	SPRING, , BSN Z6F202012
10	358971A1	20	SPRING, , ASN Z6F202012
11	358972A1	1	PLATE, Retaining, BSN Z6F202012
11	87552056	1	SPRING, Plate, ASN Z6F202012
12	370555A1	2	DISC, CLUTCH, Face
13	S4110S00F	5	DISC, CLUTCH, 2,1 mm
13	S4070S00F	5	DISC, CLUTCH, 2,4 mm
14	370556A1	4	DISC, CLUTCH, Face, 8
15	442803A1	1	PLATE, End
16	428108A1	1	SNAP RING,
17	359203A1	1	SPACER,
18	359204A1	1	GEAR, 1F
19	87350261	1	GEAR, DRIVING,
20	533725R91	1	BEARING, Roller
21	359207A1	1	CARRIER, Seal
22	S4150S00F	5	RING, Seal
23	E135785	2	BEARING, Roller
24	352818A1	AR	SHIM, 0,15 mm
24	352819A1	AR	SHIM, 0,18 mm
24	352820A1	AR	SHIM, 0,20 mm
24	352821A1	AR	SHIM, 0,25 mm
24	352822A1	AR	SHIM, 0,30 mm
24	352823A1	AR	SHIM, 0,50 mm

06-46 POWER SHIFT TRANSMISSION - SECOND SHAFT ASSY



06-46 POWER SHIFT TRANSMISSION - SECOND SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
1	87350268	1	SHAFT, CLUTCH INPUT, Second, 8C, Inc. 2 - 26
1	87350264	1	SHAFT, CLUTCH INPUT, Second, 8,5C, Inc. 2 - 26
2	428673A1	1	COUPLING, SPLINED,
3	428674A1	1	DOWEL, Dowel
4	352378A1	AR	SNAP RING, 2,5 mm
4	352394A1	AR	SNAP RING, 2,6 mm
4	352397A1	AR	SNAP RING, 2,7 mm
4	352400A1	AR	SNAP RING, 2,8 mm
4	352815A1	AR	SNAP RING, 2,9 mm
4	352816A1	AR	SNAP RING, 3,0 mm
5	428183A1	1	BEARING,
6	E135785	4	BEARING, Roller
7	352818A1	AR	SHIM, 0,15 mm
7	352819A1	AR	SHIM, 0,18 mm
7	352820A1	AR	SHIM, 0,20 mm
7	352821A1	AR	SHIM, 0,25 mm
7	352822A1	AR	SHIM, 0,30 mm
7	352823A1	AR	SHIM, 0,50 mm
8	87350273	1	SPACER, Bearing
9	87350277	1	GEAR, 2R
10	87350230	2	PLATE, Spring
11	362616A1	32	SPRING,
12	352829A1	2	SNAP RING,
13	87350231	2	PLATE, Clutch End, 8C
13	87431390	2	PLATE, Clutch End, 8,5C
14	352831A1	4	DISC, CLUTCH, Face, 7"
15	S2080S00F	AR	DISC, CLUTCH, 2,4 mm, If Used
15	S2090S00F	AR	DISC, CLUTCH, 2,1 mm, If Used.
16	352832A1	11-13	DISC, CLUTCH, Face, 7"
17	87350236	2	PISTON, 7"
18	87431391	2	RING, Seal
19	S2610S00F	2	RING, Piston
20	87350301	1	SHAFT, Drum, 8C
20	87350293	1	SHAFT, Drum, 8,5C
21	87350305	1	SPACER, Bearing
22	87350306	1	GEAR, 2M
23	87350307	1	GEAR, DRIVEN, Driven
24	359206A1	1	BEARING, ROLLER, TAPERED,
25	S3070S00F	4	RING, Seal
26	87431394	2	RING, Seal

06-47 POWER SHIFT TRANSMISSION - THIRD SHAFT ASSY



06-47 POWER SHIFT TRANSMISSION - THIRD SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
1	87431397	2	BEARING,
2	87350476	1	SHAFT, GEAR,

06-48 POWER SHIFT TRANSMISSION - FOURTH SHAFT ASSY



06-48 POWER SHIFT TRANSMISSION - FOURTH SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
1	87350312	1	SHAFT, CLUTCH INPUT, Fourth, 8C, Inc. 2 - 23, Also See Figure: 06-49
1	87350309	1	SHAFT, CLUTCH INPUT, Fourth, 8,5C, Inc. 2 - 23, Also See Figure: 06-49
2	427674A1	AR	SHIM, Retaining, 2,50 mm
2	427675A1	AR	SHIM, Retaining, 2,60 mm
2	427676A1	AR	SHIM, Retaining, 2,70 mm
2	427678A1	AR	SHIM, Retaining, 2,80 mm
2	427679A1	AR	SHIM, Retaining, 2,90 mm
2	427680A1	AR	SHIM, Retaining, 3,00 mm
3	428675A1	2	BEARING, Roller
4	87350315	1	GEAR, DRIVING, Drive
5	S5040S00F	4	RING, Retaining
6	362611A1	3	SPACER,
7	353060A1	4	BEARING, THRUST, Needle
8	87350316	1	GEAR, DRIVEN, Driven
9	87350319	1	BEARING, NEEDLE, Needle
10	87350321	1	WASHER, THRUST,
11	362615A1	1	PLATE, Spring Retainer
12	362616A1	16	SPRING,
13	359235A1	2	SNAP RING,
14	87350325	2	PLATE, END, Clutch End, 8C
14	362617A1	2	PLATE, Clutch End, 8,5C
15	362618A1	19	DISC, CLUTCH, Face
16	362628A1	AR	DISC, CLUTCH, 2,4 mm, Steel, If Used
16	362629A1	AR	DISC, CLUTCH, 2,6 mm, Steel, If Used
17	364822A1	1	PISTON, 9, Clutch
18	87431400	2	RING, Seal
19	S4410S00F	2	RING, Seal
20	87350328	1	SHAFT, Drum, 8C
20	87350326	1	SHAFT, Drum, 8,5C
21	364825A1	1	PISTON, 9, Clutch
22	S14701960	2	BALL,
23	392073A1	2	SEALRING,

06-49 POWER SHIFT TRANSMISSION - FOURTH SHAFT ASSY



06-49 POWER SHIFT TRANSMISSION - FOURTH SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
1	87350312	1	SHAFT, CLUTCH INPUT, Fourth, Inc. 1 - 12, Also See Figure: 06-48
1	87350309	1	SHAFT, CLUTCH INPUT, Fourth, Inc. 2 - 13, Also See Figure: 06-48
2	427674A1	AR	SHIM, Retaining, 2,50 mm
2	427675A1	AR	SHIM, Retaining, 2,60 mm
2	427676A1	AR	SHIM, Retaining, 2,70 mm
2	427678A1	AR	SHIM, Retaining, 2,80 mm
2	427679A1	AR	SHIM, Retaining, 2,90 mm
2	427680A1	AR	SHIM, Retaining, 3,00 mm
3	428675A1	2	BEARING, Roller
4	S5040S00F	4	RING, Retaining
5	362611A1	3	SPACER,
6	353060A1	4	BEARING, THRUST, Needle
7	364826A1	6	PLATE, Spring
8	87350331	1	WASHER, THRUST,
9	S5070S00F	2	BEARING, NEEDLE,
10	87350334	1	GEAR, DRIVEN, Drive
11	87350339	1	GEAR, DRIVING, Drive
12	87431401	4	RING, Seal
13	392073A1	1	SEALRING,

06-50 POWER SHIFT TRANSMISSION - FIFTH SHAFT ASSY



06-50 POWER SHIFT TRANSMISSION - FIFTH SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
1	87350349	1	SHAFT, CLUTCH INPUT, Fifth, 8C, Inc. 2 - 22, Also See Figure: 06-51
1	87350342	1	SHAFT, CLUTCH INPUT, Fifth, 8,5C, 2 - 22, Also See Figure: 06-51
2	428675A1	1	BEARING, Roller
3	364831A1	1	WASHER, THRUST,
4	353060A1	2	BEARING, THRUST, Needle
5	358908A1	1	WASHER, THRUST,
6	87350355	1	GEAR, DRIVEN, Driven
7	S5070S00F	1	BEARING, NEEDLE,
8	87350321	1	WASHER, THRUST,
9	S5040S00F	4	RING, Retaining
10	362615A1	1	PLATE, Spring Retaining
11	364833A1	16	SPRING,
12	428108A1	2	SNAP RING,
13	87350360	2	PLATE, 8C
13	370554A1	2	DISC, CLUTCH, 8,5C
14	370555A1	4	DISC, CLUTCH, Face
15	S4070S00F	AR	DISC, CLUTCH, 2,4 mm, If Used
15	S4110S00F	AR	DISC, CLUTCH, 2,1 mm, If Used
16	370556A1	25	DISC, CLUTCH, 8 in, Face
17	370558A1	1	PISTON, 8 in
18	87431400	2	RING, Seal
19	S4410S00F	2	RING, Piston
20	87350368	1	SHAFT, Drum, 8C
20	87350363	1	SHAFT, Drum, 8,5C
21	370562A1	1	PISTON, 8 in
22	S14701960	2	BALL,

06-51 POWER SHIFT TRANSMISSION - FIFTH SHAFT ASSY



06-51 POWER SHIFT TRANSMISSION - FIFTH SHAFT ASSY

ссылка	Номер детали	Кол-во	Описание
1	87350349	1	SHAFT, CLUTCH INPUT, Fifth, 8C, Inc. 2 - 13, Also See Figure: 06-50
1	87350342	1	SHAFT, CLUTCH INPUT, Fifth, 8,5C, Inc. 2 - 13, Also See Figure: 06-50
2	428675A1	1	BEARING, Roller
3	364831A1	1	WASHER, THRUST,
4	353060A1	2	BEARING, THRUST, Needle
5	358908A1	1	WASHER, THRUST,
6	S5070S00F	1	BEARING, NEEDLE,
7	S5040S00F	4	RING, Retaining
8	362611A1	1	SPACER,
9	364826A1	8	PLATE, Spring
10	87350331	1	WASHER, THRUST,
11	87350374	1	GEAR, DRIVEN, Driven
12	370568A1	1	CARRIER, Seal
13	S4150S00F	4	RING, Seal

06-52 POWER SHIFT TRANSMISSION - REGULATOR VALVE ASSY



06-52 POWER SHIFT TRANSMISSION - REGULATOR VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
1	87350388	1	VALVE, Regulator, Inc. 2 - 26
2	NSS	1	NOT SERVICED SEPARATELY, Body, Valve
3	370596A1	1	SPRING,
4	428679A1	1	SNAP RING,
5	370597A1	1	SPOOL,
6	371737A1	1	VALVE, SOLENOID, 3-way, Inc. 7 - 9
7	371739A1	2	COIL,
8	NSS	1	NOT SERVICED SEPARATELY, Pilot Assy.
9	371738A1	1	KIT, O-Ring
10	404450A1	1	SENSOR, Pressure
11	220064A1	1	PLUG, M14 x 1.5, ORB, M14, Inc. 12
12	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
13	87350417	1	COVER, FILTER, Relief
14	87408714	1	FILTER, Conical
15	428676A1	1	O-RING,
16	428678A1	1	PLUG, Inc. O-Ring
17	220066A1	1	PLUG, M18 x 1.5, ORB, M18, Inc. 18
18	86639043	1	O-RING,
19	398443A1	2	SPRING,
20	398445A1	AR	SHIM,
21	398444A1	1	VALVE,
22	87431407	1	PLUG, Inc. 23
23	87431408	1	O-RING,
24	87350419	1	SPOOL, Main Pressure
25	87362229	1	SCREEN, FILTER, Screen
26	87350395	1	VALVE, PILOT, Inc. 27 - 28
27	NSS	1	NOT SERVICED SEPARATELY, Valve, Pilot
28	87350407	1	KIT, O-Ring

06-53 POWER SHIFT TRANSMISSION - RANGE SELECTOR VALVE



ссылка	Номер детали	Кол-во	Описание
	87350421	1	VALVE, Range Selector, Inc. 1 - 17
1	NSS	1	NOT SERVICED SEPARATELY, Body, Valve
2	87350425	7	PLUG, STOP,
3	87350428	2	ORIFICE, Orifice
4	220064A1	10	PLUG, M14 x 1.5, ORB, M14 - 1,5, Inc. 5
5	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
6	238-5214	4	O-RING, -214, 70 Duro, .984" ID x .139" Thk,
7	238-5208	8	O-RING, -208, 70 Duro, .609" ID x .139" Thk,
8	100-2156	8	RING, SNAP, 0.562", Int, #56,
9	87350429	1	VALVE, CHECK, Check, 3,45 mm
10	87350431	2	VALVE, CHECK, Check, 2,51 mm
11	87350432	2	VALVE, CHECK, Check, 2,36 mm
12	87350433	1	VALVE, CHECK, Check, 2,82 mm
13	87350434	1	VALVE, CHECK, Check, 5,54 mm
14	87350435	1	VALVE, CHECK, Check, 4,80 mm
15	87350463	8	PLATE, Valve Retainer
16	864-6012	16	SCREW, Hex Soc Hd, M6 x 12, 8.8,
17	87357396	8	VALVE, SOLENOID, PWM Solenoid, 18 - 21
18	NSS	1	NOT SERVICED SEPARATELY, Body, Valve
19	87014033	1	O-RING, -019, Cl 7, .801" ID x .070" Thk,
20	238-7016	1	O-RING, -016, Cl 7, .614" ID x .070" Thk,
21	238-7015	1	O-RING, -015, Cl 7, .551" ID x .070" Thk,


8
9
10

06-54 AXLE MOUNTING

ссылка	Номер детали	Кол-во	Описание
1	86528190	1	BOLT, Hex, M24 x 200, 10.9, , with 450 Series Axle
1	86639187	1	BOLT, Hex, M24 x 270, 10.9, , with 500 Series Axle
2	86639319	8	WASHER, 26 x 44 x 5 mm
3	9848973	AR	NUT, M24, Cl 10, (4) Rear Axle and (8) Front Axle
4	296050A1	2	PLATE, Mounting, Rear Axle
5	435501A1	2	SPACER,
6	86625266	2	WASHER, M17.5 x 30 x 4, HT,
7	86508623	2	BOLT, Hex, M16 x 30, 10.9, Full Thd,
8	316659A1	2	PLATE, SPACER, Rear Axle, with 450 Series Axle
9	412123	2	WASHER, LOCK, M12, , with 450 Series Axle
10	337563	2	BOLT, Hex, M12 x 40, 10.9, Full Thd, , with 450 Series Axle

06-55 450 SERIES AXLE ASSY - FRONT COVER



TJ430 TRACTOR (1/06-) - Power Train

06-55 450 SERIES AXLE ASSY - FRONT COVER

ссылка	Номер детали	Кол-во	Описание
	302259A2	1	GEAR SET, Set, Pinion Shaft And Gears, Inc. 1, See Figure(s) : 06-58 & 06-59
1	NSS	1	NOT SERVICED SEPARATELY, 12 T / 53 T, Shaft, Pinion
2	248118A1	1	BEARING, CONE,
3	248114A1	1	BEARING SET,
4	86985627	1	COVER,
5	246146A1	1	BAFFLE,
6	191440A1	1	BEARING, CUP,
7	67190R91	1	BEARING, CONE, Cone
8	229515A1	1	SNAP RING, Retaining, M4
9	86534066	2	RING, SNAP, 5.50", Int, #550,
10	259516A1	1	SEAL, Oil
11	853764	1	CLAMP, 5/16", Insul, 5/16" Bolt,
12	228968A2	1	SPACER, Thick
13	191713A1	1	SPACER, Thin
14	191709A1	AR	SHIM, 0,076 mm
14	191711A1	AR	SHIM, 0,101 mm
14	191712A1	AR	SHIM, 0,130 mm
14	220785A1	AR	SHIM, 0,508 mm
15	43232	4	SCREW,
16	284186A1	1	SEAL,
17	412085	8	BOLT, Hex, M12 x 80, 10.9,
18	234433A1	1	TUBE, Lubrication
19	226492A2	AR	SHIM, 0,076 mm
19	226493A2	AR	SHIM, 0,101 mm
19	226494A2	AR	SHIM, 0,130 mm
19	226496A2	AR	SHIM, 0,508 mm
20	221573A1	1	PLUG, Hex Soc, M12 x 1.5, ORB, M12 orb x 13, Includes 21
21	86642448	1	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
22	221579A1	1	PLUG, Hex Soc, M22 x 1.5, ORB, Includes 23
23	637-63193	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
24	395209A1	1	YOKE,
25	86985636	1	ELBOW, Orificed, 5/16 x 3/8, Inc. 76
26	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
28	412087	14	BOLT, Hex, M12 x 45, 10.9, Full Thd,
29	86625138	1	PLUG, Hex Soc, 7/8"-14 ORB, Includes 30
30	167269	1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,
31	221576A1	1	PLUG, Hex Soc, M14 x 1.5, ORB, Includes 32
32	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,

06-56 450 SERIES AXLE ASSY - REAR COVER



TJ430 TRACTOR (1/06-) - Power Train

06-56 450 SERIES AXLE ASSY - REAR COVER

ссылка	Номер детали	Кол-во	Описание
	302260A1	1	GEAR SET, Pinion Shaft and Gears, Inc. 1, See Figure(s): 06-58 & 06-59
1	NSS	1	NOT SERVICED SEPARATELY, Shaft, Pinion, 12 T / 53 T
2	248118A1	1	BEARING, CONE,
3	248114A1	1	BEARING SET,
4	86985626	1	COVER,
5	246146A1	1	BAFFLE,
6	86625138	1	PLUG, Hex Soc, 7/8"-14 ORB, Includes 7
7	167269	1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,
8	191440A1	1	BEARING, CUP, Cup
9	67190R91	1	BEARING, CONE, Cone
10	229515A1	1	SNAP RING, Retaining, M4
11	87432424	1	SEAL, Oil
12	228968A2	1	SPACER, Thick
13	191713A1	1	SPACER, Thin
14	853764	1	CLAMP, 5/16", Insul, 5/16" Bolt,
15	86639333	3	WASHER, 5/16",
16	43232	6	SCREW,
17	191709A1	AR	SHIM, 0,076 mm
17	191711A1	AR	SHIM, 0,101 mm
17	191712A1	AR	SHIM, 0,130 mm
17	220785A1	AR	SHIM, 0,508 mm
18	226492A2	AR	SHIM, 0,076 mm
18	226493A2	AR	SHIM, 0,101 mm
18	226494A2	AR	SHIM, 0,130 mm
18	226496A2	AR	SHIM, 0,508 mm
19	234432A1	1	TUBE, Lubrication
20	412087	14	BOLT, Hex, M12 x 45, 10.9, Full Thd,
21	412085	8	BOLT, Hex, M12 x 80, 10.9,
22	221573A1	1	PLUG, Hex Soc, M12 x 1.5, ORB, M12 orb x 13, Includes 23
23	86642448	1	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
24	86985636	1	ELBOW, Orificed, 5/16 x 3/8, Inc. 25
25	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
26	220069A1	1	PLUG, M33 x 2, ORB, M33 orb x 2, Inc. 27
27	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
28	221576A1	1	PLUG, Hex Soc, M14 x 1.5, ORB, Includes 29
29	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
30	221579A1	1	PLUG, Hex Soc, M22 x 1.5, ORB, Includes 31
31	637-63193	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
32	86639321	22	WASHER, 13,5 x 24 x 3 mm
33	395207A1	1	YOKE, 8C
34	228967A2	1	WASHER, Retaining
35	178545A1	AR	SHIM, 0,076 mm
35	178546A1	AR	SHIM, 0,101 mm
35	178547A1	AR	SHIM, 0,130 mm
35	220779A1	AR	SHIM, 0, 508 mm

ссылка	Номер детали	Кол-во	Описание
36	9780064	1	BOLT, Hex, M24 x 110, 10.9,

06-57 450 SERIES AXLE ASSY - CENTER AND LEFT-HAND CARRIER



06-57 450 SERIES AXLE ASSY - CENTER AND LEFT-HAND CARRIER

ссылка	Номер детали	Кол-во	Описание
	388968A1	1	CARRIER ASSY., Center, Inc. 1 - 4
1	NSS	1	NOT SERVICED SEPARATELY, Carrier
2	NSS	2	NOT SERVICED SEPARATELY, Pin, Dowel
3	NSS	2	NOT SERVICED SEPARATELY, Pin, 16 x 40 mm
4	NSS	2	NOT SERVICED SEPARATELY, Pin, 12 x 25 mm
5	1251958C1	12	WASHER,
6	9824642	12	BOLT, Hex, M12 x 35, 10.9,
7	231637A2	1	CARRIER, Left-Hand
8	253932A1	1	BEARING, CONE,
9	139060C2	1	RING,
10	139059C1	1	SEAL,
11	86639334	3	WASHER, 33/64" x 7/8" x .049",
12	86639264	3	SCREW, Hex Flat Hd, M8 x 12, 4.8,
13	255121A1	AR	SHIM, 0,076 mm
13	255122A1	AR	SHIM, 0,101 mm
13	255123A1	AR	SHIM, 0,130 mm
13	255124A1	AR	SHIM, 0,508 mm
14	229553A3	1	TUBE,
15	272217	5	O-RING, -013, 90 Duro, .426" ID x .070" Thk,
16	245162A1	1	TUBE, Jumper, Lubrication
17	165212	3	O-RING, -015, 90 Duro, .551" ID x .070" Thk,
18	86985628	1	TUBE, Jumper, Lubricaton
19	228893A2	2	TUBE, Service / Park Brake
20	217408	1	O-RING, -226, 70 Duro, 1.984" ID x .139" Thk,
21	86639250	1	DOWEL, M6 x 55, Dowel, 6 x 55 mm

06-58 450 SERIES AXLE ASSY - DIFFERENTIAL, WITHOUT DIFFERENTIAL LOCKS



06-58 450 SERIES AXLE ASSY - DIFFERENTIAL, WITHOUT DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
	389329A1	1	HOUSING ASSY., Inc. 1 & 2
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	1342851C1	1	PLUG, 10mm
3	92907C1	1	SHAFT, Pinion, Long
4	1289349C1	1	SPACER,
5	92906C1	2	SHAFT, SHORT, Pinion
6	1289350C1	2	SPACER,
7	1270697C1	112	NEEDLE, 28 Per Gear
8	1289348C1	4	RING, Retaining
9	92718C2	4	WASHER,
10	92905C1	4	PINION,
11	1997421C1	2	BOLT,
12	137023A1	6	DOWEL, 10 x 60 mm
13	86625266	24	WASHER, M17.5 x 30 x 4, HT,
14	9843611	24	BOLT, Hex, M16 x 55, 10.9, Full Thd,
15	87308339	1	WASHER, THRUST,
16	1259633C3	1	GEAR,
17	314226A3	1	COVER,
18	A63171	1	BEARING, CUP,
19	622336C1	1	BEARING, CONE,
20	148939C1	1	SEAL,
	302259A2	1	GEAR SET, Pinion Shaft and Gears, Front Axle, Inc. 21, See Figure: 06-55
	302260A1	1	GEAR SET, Pinion Shaft and Gears, Rear Axle, Not Illustrated, Inc. 22, See Figure: 06-56
21	NSS	1	NOT SERVICED SEPARATELY, Gear, Drive, 53 T, Front Axle
22	NSS	1	NOT SERVICED SEPARATELY, Gear, Drive, Rear Axle, Not Illustrated
23	253931A1	1	BEARING SET,
24	253932A1	1	BEARING, CONE,
25	310693A1	1	SHAFT, Sun Gear
26	388308A1	1	SEAL, Not Illustrated

06-59 450 SERIES AXLE ASSY - DIFFERENTIAL, WITH DIFFERENTIAL LOCKS



06-59 450 SERIES AXLE ASSY - DIFFERENTIAL, WITH DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
	87304962	1	DIFFERENTIAL ASSY, Differential, Inc. 1, 2
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	1342851C1	1	PLUG, 10 mm
3	92907C1	1	SHAFT, Pinion, Long
4	1289349C1	1	SPACER,
5	92906C1	2	SHAFT, SHORT, Pinion
6	1289350C1	2	SPACER,
7	1270697C1	112	NEEDLE, 28 Per Gear
8	1289348C1	4	RING, Retainer
9	92718C2	4	WASHER,
10	92905C1	4	PINION,
11	1997421C1	2	BOLT,
12	137023A1	6	DOWEL, 10 x 60 mm
13	92915C1	4	PLATE, Separator
14	120679C1	3	PLATE, Friction
15	87308339	1	WASHER, THRUST,
16	1259633C3	1	GEAR,
17	253609A4	1	COVER,
18	310693A1	1	SHAFT, Sun Gear, Short
19	1259634C3	1	PINION, Lock
20	148939C1	1	SEAL,
	302259A2	1	GEAR SET, Pinion Shaft and Gears, Front Axle, Inc. 21, See Figure: 06-55
	302260A1	1	GEAR SET, Pinion Shaft and Gears, Rear Axle, Not Illustrated, Inc. 22, See Figure: 06-56
21	NSS	1	NOT SERVICED SEPARATELY, Gear, Drive, 53 T, Front Axle
22	NSS	1	NOT SERVICED SEPARATELY, Gear, Drive, Rear Axle, Not Illustrated
23	253931A1	1	BEARING SET,
24	253932A1	1	BEARING, CONE,
25	86625266	24	WASHER, M17.5 x 30 x 4, HT,
26	9843611	24	BOLT, Hex, M16 x 55, 10.9, Full Thd,
27	1997422C1	1	PISTON, Brake
28	622336C1	1	BEARING, CONE,
29	A63171	1	BEARING, CUP,

06-60 450 SERIES AXLE ASSY - BRAKE AND RIGHT-HAND CARRIER



06-60 450 SERIES AXLE ASSY - BRAKE AND RIGHT-HAND CARRIER

ссылка	Номер детали	Кол-во	Описание
	398362A1	1	CARRIER, Brake, Inc. 1, 2
1	NSS	1	NOT SERVICED SEPARATELY, Carrier
2	NSS	1	NOT SERVICED SEPARATELY, Plug, Expansion, 12 mm
3	139059C1	1	SEAL,
4	86639323	18	WASHER, M17.5 x 30 x 4, HT,
5	9840670	15	BOLT, Hex, M16 x 180, 10.9,
6	178565A2	1	PISTON, Service Brake
7	228194A3	1	PLATE, Return
8	353363A1	3	PLATE, Friction
9	228193A1	3	PLATE, Separator
10	226252A2	1	PLATE, Backing
11	226318A2	1	PISTON, Park Brake
12	226254A4	1	RING, Retaining
13	226320A1	1	SPRING,
14	86639321	12	WASHER, 13,5 x 24 x 3 mm
15	412085	2	BOLT, Hex, M12 x 80, 10.9,
16	412605	10	BOLT, Hex, M12 x 90, 10.9,
17	388308A1	2	SEAL, Ring
	235507A5	3	ADJUSTER, Inc. 18 - 20
18	86637801	1	DOWEL, 1/2" x 2", Dowel
19	86637643	6	RING, SNAP, #50, Ext,
20	1342928C1	9	WASHER, Thrust
21	86637768	1	O-RING, 1/8 ID x 18; 5
22	86637771	1	O-RING, -277, Cl 7, 11.484" ID x .139" Thk,
23	86637775	1	O-RING, 1/8 ID x 16; 7
24	86637772	1	O-RING, 1/8 ID x 12; 7
25	A63171	1	BEARING, CUP,
25	622336C1	1	BEARING, CONE,
26	178553A1	AR	SHIM, 0,076 mm
26	178554A1	AR	SHIM, 0,101 mm
26	178555A1	AR	SHIM, 0,130 mm
26	198843A1	AR	SHIM, 0,508 mm
27	310692A1	1	SHAFT, Sun Gear, Long
28	390873A1	3	BOLT, SPECIAL,
29	388308A1	1	SEAL, Not Illustrated

06-61 450 SERIES AXLE ASSY - FINAL DRIVE



06-61 450 SERIES AXLE ASSY - FINAL DRIVE

ссылка	Номер детали	Кол-во	Описание
	87363036	1	HOUSING, Inc. 1 - 4
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	86639248	2	DOWEL, M16 x 40, 16 x 40 mm
3	237698A1	1	BEARING, CUP,
4	A136253	1	BEARING SET, Cup
5	A136255	1	BEARING, CONE,
6	237700A1	1	BEARING, CONE,
	87363294	2	CARRIER, AXLE, 115 mm (4-1/2 in), Axle, Inc. 7 - 10
7	NSS	1	NOT SERVICED SEPARATELY, Shaft, 115 mm (4-1/2 in)
8	239529A1	1	BUSHING, Outboard
9	86637742	1	O-RING, -246, 70 Duro, 4.484" ID x .139" Thk,
10	1981270C1	1	INSERT,
11	239942A3	1	SEAL,
12	435222A1	1	SNAP RING, Retaining
13	436752A1	1	RING, THRUST, Retaining
14	437392A1	1	SHIM,
14	437393A1	1	SHIM,
14	437394A1	1	SHIM,
14	437395A1	1	SHIM,
14	437396A1	1	SHIM,
15	86639333	4	WASHER, 5/16",
16	43232	4	SCREW,
17	221578A1	1	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 18
18	86639043	1	O-RING, 15.3 ID x 2.2
19	388370A1	1	CARRIER, GEARS, Planetary
20	310697A3	4	SHAFT,
21	310694A2	4	GEAR, PLANETARY, 29 T
22	87435907	6	WASHER, Thrust
23	86985634	4	SPACER, RING,
24	1349347C1	1	BEARING, NEEDLE,
25	86639256	4	PIN, M8 x 26, Coiled,
26	360761A1	2	GEAR, RING, 76 T
27	86637645	2	RING, SNAP, #350, Ext,
28	86639323	36	WASHER, M17.5 x 30 x 4, HT,
29	86639230	18	BOLT, Hex, M16 x 150, 10.9,
30	800-51100	4	RING, SNAP, M100, Ext, Hvy, Retaining, 100 mm

06-62 500 SERIES AXLE ASSY - FRONT COVER



TJ430 TRACTOR (1/06-) - Power Train

06-62 500 SERIES AXLE ASSY - FRONT COVER

ссылка	Номер детали	Кол-во	Описание
	352211A1	1	GEAR SET, Pinion Shaft and Gears, Inc. 1, See Figure(s) : 06-65 & 06-66
1	NSS	1	NOT SERVICED SEPARATELY, Shaft, Pinion
2	248118A1	1	BEARING, CONE,
3	248114A1	1	BEARING SET,
4	328421A5	1	COVER,
5	14458081	1	O-RING, -122, Cl 7, 1.112" ID x .103" Thk,
6	191440A1	1	BEARING, CUP,
7	67190R91	1	BEARING, CONE,
8	229515A1	1	SNAP RING, Retaining, M4
9	86534066	2	RING, SNAP, 5.50", Int, #550,
10	87432424	1	SEAL, Pinion, Input Shaft
11	853764	1	CLAMP, 5/16", Insul, 5/16" Bolt,
12	228968A2	1	SPACER, Thick
13	191713A1	1	SPACER, Thin
14	191709A1	AR	SHIM, 0,076 mm
14	191711A1	AR	SHIM, 0,101 mm
14	191712A1	AR	SHIM, 0.130 mm
14	220785A1	AR	SHIM, 0,508 mm
15	43232	1	SCREW,
16	284186A1	1	SEAL,
17	86625090	1	O-RING, -276, 70 Duro, 10.984" ID x .139" Thk,
18	284180A1	1	PIPE, Lubrication
19	9617873	2	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk, Not Illustrated
20	279714A4	AR	SHIM, 0,076 mm
20	279715A4	AR	SHIM, 0,101 mm
20	279716A4	AR	SHIM, 0,130 mm
20	279717A4	AR	SHIM, 0,508 mm
21	284184A1	1	YOKE, 8,5 C
22	221578A1	1	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 23
23	86639043	1	O-RING, 15.3 ID x 2.2 W
24	9625178	1	PLUG, Hex Soc, 9/16"-18 ORB, Not Illustrated
25	86985636	1	ELBOW, Orificed, 5/16 x 3/8, Inc. 26
26	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
27	86639323	8	WASHER, M17.5 x 30 x 4, HT,
28	9843611	8	BOLT, Hex, M16 x 55, 10.9, Full Thd,
29	221578A1	1	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 30, Not Illustrated
30	86639043	1	O-RING, 15.3 ID x 2.2 W

06-63 500 SERIES AXLE ASSY - REAR COVER



TJ430 TRACTOR (1/06-) - Power Train

06-63 500 SERIES AXLE ASSY - REAR COVER

ссылка	Номер детали	Кол-во	Описание
	352212A2	1	GEAR SET, Set, Pinion Shaft and Gears, Inc. 1, See Figure(s) : 06-65 & 06-66
1	NSS	1	NOT SERVICED SEPARATELY, Shaft, Pinion
2	248118A1	1	BEARING, CONE,
3	248114A1	1	BEARING SET,
4	328422A5	1	COVER,
5	279714A4	AR	SHIM, 0,076 mm
5	279715A4	AR	SHIM, 0,101 mm
5	279716A4	AR	SHIM, 0,130 mm
5	279717A4	AR	SHIM, 0,508 mm
6	284185A1	1	YOKE, 8,5 C
7	9843611	8	BOLT, Hex, M16 x 55, 10.9, Full Thd,
8	191440A1	1	BEARING, CUP,
9	67190R91	1	BEARING, CONE,
10	228968A2	1	SPACER, Thick
11	87432424	1	SEAL, Oil, Pinion Input Shaft
12	229515A1	1	SNAP RING, Retaining, M4
13	191713A1	1	SPACER, Thin
14	853764	1	CLAMP, 5/16", Insul, 5/16" Bolt,
15	86639333	3	WASHER, 5/16",
16	43232	4	SCREW,
17	191709A1	1	SHIM, 0,076 mm
17	191711A1	1	SHIM, 0,101 mm
17	191712A1	1	SHIM, 0,130 mm
17	220785A1	1	SHIM, 0,508 mm
18	86625090	1	O-RING, -276, 70 Duro, 10.984" ID x .139" Thk,
19	313377A1	1	PIPE, Lubrication
20	221578A1	1	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 21, Not Illustrated
21	86639043	1	O-RING, 15.3 ID x 2.2
22	9625178	1	PLUG, Hex Soc, 9/16"-18 ORB, Not Illustrated, Includes 28
24	86639323	8	WASHER, M17.5 x 30 x 4, HT,
25	86985636	1	ELBOW, Orficed, 5/16 x 3/8, Inc. 26
26	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
27	9625178	1	PLUG, Hex Soc, 9/16"-18 ORB, Not Illustrated, Includes 28
29	9780064	1	BOLT, Hex, M24 x 110, 10.9,
30	228967A2	1	WASHER, Retaining
31	178545A1	AR	SHIM, 0,076 mm
31	178546A1	AR	SHIM, 0,101 mm
31	178547A1	AR	SHIM, 0,130 mm
31	220779A1	AR	SHIM, 0,508 mm
23	9993141	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
28	9993141	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,

06-64 500 SERIES AXLE ASSY - CENTER AND LEFT-HAND CARRIER



06-64 500 SERIES AXLE ASSY - CENTER AND LEFT-HAND CARRIER

ссылка	Номер детали	Кол-во	Описание
	87402395	1	HOUSING, AXLE, Axle, Center. Inc. 1 - 3
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	86639248	6	DOWEL, M16 x 40, 16 x 40 mm
3	86639247	1	DOWEL, M12 x 25, 12 x 25 mm
4	369765A1	1	CARRIER, BEARING,
5	253932A1	1	BEARING, CONE,
6	139060C2	1	RING,
7	139059C1	1	SEAL,
8	284188A1	1	TUBE, Jumper, Service Brake
9	86985628	1	TUBE, Jumper, Lubrication
10	86985628	1	TUBE, Jumper, Lubrication
11	298567A1	1	TUBE, Jumper, Park Brake
12	272217	4	O-RING, -013, 90 Duro, .426" ID x .070" Thk,
13	165212	4	O-RING, -015, 90 Duro, .551" ID x .070" Thk,
14	220069A1	1	PLUG, M33 x 2, ORB, M33 orb x 2, Inc. 15
15	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
16	86639334	3	WASHER, 33/64" x 7/8" x .049",
17	86639264	3	SCREW, Hex Flat Hd, M8 x 12, 4.8,
18	86639321	12	WASHER, 13.5 x 24 x 3 mm
19	412087	12	BOLT, Hex, M12 x 45, 10.9, Full Thd,
20	255121A1	AR	SHIM, 0,076 mm
20	255122A1	AR	SHIM, 0,101 mm
20	255123A1	AR	SHIM, 0,130 mm
20	255124A1	AR	SHIM, 0,508 mm

06-65 500 SERIES AXLE ASSY - DIFFERENTIAL, WITHOUT DIFFERENTIAL LOCKS



06-65 500 SERIES AXLE ASSY - DIFFERENTIAL, WITHOUT DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
	87304960	1	DIFFERENTIAL ASSY, Inc. 1, 2
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	1342851C1	1	PLUG, 10 mm
3	92907C1	1	SHAFT, Pinion, Long
4	1289349C1	1	SPACER, Long Pinion
5	92906C1	2	SHAFT, SHORT, Pinion
6	1289350C1	2	SPACER,
7	1270697C1	112	NEEDLE, 28 Per Gear
8	1289348C1	4	RING, Retaining
9	92718C2	4	WASHER,
10	92905C1	4	PINION,
11	1997421C1	2	BOLT, Cross Pin
12	137023A1	6	DOWEL, 10 x 60 mm
13	86625266	24	WASHER, M17.5 x 30 x 4, HT,
14	9843611	24	BOLT, Hex, M16 x 55, 10.9, Full Thd,
15	87308339	2	WASHER, THRUST,
16	1259633C3	2	GEAR, Bevel, 20T
17	87304965	1	COVER, Housing
18	622337C1	1	BEARING, CUP,
19	622336C1	1	BEARING, CONE,
20	148939C1	1	SEAL,
	352211A1	1	GEAR SET, Pinion Shaft and Gears, Front Axle, Inc. 21, See Figure: 06-62
	352212A2	1	GEAR SET, Set, Pinion Shaft and Gears, Rear Axle, Not Illustrated, Inc. 22, See Figure: 06-63
21	NSS	1	NOT SERVICED SEPARATELY, Gear, Drive, Front Axle, 53 T
22	NSS	1	NOT SERVICED SEPARATELY, Gear, Drive, Rear Axle, Not Illustrated
23	253931A1	1	BEARING SET,
24	253932A1	1	BEARING, CONE,
25	279719A2	1	SUN GEAR, Short

06-66 500 SERIES AXLE ASSY - DIFFERENTIAL, WITH DIFFERENTIAL LOCKS



06-66 500 SERIES AXLE ASSY - DIFFERENTIAL, WITH DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
	87304960	1	DIFFERENTIAL ASSY, Inc. 1, 2
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	1342851C1	1	PLUG, 10 mm
3	92907C1	1	SHAFT, Pinion, Long
4	1289349C1	1	SPACER, Long Pinion
5	92906C1	2	SHAFT, SHORT, Pinion
6	1289350C1	2	SPACER,
7	1270697C1	112	NEEDLE, 28 Per Gear
8	1289348C1	4	RING, Retaining
9	92718C2	4	WASHER,
10	92905C1	4	PINION,
11	1997421C1	2	BOLT, Cross Pin
12	137023A1	6	DOWEL, 10 x 60 mm
13	92915C1	4	PLATE, Separator
14	120679C1	3	PLATE, Friction
15	87308339	1	WASHER, THRUST,
16	1259633C3	1	GEAR, Bevel, 20T
17	87304964	1	COVER, Housing
18	279719A2	1	SUN GEAR, Short
19	1259634C3	1	PINION, Lock
20	148939C1	1	SEAL,
	352211A1	1	GEAR SET, Pinion Shaft and Gears, Front Axle, Inc. 21, See Figure: 06-62
	352212A2	1	GEAR SET, Set, Pinion Shaft and Gears, Rear Axle, Not Illustrated, Inc. 22, See Figure: 06-63
21	NSS	1	NOT SERVICED SEPARATELY, Gear, Drive, 53 T
22	NSS	1	NOT SERVICED SEPARATELY, Cover, Drive, Rear Axle, Not Illustrated
23	253931A1	1	BEARING SET,
24	253932A1	1	BEARING, CONE,
25	86625266	24	WASHER, M17.5 x 30 x 4, HT,
26	9843611	24	BOLT, Hex, M16 x 55, 10.9, Full Thd,
27	1997422C1	1	PISTON, Brake
28	622336C1	1	BEARING, CONE,
29	A63171	1	BEARING, CUP,

06-67 500 SERIES AXLE ASSY - BRAKE AND RIGHT-HAND CARRIER



06-67 500 SERIES AXLE ASSY - BRAKE AND RIGHT-HAND CARRIER

ссылка	Номер детали	Кол-во	Описание
	398453A1	1	CARRIER, Inc. 1, 2
1	NSS	1	NOT SERVICED SEPARATELY, Carrier, Brake
2	NSS	1	NOT SERVICED SEPARATELY, Plug, Expansion, 6,5 mm
3	139059C1	1	SEAL,
4	86639334	3	WASHER, 33/64" x 7/8" x .049", 33/64 x 7/8
5	86639264	3	SCREW, Hex Flat Hd, M8 x 12, 4.8,
6	353364A1	1	PISTON, Service Brake
7	228194A3	1	PLATE, Return
8	353363A1	4	PLATE, Friction
9	228193A1	4	PLATE, Separator
10	353367A3	1	PLATE, Backing
11	353369A1	1	PISTON, Park Brake
12	279707A1	1	SNAP RING, Retaining
13	226320A1	1	SPRING,
14	86639321	12	WASHER, 13.5 x 24 x 3 mm
15	86508622	10	BOLT, Hex, M12 x 100, 10.9, Cap, HH, CL 10.9, M12 x 1.75 x 100
16	412605	2	BOLT, Hex, M12 x 90, 10.9,
17	388308A1	2	SEAL, Ring
	363254A1	3	ADJUSTER, Inc. 18 - 20
18	86637802	1	DOWEL, 1/2" x 3",
19	86637643	6	RING, SNAP, #50, Ext,
20	1342928C1	12	WASHER, Thrust
21	86637774	1	O-RING, 1/8 ID x 15; 7
22	86637771	1	O-RING, -277, Cl 7, 11.484" ID x .139" Thk,
23	86637775	1	O-RING, 1/8 ID x 16; 7
24	86637772	1	O-RING, 1/8 ID x 12; 7
25	622336C1	1	BEARING, CONE,
26	279709A1	AR	SHIM, 0,076 mm
26	279710A1	AR	SHIM, 0,101 mm
26	279711A1	AR	SHIM, 0,130 mm
26	279712A1	AR	SHIM, 0,508 mm
27	279718A2	1	SHAFT, Long
28	86639322	18	WASHER, M12 x 28.5 x 3, HT,
29	86589011	18	BOLT, Hex, M14 x 3 x 55, 10.9,

06-68 500 SERIES AXLE ASSY - FINAL DRIVE



TJ430 TRACTOR (1/06-) - Power Train

06-68 500 SERIES AXLE ASSY - FINAL DRIVE

ссылка	Номер детали	Кол-во	Описание
	435221A1	1	CARRIER, AXLE, Inc. 1 - 4
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	86639248	2	DOWEL, M16 x 40, 16 x 40 mm
3	237698A1	1	BEARING, CUP,
4	A136253	1	BEARING SET,
5	NSS	1	NOT SERVICED SEPARATELY, Bearing, Cone
6	237700A1	1	BEARING, CONE,
	435219A1	1	SHAFT ASSY., Axle, 115 mm (4-1/2 in), Inc. 7 - 10
7	NSS	1	NOT SERVICED SEPARATELY, Shaft, 115 mm (4-1/2 in)
8	87593684	1	BUSHING, Outboard
9	86637742	1	O-RING, -246, 70 Duro, 4.484" ID x .139" Thk,
10	1981270C1	1	INSERT,
11	239942A3	1	SEAL,
12	435222A1	1	SNAP RING, Retaining
13	436752A1	1	RING, THRUST, Retaining
14	437392A1	1	SHIM,
14	437393A1	1	SHIM,
14	437394A1	1	SHIM,
14	437395A1	1	SHIM,
14	437396A1	1	SHIM,
15	86639333	4	WASHER, 5/16",
16	43232	4	SCREW,
17	221578A1	1	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 18
18	86639043	1	O-RING, 15.3 ID x 2.2
19	435215A1	1	CARRIER, AXLE, Planetary, 44T / 18T, Large Spline
20	357483A1	3	SHAFT,
21	357347A2	3	GEAR, 18 T / 44 T
22	397449A1	6	WASHER, THRUST,
23	377650A1	3	SPACER,
24	360785A1	1	NEEDLE, 58 per gear
25	86639256	3	PIN, M8 x 26, Coiled,
26	357346A1	2	GEAR, 69 T
27	86637645	2	RING, SNAP, #350, Ext,
28	86639323	36	WASHER, M17.5 x 30 x 4, HT,
29	87015550	36	BOLT, Hex, M16 x 130, 10.9,
30	301615	4	RING, SNAP, Retaining, 115 mm
31	435216A1	2	SPACER,

06-69 AXLE ASSY - JET PUMP



TJ430 TRACTOR (1/06-) - Power Train

06-69 AXLE ASSY - JET PUMP

ссылка	Номер детали	Кол-во	Описание
1	428862A1	1	PUMP, LUBE,
2	347294A3	1	PUMP,
3	9861410	1	O-RING, -017, 90 Duro, .676" ID x .070" Thk,
4	49861	1	O-RING, -110, 70 Duro, .362" ID x .103" Thk,
5	221580A1	1	PLUG, Hex Soc, M27 x 2, ORB, Includes 6
6	86639045	1	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
7	221578A1	2	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 8
8	86639043	2	O-RING, 15.3 ID x 2.2
9	221576A1	1	PLUG, Hex Soc, M14 x 1.5, ORB, Includes 10
10	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
11	221579A1	1	PLUG, Hex Soc, M22 x 1.5, ORB, Includes 12
12	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
13	86624176	3	WASHER, M10 x 20 x 2,
14	86639212	1	BOLT, Hex, M10 x 75, 10.9,
15	86625011	2	BOLT, Hex, M10 x 35, 10.9, Full Thd,
16	14458081	2	O-RING, -122, Cl 7, 1.112" ID x .103" Thk,
17	86625138	1	PLUG, Hex Soc, 7/8"-14 ORB, Includes 18
18	167269	1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,

07-01 BRAKE CONTROL



TJ430 TRACTOR (1/06-) - Brakes

07-01 BRAKE CONTROL

ссылка	Номер детали	Кол-во	Описание
1	222462A2	1	PEDAL,
2	87448885	1	SUPPORT,
3	43139	2	SCREW,
4	321961A1	2	MOLDING,
5	281093A1	2	WASHER,
6	278210A1	1	SPRING,
7	279265A2	1	SWITCH, Brake Light
8	281893A1	1	BEARING, Pivot
9	302822A3	1	VALVE, Brake, See Figure(s) : 07-02
10	1537272C1	1	CLEVIS, M10 x 40
11	369851A1	1	ROD,
12	86500689	1	NUT, M10, Cl 10,
13	43233	4	BOLT, Hex, M8 x 20, 10.9,
14	86624184	4	WASHER, M8 x 16 x 1.6,
15	86639108	1	PIN, CLEVIS, M10 x 30, 10 x 30 mm
16	86639116	1	PIN, SPLIT (COTTER), M2.5 x 12,
17	86625251	1	WASHER, M10 x 18 x 1.6,
18	345471A1	1	SWITCH, Differential Lock

07-02 BRAKE VALVE ASSY



TJ430 TRACTOR (1/06-) - Brakes

07-02 BRAKE VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
	302822A3	1	VALVE, Brake, Inc. 1 - 10
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	195806A1	1	SEAL,
3	185613A1	1	SPRING,
4	280297A1	1	SPOOL,
5	291105A1	1	SPRING, Outer
6	291107A1	1	RETAINER,
7	229659A1	1	RING, SNAP, Retaining
8	291106A1	1	STEM,
9	279266A1	1	SWITCH, Inc. 10
10	86513328	1	O-RING, 3-1, .301" ID x .064" Thk,
11	291104A1	1	SPRING,
12	167111	1	RING, SNAP, 1.50", Int, #150,

07-03 450 SERIES AXLE HYDRAULICS - SERVICE BRAKE CIRCUIT



TJ430 TRACTOR (1/06-) - Brakes

07-03 450 SERIES AXLE HYDRAULICS - SERVICE BRAKE CIRCUIT

ссылка	Номер детали	Кол-во	Описание
1	401760A1	1	VALVE, Check, 13/16 fc sl x 22 or, Inc. 2, 3
2	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
3	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
4	392132A1	1	HOSE ASSY., 2125 mm (84")
5	86579691	1	ELBOW, 90є, 13/16"-18 ORFS x M18 x 1.5 ORB, Includes 6, 7
6	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
7	86639043	1	O-RING, 15.3 ID x 2.2
8	87364344	1	HOSE, 1105 mm (43-1/2")
9	353609A1	1	HOSE ASSY., 2115 mm (83")
10	86639083	2	NUT, LOCK, 13/16"-16, ORFS Blkhd,
11	86639079	1	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc. 12
12	9992298	2	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
13	86637979	2	CLAMP, 13/16", Insul, 3/8" Bolt, P-type
14	43362	1	NUT, M8, Cl 10,
15	L18331	2	STRAP, CABLE, Tie
16	86639058	1	TEE, 13/16"-16 ORFS x M22 x 1.5 ORB Run, Inc. 17, 18
17	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
18	9992298	2	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
19	86624184	1	WASHER, M8 x 16 x 1.6,
20	S120426	1	SLEEVE,
21	R43926	1	CLAMP, 90 Twist, 3/4"
22	895-15008	1	WASHER, M8 x 20 x 1.6,
23	627-8030	1	BOLT, Hex, M8 x 30, 10.9,
24	832-10408	1	NUT, LOCK, M8 x 1.25, Cl 8,
25	394446A1	1	PLATE, Mounting
26	L50641	1	CONNECTING STRIP, Bracket

07-04 450 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITH DIFFERENTIAL LOCKS



TJ430 TRACTOR (1/06-) - Brakes

07-04 450 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITH DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
1	86639083	1	NUT, LOCK, 13/16"-16, ORFS Blkhd,
2	86639079	1	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc.7
3	449796A1	1	TUBE ASSY.,
4	361955A1	1	HOSE ASSY., 2286 mm (90 in)
5	418814A1	1	HOSE, 2184 mm (86 in)
6	86639080	1	TEE, 13/16"-16 ORFS, Blkd Run, Inc. 7
7	9992298	15	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
8	87309670	1	HOSE, 1170 mm (46 in)
9	86579679	2	CONNECTOR, HYD., 1"-14 ORFS x M18 x 1.5 ORB, Inc. 10, 11
10	9992069	7	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
11	86639043	2	O-RING, 15.3 ID x 2.2
12	86579680	1	CONNECTOR, HYD., 1"-14 ORFS x M22 x 1.5 ORB, Includes 10, 14
13	87345208	1	TUBE, Brake Supply
14	86639044	3	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
15	87365244	1	TUBE, Return
17	86624184	8	WASHER, M8 x 16 x 1.6,
16	349863A2	1	CABLE, Tow Valve, See Figure: 08-14 for Mounting & Related Parts.
18	411104A2	1	VALVE, Regulator, See Figure: 08-11
19	86639150	3	BOLT, Hex, M10 x 150, 10.9,
20	449827A1	1	TUBE ASSY.,
21	86639085	1	NUT, LOCK, 1"-14, ORFS Blkhd,
22	449798A1	1	TUBE ASSY.,
23	84989383	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Inc. 7
24	515-24206	2	CLAMP, 13/16", Insul, 7/16" Bolt,
25	86624176	2	WASHER, M10 x 20 x 2,
26	86500689	2	NUT, M10, Cl 10,
27	87424332	1	HOSE ASSY., 1298 mm (51 in)
28	87452229	1	VALVE, Control, Tow Block, See Figure: 08-13
29	361897A1	1	SPRING,
30	449830A1	1	PLATE ASSY.,
31	86637776	1	LINK, CHAIN,
32	392748A1	2	SPACER,
33	390918A3	1	ARM,
34	86639207	1	BOLT, Hex, M6 x 70, 10.9,
35	412250	1	NUT, LOCK, M8 x 1.25, Cl 8,
36	86624177	3	WASHER, M12 x 24 x 2.5,
37	337475	3	NUT, M12, Cl 10,
38	86625251	1	WASHER, M10 x 18 x 1.6,
39	43362	7	NUT, M8, Cl 10,
41	L111928	1	CLAMP,
	178889A1	1	FITTING, Diagnostic, Inc. 42, 43
42	86502604	1	DUST CAP, Dust
43	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 44
44	86639042	3	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
45	86639081	1	TEE, 1"-14 ORFS, Blkd Run, Inc. 53

07-04 450 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITH DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
46	87345210	1	BRACKET, Mounting
47	43233	3	BOLT, Hex, M8 x 20, 10.9,
48	86639323	1	WASHER, M17.5 x 30 x 4, HT,
49	86639058	2	TEE, 13/16"-16 ORFS x M22 x 1.5 ORB Run, Inc. 7, 14
50	9706748	2	CLAMP, 5/8", Insul, 5/16" Bolt,
51	416276A1	1	TUBE ASSY.,
52	416282A1	1	TUBE ASSY.,
	341195A1	2	ORIFICE, Inc. 53 - 56
53	86579674	2	CONNECTOR, HYD., 13/16"-16 ORFS x M14 x 1.5 ORB, Inc. 7, 44
54	NSS	1	NOT SERVICED SEPARATELY, Orifice, M8 x 12
55	384977A1	2	VALVE, Solenoid, Differential Lock, See Figure: 07-09

07-05 450 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITHOUT DIFFERENTIAL LOCKS



TJ430 TRACTOR (1/06-) - Brakes

07-05 450 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITHOUT DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
1	86639083	1	NUT, LOCK, 13/16"-16, ORFS Blkhd,
2	86639079	1	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc.7
3	449796A1	1	TUBE ASSY.,
4	361955A1	1	HOSE ASSY., 2286 mm (90 in)
5	418814A1	1	HOSE, 2184 mm (86 in)
6	86639080	1	TEE, 13/16"-16 ORFS, Blkd Run, Inc. 7
7	9992298	13	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
8	87309670	1	HOSE, 2286 mm (90 in)
9	86579679	2	CONNECTOR, HYD., 1"-14 ORFS x M18 x 1.5 ORB, Inc. 10, 11
10	9992069	6	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
11	86639043	2	O-RING, 15.3 ID x 2.2
12	86579680	1	CONNECTOR, HYD., 1"-14 ORFS x M22 x 1.5 ORB, Includes 10, 14
14	86639044	3	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
15	87365244	1	TUBE, Return
16	349863A2	1	CABLE, Tow Valve, See Figure: 08-14 for Mounting & Related Parts.
17	86624184	2	WASHER, M8 x 16 x 1.6,
18	411104A2	1	VALVE, Regulator, See Figure: 08-11
19	86639150	3	BOLT, Hex, M10 x 150, 10.9,
20	449827A2	1	TUBE ASSY.,
21	86639085	1	NUT, LOCK, 1"-14, ORFS Blkhd,
22	449798A1	1	TUBE ASSY.,
23	84989383	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Inc. 7
24	515-24206	2	CLAMP, 13/16", Insul, 7/16" Bolt,
25	86624176	2	WASHER, M10 x 20 x 2,
26	86500689	2	NUT, M10, Cl 10,
27	87424332	1	HOSE ASSY., 1298 mm (51 in)
28	87452229	1	VALVE, Control, Tow Block, See Figure: 08-13
29	361897A1	1	SPRING,
30	449830A1	1	PLATE ASSY.,
31	86637776	1	LINK, CHAIN,
32	392748A1	2	SPACER,
33	390918A3	1	ARM,
34	86639207	1	BOLT, Hex, M6 x 70, 10.9,
35	412250	1	NUT, LOCK, M8 x 1.25, Cl 8,
36	86624177	3	WASHER, M12 x 24 x 2.5,
37	337475	3	NUT, M12, Cl 10,
38	86625251	1	WASHER, M10 x 18 x 1.6,
39	43362	7	NUT, M8, Cl 10,
41	L111928	1	CLAMP,
	178889A1	1	FITTING, Diagnostic, Inc. 42, 43
42	86502604	1	DUST CAP, Dust
43	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 44
44	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
45	86639081	1	TEE, 1"-14 ORFS, Blkd Run, Inc. 10
46	87345210	1	BRACKET, Mounting

07-05 450 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITHOUT DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
47	43233	3	BOLT, Hex, M8 x 20, 10.9,
48	86639323	1	WASHER, M17.5 x 30 x 4, HT,
49	86579678	2	CONNECTOR, HYD., 13/16"-16 ORFS x M22 x 1.5 ORB, Inc. 7, 14

07-06 500 SERIES AXLE HYDRAULICS - SERVICE BRAKE CIRCUIT



TJ430 TRACTOR (1/06-) - Brakes

07-06 500 SERIES AXLE HYDRAULICS - SERVICE BRAKE CIRCUIT

ссылка	Номер детали	Кол-во	Описание
1	401760A1	1	VALVE, Check, 13/16 fc sl x 22 or, Inc. 2, 3
2	9992298	6	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
3	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
4	391243A2	1	HOSE ASSY., 2184 mm (86")
5	86579691	1	ELBOW, 90є, 13/16"-18 ORFS x M18 x 1.5 ORB, Includes 2, 7
6	86639058	1	TEE, 13/16"-16 ORFS x M22 x 1.5 ORB Run, Inc. 2, 12
7	86639043	1	O-RING, 15.3 ID x 2.2
8	87364344	1	HOSE, 1105 mm (43-1/2")
9	353609A1	1	HOSE ASSY., 2115 mm (83")
10	86639083	2	NUT, LOCK, 13/16"-16, ORFS Blkhd,
11	86639079	1	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc. 2
12	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
13	86637979	2	CLAMP, 13/16", Insul, 3/8" Bolt, P-type
14	43362	1	NUT, M8, Cl 10,
15	43234	1	BOLT, Hex, M8 x 25, 10.9,
16	S120426	1	SLEEVE,
17	L18331	1	STRAP, CABLE, Tie
18	R43926	1	CLAMP, 90 Twist, 3/4"
19	895-15008	1	WASHER, M8 x 20 x 1.6,
20	627-8030	1	BOLT, Hex, M8 x 30, 10.9,
21	832-10408	1	NUT, LOCK, M8 x 1.25, Cl 8,

07-07 500 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITH DIFFERENTIAL LOCKS



07-07 500 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITH DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
1	43362	4	NUT, M8, Cl 10,
2	349863A2	1	CABLE, Tow Valve, See Figure 08-14 for Mounting & Related Parts.
3	86624176	2	WASHER, M10 x 20 x 2,
4	86625251	3	WASHER, M10 x 18 x 1.6,
5	428171A1	1	HOSE ASSY., 2235 mm (88 in)
6	86639080	1	TEE, 13/16"-16 ORFS, Blkd Run,
7	9992298	8	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
8	87309670	1	HOSE, 1170 mm (46 in)
9	86579679	2	CONNECTOR, HYD., 1"-14 ORFS x M18 x 1.5 ORB, Inc. 10, 11
10	9992069	7	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
11	86639043	2	O-RING, 15.3 ID x 2.2
12	86579680	1	CONNECTOR, HYD., 1"-14 ORFS x M22 x 1.5 ORB, Includes 10, 14
13	87345208	1	TUBE, Brake Supply
14	86639044	2	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
15	87365244	1	TUBE, Return
16	515-24206	2	CLAMP, 13/16", Insul, 7/16" Bolt, P-type
17	43233	1	BOLT, Hex, M8 x 20, 10.9,
18	411104A2	1	VALVE, Regulator, See Figure: 08-11
19	86639150	3	BOLT, Hex, M10 x 150, 10.9,
20	449827A2	1	TUBE ASSY.,
21	86639085	1	NUT, LOCK, 1"-14, ORFS Blkhd,
22	449796A1	1	TUBE ASSY.,
23	86639079	1	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc. 7
24	87345210	1	BRACKET, Mounting
25	449798A1	1	TUBE ASSY.,
26	84989383	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Inc. 7
27	627-8020	1	BOLT, Hex, M8 x 20, 10.9,
28	87452229	1	VALVE, Control, Tow Block, See Figure: 08-13
29	361897A1	1	SPRING,
30	449830A1	1	PLATE ASSY.,
31	86637776	1	LINK, CHAIN,
32	392748A1	2	SPACER,
33	390918A3	1	ARM,
34	86639207	1	BOLT, Hex, M6 x 70, 10.9,
35	412250	1	NUT, LOCK, M8 x 1.25, Cl 8,
36	86624177	3	WASHER, M12 x 24 x 2.5,
37	337475	3	NUT, M12, Cl 10,
38	87414079	1	HOSE ASSY.,
39	86500689	2	NUT, M10, Cl 10,
40	86639083	3	NUT, LOCK, 13/16"-16, ORFS Blkhd,
41	435470A1	2	CLAMP,
42	435468A1	2	PLATE,
43	86556137	1	BOLT, Hex, M8 x 70, 10.9,
44	86624184	8	WASHER, M8 x 16 x 1.6,
45	352112A3	1	HOSE ASSY., 2336 mm (92 in)

07-07 500 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT, WITH DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
46	515-22159	2	CLAMP, 5/8", Insul, 5/16" Bolt,
47	86639323	1	WASHER, M17.5 x 30 x 4, HT,
	178889A1	1	FITTING, Diagnostic, Inc. 48, 49
48	86502604	1	DUST CAP, Dust
49	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 50
50	86639042	3	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
51	86639081	1	TEE, 1"-14 ORFS, Blkd Run, Inc. 10
52	86639058	2	TEE, 13/16"-16 ORFS x M22 x 1.5 ORB Run, Inc. 7, 14
53	416697A1	2	TUBE ASSY.,
	341195A1	2	ORIFICE, Inc. 54, 55
54	86639306	2	SET SCREW, Hex Soc, M8 x 12, Cup Pt,
55	86579674	2	CONNECTOR, HYD., 13/16"-16 ORFS x M14 x 1.5 ORB, Inc. 60, 61
56	384977A1	2	VALVE, Solenoid, Differential Lock, See Figure: 07-09

07-08 500 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT,WITHOUT DIFFERENTIAL LOCKS



TJ430 TRACTOR (1/06-) - Brakes

07-08 500 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT,WITHOUT DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
1	43362	1	NUT, M8, Cl 10,
2	349863A2	1	CABLE, Tow Valve, See Figure: 08-14 for Mounting & Related Parts
3	86624176	2	WASHER, M10 x 20 x 2,
4	86625251	3	WASHER, M10 x 18 x 1.6,
5	428171A1	1	HOSE ASSY., 2235 mm (88 in)
6	86639080	1	TEE, 13/16"-16 ORFS, Blkd Run,
7	9992298	3	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
8	87416123	1	HOSE ASSY., 2286 mm (90 in)
9	86579679	2	CONNECTOR, HYD., 1"-14 ORFS x M18 x 1.5 ORB, Inc. 10, 11
10	9992069	2	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
11	86639043	2	O-RING, 15.3 ID x 2.2
12	86579680	1	CONNECTOR, HYD., 1"-14 ORFS x M22 x 1.5 ORB, Includes 10, 14
13	87345208	1	TUBE, Brake Supply
14	86639044	2	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
15	87365244	1	TUBE, Return
16	515-24206	2	CLAMP, 13/16", Insul, 7/16" Bolt, P-type
17	43233	1	BOLT, Hex, M8 x 20, 10.9,
18	411104A2	1	VALVE, Regulator, See Figure: 08-11
19	86639150	3	BOLT, Hex, M10 x 150, 10.9,
20	449827A2	1	TUBE ASSY.,
21	86639085	1	NUT, LOCK, 1"-14, ORFS Blkhd,
22	449796A1	1	TUBE ASSY.,
23	86639079	1	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc. 7
24	87345210	1	BRACKET, Mounting
25	449798A1	1	TUBE ASSY.,
26	84989383	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Inc. 7
27	627-8020	3	BOLT, Hex, M8 x 20, 10.9,
28	87452229	1	VALVE, Control, Tow Block, See Figure: 08-13
29	361897A1	1	SPRING,
30	449830A1	1	PLATE ASSY.,
31	86637776	1	LINK, CHAIN,
32	392748A1	2	SPACER,
33	390918A3	1	ARM,
34	86639207	1	BOLT, Hex, M6 x 70, 10.9,
35	412250	1	NUT, LOCK, M8 x 1.25, Cl 8,
36	86624177	3	WASHER, M12 x 24 x 2.5,
37	337475	3	NUT, M12, Cl 10,
38	87414079	1	HOSE ASSY.,
39	86500689	2	NUT, M10, Cl 10,
40	86639083	3	NUT, LOCK, 13/16"-16, ORFS Blkhd,
41	435470A1	2	CLAMP,
42	435468A1	2	PLATE,
43	86556137	1	BOLT, Hex, M8 x 70, 10.9,
44	86624184	8	WASHER, M8 x 16 x 1.6,
45	352112A3	1	HOSE ASSY., 2336 mm (92 in)

07-08 500 SERIES AXLE HYDRAULICS - PARK BRAKE CIRCUIT,WITHOUT DIFFERENTIAL LOCKS

ссылка	Номер детали	Кол-во	Описание
46	515-22159	2	CLAMP, 5/8", Insul, 5/16" Bolt,
47	86639323	1	WASHER, M17.5 x 30 x 4, HT,
	178889A1	1	FITTING, Diagnostic, Inc. 48, 49
48	86502604	1	DUST CAP, Dust
49	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 50
50	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
51	86639081	1	TEE, 1"-14 ORFS, Blkd Run, Inc. 52
52	86579692	2	ELBOW, 90є, 13/16"-18 ORFS x M22 x 1.5 ORB, Inc. 7, 14

07-09 VALVE ASSY - DIFFERENTIAL LOCK



TJ430 TRACTOR (1/06-) - Brakes

07-09 VALVE ASSY - DIFFERENTIAL LOCK

ссылка	Номер детали	Кол-во	Описание
	384977A1	1	VALVE, Solenoid, Differential Lock, Inc. 1 - 6
1	384976A1	1	CARTRIDGE,
2	353941A1	1	COIL,
3	167269	1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,
4	14453280	1	O-RING, -015, 70 Duro, .551" ID x .070" Thk,
5	130282	1	O-RING, -014, 70 Duro, .489" ID x .070" Thk,
6	NSS	1	NOT SERVICED SEPARATELY, Nut

08-01 HYDRAULIC OIL COOLER, TJ380 / 430 & T9030 / 9040



TJ430 TRACTOR (1/06-) - Hydraulic System

08-01 HYDRAULIC OIL COOLER, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87312759	1	COOLER, Oil
2	REF	1	INSTRUCTION, Head Filter, Transmission, LH, See Figure: 08-04
3	REF	1	INSTRUCTION, Head Filter, Axle Lubrication, RH, See Figure: 8-04
4	377614A1	4	HOSE ASSY., 1022 mm (45 in)
5	86579682	4	CONNECTOR, HYD., 1 3/16"-12 ORFS x M27 x 2 ORB, Includes 6 & 7
6	9991976	4	O-RING, -018, 90 Duro, .739" ID x .070" Thk,
7	86639045	4	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
8	86580179	2	CONNECTOR, HYD., 1 7/16"-12 ORFS x M22 x 2 ORB, Includes 9, 10
10	86639046	2	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
11	9846677	4	BOLT, Hex, M10 x 25, 10.9, Full Thd,
12	86624176	6	WASHER, M10 x 20 x 2,
13	R15257	2	CLAMP,
14	9992069	4	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
15	86500689	2	NUT, M10, Cl 10,
9	9993141	2	O-RING, -012, 90 Duro, .364" ID x .070" Thk,

08-03 HYDRAULIC OIL COOLER MOUNTING, TJ380 / 430 & T9030 / 9040



08-03 HYDRAULIC OIL COOLER MOUNTING, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87312759	1	COOLER, Oil
2	302339A1	1	ANGLE,
3	9992069	4	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
4	86625263	9	WASHER, M8 x 20 x 1.6,
5	43233	9	BOLT, Hex, M8 x 20, 10.9,


11
2
3
7
6
8
4
5
4
10
1
9

TJ430 TRACTOR (1/06-) - Hydraulic System

08-04 OIL FILTER - AXLE AND TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	302557A2	2	SENDER UNIT, Temperature
2	87524853	1	Head, Filter, Axle Lubrication, RH
2	87524852	1	Head, Filter, Transmission Lubrication, LH
3	N6755	1	INDICATOR, Switch, Restriction, Inc. 4 - 8
4	86625058	2	NUT, #10-32, LH,
5	280254	1	WASHER, LOCK, Int Tooth, #10,
6	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
7	9672548	1	O-RING, -011, 70 Duro, .301" ID x .070" Thk,
8	NSS	1	NOT SERVICED SEPARATELY, Switch
9	86989735	1	FILTER, HYDRAULIC OIL, Inc. 10
10	1986552C2	1	O-RING,
11	443097A1	1	KIT, Check Valve, Outline

08-05 OIL FILTER - MAIN HYDRAULICS (BELOW BATTERY)



TJ430 TRACTOR (1/06-) - Hydraulic System

08-05 OIL FILTER - MAIN HYDRAULICS (BELOW BATTERY)

ссылка	Номер детали	Кол-во	Описание
1	86991559	1	FILTER ASSY, Inc. 2 - 12
2	87409374	1	Head, Filter,
3	NSS	1	NOT SERVICED SEPARATELY, Valve, By-Pass
4	N6755	1	INDICATOR, Restriction, Inc. 5 - 9
5	NSS	1	NOT SERVICED SEPARATELY, Indicator
6	280254	1	WASHER, LOCK, Int Tooth, #10,
7	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
8	9672548	1	O-RING, -011, 70 Duro, .301" ID x .070" Thk,
9	86625058	2	NUT, #10-32, LH,
10	86018758	1	FILTER, HYDRAULIC OIL, Inc. 11 & 12
11	NSS	1	NOT SERVICED SEPARATELY, Element
12	NSS	1	NOT SERVICED SEPARATELY, O-Ring

08-06 450 SERIES AXLE HYDRAULICS - LUBRICATION CIRCUIT



TJ430 TRACTOR (1/06-) - Hydraulic System

08-06 450 SERIES AXLE HYDRAULICS - LUBRICATION CIRCUIT

ссылка	Номер детали	Кол-во	Описание
1	86579678	2	CONNECTOR, HYD., 13/16"-16 ORFS x M22 x 1.5 ORB, Inc. 2, 3
2	9992298	15	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
3	86639044	2	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
4	390659A2	1	HOSE ASSY., 2178 mm (86 in)
5	87413875	1	HOSE,
6	43234	2	BOLT, Hex, M8 x 25, 10.9,
7	9993141	3	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
8	86639083	3	NUT, LOCK, 13/16"-16, ORFS Blkhd,
9	507586	6	CLAMP, HOSE, #20, 0.81/1.75 Type F Worm, No. 20
10	337545A1	2	CONNECTOR, HYD., Axle Drain
11	404991A1	1	HOSE, 38, Cut From : S118383
12	87388066	1	TUBE, HYD,
13	87390647	1	HOSE,
14	416727A1	1	TUBE,
15	87414080	1	HOSE ASSY.,
16	411104A2	1	VALVE, Regulator, See Figure: 08-11
17	86579675	1	CONNECTOR, HYD., 13/16"-16 ORFS x M16 x 1.5 ORB, Inc. 2, 19
18	87307544	1	TUBE ASSY.,
19	86642449	1	O-RING, Cl 6, 13.3MM ID x 2.2 Thk,
20	413338A1	1	TUBE ASSY.,
21	449800A1	1	TUBE ASSY.,
22	86579676	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 2, 24
23	700-447	1	TEE, 13/16"-16 ORFS x M22 x 1.5 ORB Br, Inc. 2, 24
24	86639043	2	O-RING, 15.3 ID x 2.2
25	87307521	1	TUBE ASSY.,
26	9992307	3	ELBOW, 90є, 13/16"-16 x 3/4"-18 Adj, ORFS, 90, 1/2 or x fc sl, Inc. 2, 27
27	86642448	3	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
28	X4837565	2	FITTING, 13/16 fc sl x blkhd, Inc. 2
29	86590562	1	PLUG, Hex Soc, 3/4"-16 ORB, Soc Hd, 3/4"or, Inc. 36
30	334783A1	1	SLEEVE, 24"
31	L18331	2	STRAP, CABLE, 15 in
32	86637979	1	CLAMP, 13/16", Insul, 3/8" Bolt,
33	449813A2	1	TUBE ASSY.,
33	449813A2	1	TUBE ASSY., 19.3 ID x 2.2 mm
34	449815A2	2	TUBE ASSY.,
35	358968A1	1	COUPLING, M18 orb x 1,5, Diagnostic, Inc. 24
36	167266	1	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk,
38	392690A1	1	COUPLING,
39	399032A1	1	CAP,
40	435457A1	2	HOSE, 102 mm (4 in), Cut From : 443082A1
41	416729A1	1	TUBE ASSY.,
42	416512A1	1	SUPPORT,
43	86624184	2	WASHER, M8 x 16 x 1.6,
44	43233	2	BOLT, Hex, M8 x 20, 10.9,
45	43362	1	NUT, M8, Cl 10,

ссылка	Номер детали	Кол-во	Описание
46	409614A1	1	TUBE ASSY., Return
47	253105A1	2	U-BOLT,
48	396490A1	2	U-BOLT,
49	86624184	8	WASHER, M8 x 16 x 1.6,
50	86528579	8	NUT, LOCK, M8 x 1.25, Cl 10,
51	87535336	2	BRACKET,
52	434727A1	1	MOTOR-PUMP, Axle Air / Lube
53	437116A1	1	HOSE, LARGE, 127 mm (5 in), Cut From: 443082A1
54	86639079	1	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc. 2

08-07 450 SERIES AXLE HYDRAULICS - AIR AND LUBRICATION CIRCUIT



TJ430 TRACTOR (1/06-) - Hydraulic System

08-07 450 SERIES AXLE HYDRAULICS - AIR AND LUBRICATION CIRCUIT

ссылка	Номер детали	Кол-во	Описание
1	86579676	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 2, 3
2	86639043	1	O-RING, 15.3 ID x 2.2
3	9992298	6	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
4	436927A1	1	HOSE ASSY., 2045 mm (80 1/2in), Used without Power Take Off
5	87016877	3	ELBOW, 90є, 13/16"-16 x 9/16"-18, Adj, ORFS, 90, M12 or x fc sl, Inc. 6, 3
6	86642448	3	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
7	449794A1	1	TUBE ASSY.,
8	87323932	1	FITTING, Special, Inc. 3, 6
9	87381645	1	TUBE, M12 fc sl x blkhd fc sl, Inc. 10
10	86992953	3	HOSE ASSY.,
11	434727A1	1	MOTOR-PUMP, Axle Air / Lube
12	43234	4	BOLT, Hex, M8 x 25, 10.9,
13	43362	7	NUT, M8, Cl 10,
14	86624184	10	WASHER, M8 x 16 x 1.6,
15	86637979	1	CLAMP, 13/16", Insul, 3/8" Bolt,
16	416512A1	4	SUPPORT,
17	86624005	2	CLAMP, 3/4", Insul, 3/8" Bolt,
18	43233	8	BOLT, Hex, M8 x 20, 10.9,
19	86639083	1	NUT, LOCK, 13/16"-16, ORFS Blkhd,
20	86639079	3	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc. 21
21	9992298	7	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
22	416102A1	1	SUPPORT, Bracket
23	449825A1	1	TUBE ASSY.,
24	86993932	1	HOSE ASSY., 1353 mm (53-1/4")
25	87413731	1	TUBE ASSY.,
26	86579692	1	ELBOW, 90є, 13/16"-18 ORFS x M22 x 1.5 ORB, Inc. 54
27	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
28	86010402	2	CLAMP, 1/2", Insul, 3/8" Bolt,
29	86579678	1	CONNECTOR, HYD., 13/16"-16 ORFS x M22 x 1.5 ORB, Inc. 45, 57
30	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
31	449817A2	1	TUBE ASSY.,
32	86992542	1	TUBE ASSY.,
33	86639083	2	NUT, LOCK, 13/16"-16, ORFS Blkhd,
34	449823A1	1	TUBE ASSY.,
35	X4837565	1	FITTING, 13/16 fc sl x blkhd, Inc. 3
36	86994373	1	HOSE ASSY., 2150 mm (84-1/2 in)
37	9515003	4	BOLT, Hex, M10 x 30, 10.9, Full Thd,
38	86625252	4	WASHER, M10 x 21.5 x 2.5, HT,
39	86500689	4	NUT, M10, Cl 10,
40	87413733	1	BRACKET,

08-08 500 SERIES AXLE HYDRAULICS - LUBRICATION CIRCUIT



TJ430 TRACTOR (1/06-) - Hydraulic System

08-08 500 SERIES AXLE HYDRAULICS - LUBRICATION CIRCUIT

ссылка	Номер детали	Кол-во	Описание
1	86639058	2	TEE, 13/16"-16 ORFS x M22 x 1.5 ORB Run, Inc. 2, 3
2	9992298	15	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
3	86639044	5	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
4	86579676	4	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 2, 6
5	449815A2	1	TUBE ASSY.,
6	86639043	3	O-RING, 15,3 ID x 2,2
7	353607A3	1	HOSE ASSY., 2165 mm (85 in)
8	87413874	1	HOSE ASSY.,
9	507586	6	CLAMP, HOSE, #20, 0.81/1.75 Type F Worm, No. 20
10	451013A1	2	TUBE ASSY.,
11	353649A1	1	HOSE, 1346 mm (53 in), Cut From : 443082A1
12	87376395	1	TUBE, HYD,
13	87390647	1	HOSE,
14	395933A1	1	HOSE, 356 mm (14 in), Cut From : S118383
15	80167266	1	O-RING,
16	411104A2	1	VALVE, Regulator, See Figure: 08-11
17	86579675	1	CONNECTOR, HYD., 13/16"-16 ORFS x M16 x 1.5 ORB, Inc. 2, 19
18	9672548	2	O-RING, -011, 70 Duro, .301" ID x .070" Thk,
19	86642449	1	O-RING, Cl 6, 13.3MM ID x 2.2 Thk,
20	413338A1	1	TUBE ASSY.,
21	449800A1	1	TUBE ASSY.,
22	86579676	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 23, 24
23	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
24	128999	2	O-RING, -111, 70 Duro, .424" ID x .103" Thk,
25	87307521	2	TUBE ASSY.,
26	86639079	1	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc. 2
27	87400028	2	ORIFICE, Pinnion Cover
28	86639083	3	NUT, LOCK, 13/16"-16, ORFS Blkhd,
29	X4837565	2	FITTING, 13/16 fc sl x blkhd, Inc. 2
30	449813A2	1	TUBE ASSY.,
32	43234	2	BOLT, Hex, M8 x 25, 10.9,
33	358968A1	1	COUPLING, M18 orb x 1,5, Diagnostic, Inc. 3
34	43362	6	NUT, M8, Cl 10,
35	86639043	1	O-RING, 15,3 ID x 2,2 mm
36	392690A1	1	COUPLING,
37	399032A1	1	CAP,
38	390348A1	2	STEM, M33 orb x barb, Axle Drain, Inc. 39
39	86639046	2	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
40	334783A1	1	SLEEVE,
41	L18331	2	STRAP, CABLE, Tie
42	9992307	4	ELBOW, 90є, 13/16"-16 x 3/4"-18 Adj, ORFS, 90, 1/2 or x13/16 fc sl, Inc. 43, 2
43	86642448	1	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
44	87307544	1	TUBE ASSY.,
45	86579678	2	CONNECTOR, HYD., 13/16"-16 ORFS x M22 x 1.5 ORB, Inc. 2, 3
46	700-447	1	TEE, 13/16"-16 ORFS x M22 x 1.5 ORB Br, Inc. 2

08-08 500 SERIES AXLE HYDRAULICS - LUBRICATION CIRCUIT

ссылка	Номер детали	Кол-во	Описание
47	86590562	1	PLUG, Hex Soc, 3/4"-16 ORB, Soc Hd, 3/4" or, Inc. 56
48	434727A1	1	MOTOR-PUMP, Axle Air / Lube
49	87400024	2	TUBE ASSY., Final Drive, Long
50	409614A1	1	TUBE ASSY., Return
51	253105A1	2	U-BOLT,
52	396490A1	2	U-BOLT,
53	86624184	16	WASHER, M8 x 16 x 1.6,
54	86528579	8	NUT, LOCK, M8 x 1.25, Cl 10,
55	409609A1	2	PLATE,
56	167266	1	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk,
31	9993141	3	O-RING, -012, 90 Duro, .364" ID x .070" Thk,

08-09 500 SERIES AXLE HYDRAULICS - AIR AND LUBRICATION CIRCUIT



TJ430 TRACTOR (1/06-) - Hydraulic System

08-09 500 SERIES AXLE HYDRAULICS - AIR AND LUBRICATION CIRCUIT

ссылка	Номер детали	Кол-во	Описание
1	86579676	2	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 2, 3
2	9992298	12	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
3	86639043	1	O-RING, 15,3 ID x 2,2
4	436864A1	1	HOSE ASSY., 533 mm (21")
5	86639079	2	ELBOW, 90є, 13/16"-16, ORFS, Blkhd, Inc. 6, 7
6	9992298	3	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
7	86639083	1	NUT, LOCK, 13/16"-16, ORFS Blkhd,
8	87381645	1	TUBE, Air Supply
9	86992953	1	HOSE ASSY., 1715 mm (67-1/2 in)
10	86637979	3	CLAMP, 13/16", Insul, 3/8" Bolt,
11	86624184	2	WASHER, M8 x 16 x 1.6,
12	43362	2	NUT, M8, Cl 10,
13	515-23190	2	CLAMP, 3/4", Insul, 3/8" Bolt, P-type
14	416102A1	1	SUPPORT, Bracket
15	43362	7	NUT, M8, Cl 10,
16	43234	1	BOLT, Hex, M8 x 25, 10.9,
17	434727A1	2	MOTOR-PUMP, Axle Air / Lube
18	87016877	3	ELBOW, 90є, 13/16"-16 x 9/16"-18, Adj, ORFS, 90, M12 or x 13/16 fc sl, Inc. 2, 19
19	86642448	3	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
20	87323932	1	FITTING, Special, 1/2 or x fc sl, Inc. 2, 19
21	449817A2	1	TUBE ASSY.,
22	86992542	1	TUBE ASSY.,
23	X4837565	2	FITTING, 13/16 fc sl x blkhd, Inc. 2
24	86639083	2	NUT, LOCK, 13/16"-16, ORFS Blkhd,
25	86579678	1	CONNECTOR, HYD., 13/16"-16 ORFS x M22 x 1.5 ORB, Inc. 2, 26
26	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
27	87400117	1	HOSE ASSY., 2299 mm (90-1/2 in), Used without Power Take Off
28	449825A1	1	TUBE ASSY.,
29	449794A1	1	TUBE ASSY.,
30	449823A1	1	TUBE ASSY.,
31	86993937	4	HOSE ASSY., 1194 mm (47 in)
32	86624184	4	WASHER, M8 x 16 x 1.6,
33	417271A1	1	BRACKET,
34	89515003	4	SCREW,
35	120104	1	BOLT, Hex, M8 x 20, 8.8,
36	417272A1	1	BRACKET,
37	43235	1	BOLT, Hex, M8 x 30, 10.9,
38	86625252	4	WASHER, M10 x 21.5 x 2.5, HT,
39	86500689	4	NUT, M10, Cl 10,

08-10 450 / 500 SERIES AXLE HYDRAULICS - COOLING CIRCUIT



TJ430 TRACTOR (1/06-) - Hydraulic System

08-10 450 / 500 SERIES AXLE HYDRAULICS - COOLING CIRCUIT

ссылка	Номер детали	Кол-во	Описание
1	43234	4	BOLT, Hex, M8 x 25, 10.9,
2	43362	3	NUT, M8, Cl 10,
3	411104A2	1	VALVE, Regulator, See Figure: 08-11
4	86580180	2	ELBOW, 90є, 1 7/16"-12 ORFS x M33 x 2 ORB, Includes 18, 19
5	9824050	2	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
6	86639046	2	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
7	418818A1	1	TUBE ASSY.,
8	87439123	1	TUBE,
9	R15257	2	CLAMP,
10	9780069	2	BOLT, Hex, M8 x 40, 10.9,
11	328232A1	1	TEE, Inc. 12 & 13
12	86639046	2	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
13	9824050	1	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
14	87310970	1	TUBE, HYD, Pump Supply
15	86991559	1	FILTER ASSY, See Figure: 08-05
16	86639150	3	BOLT, Hex, M10 x 150, 10.9,
17	9840576	1	CAP, 1"-14 ORFS, , With Electronic Three Point Hitch
18	832-10408	2	NUT, LOCK, M8 x 1.25, Cl 8,
19	86625251	2	WASHER, M10 x 18 x 1.6,
20	418820A1	1	TUBE ASSY.,
21	416708A1	1	TUBE ASSY.,
22	451507A1	2	BRACKET,
23	86637977	3	CLAMP, 1", Insul, 5/16" Bolt, 1 ID
24	86624184	3	WASHER, M8 x 16 x 1.6,
25	9824050	5	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
26	418816A2	1	TUBE ASSY., Pump Supply, Used with Mega Flow Application
27	413322A1	1	BRACKET, Mounting
28	86625251	4	WASHER, M10 x 18 x 1.6,
29	9861444	4	BOLT, Hex, M10 x 20, 10.9, Full Thd,
30	627-8030	1	BOLT, Hex, M8 x 30, 10.9,

08-11 REGULATOR VALVE ASSY



TJ430 TRACTOR (1/06-) - Hydraulic System

08-11 REGULATOR VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
	411104A2	1	VALVE, Regulator, Inc. 1 - 36
1	NSS	1	NOT SERVICED SEPARATELY, Body
	1542563C1	1	VALVE, CHECK, Inc. 2 - 6
2	1994580C1	1	PLUG,
3	1543329C1	1	POPPET, VALVE,
4	1994581C1	1	SPRING,
5	165212	1	O-RING, -015, 90 Duro, .551" ID x .070" Thk,
6	G108723	1	RING,
7	221579A1	1	PLUG, Hex Soc, M22 x 1.5, ORB, Inc. 8
8	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
9	119182A3	1	SPOOL,
10	176312A1	1	SPRING,
11	313941A1	1	PLUG,
12	167266	1	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk,
13	86637729	1	NUT, LOCK, Blkhd, 1 1/16"-12,
	344573A1	1	PLUG, Inc. 14 - 15
14	NSS	1	NOT SERVICED SEPARATELY, Plug
15	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
16	330105A1	1	SPRING,
17	330103A1	1	SPOOL,
18	330104A1	1	PIN,
19	9841223	1	PLUG, Hex Soc, 1 1/16"-12 ORB, Includes 20
20	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
21	221578A1	3	PLUG, Hex Soc, M18 x 1.5, ORB, Inc. 22
22	86639043	3	O-RING, 15.3 ID x 2.2
	339487A2	1	CONNECTOR, HYD., Inc. 23 - 25
23	NSS	1	NOT SERVICED SEPARATELY, Adapter, 11/16 fc sl x 14 orb
24	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
26	86579671	1	CONNECTOR, HYD., 11/16"-16 ORFS x M14 x 1.5 ORB, Inc. 27, 28
27	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
29	86629585	1	O-RING, -118, 70 Duro, .862" ID x .103" Thk,
30	358968A1	1	COUPLING, Diagnostic, Inc. 22
31	14457081	2	O-RING, -112, Cl 7, .487" ID x .103" Thk,
	87330331	1	SOLENOID, Inc. 32 - 39
32	298614A1	1	SOLENOID,
33	NSS	1	NOT SERVICED SEPARATELY, Nut
34	NSS	1	NOT SERVICED SEPARATELY, Valve, Cartridge, 2 gpm
35	167266	1	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk,
36	NSS	1	NOT SERVICED SEPARATELY, Filter, Screen
37	87330336	1	SOLENOID, Solenoid Holder
38	G35540	1	RING, Backup
39	9991976	1	O-RING, -018, 90 Duro, .739" ID x .070" Thk,
25	9993141	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
28	9993141	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,

08-12 PRIORITY / STEERING CONTROL VALVE ASSEMBLY



KIT KIT

● = 3
▲ =18
■ =21

TJ430 TRACTOR (1/06-) - Hydraulic System

08-12 PRIORITY / STEERING CONTROL VALVE ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
1	87442925	1	VALVE, CONTROL, Priority / EHPS, Inc. 2 - 20, BSN Z7F202170
1	87585897	1	VALVE, HYDRAULIC, Priority / EHPS, Inc. 2 - 20, ASN Z7F202170
1	87436468	1	VALVE, CONTROL, Priority / EHPS, Inc. 2 - 26, Used with INTELLIGUIDE Applications., BSN Z7F202170
1	87585898	1	VALVE, HYDRAULIC, Prioritu / EHPS, 2 - 26, Used with INTELLIGUIDE Applications., ASN Z7F20217(
2	NSS	1	NOT SERVICED SEPARATELY, Housing, Steering Valve
3	87397327	1	KIT, SEALS, EHPS
4	NSS	1	NOT SERVICED SEPARATELY, Plug, w/ O-Ring
5	NSS	6	NOT SERVICED SEPARATELY, Plug, w/ O-Ring
6	NSS	1	NOT SERVICED SEPARATELY, Bushing, w/ O-Ring
7	NSS	1	NOT SERVICED SEPARATELY, Plug, w/ O-Ring
8	NSS	1	NOT SERVICED SEPARATELY, Plug, w/ O-Ring
9	NSS	1	NOT SERVICED SEPARATELY, Plug, w/ O-Ring
10	NSS	5	NOT SERVICED SEPARATELY, O-Ring
11	NSS	4	NOT SERVICED SEPARATELY, O-Ring
12	NSS	AR	NOT SERVICED SEPARATELY, Screw
13	NSS	1	NOT SERVICED SEPARATELY, Cover
14	NSS	4	NOT SERVICED SEPARATELY, Screw
15	NSS	2	NOT SERVICED SEPARATELY, Plug, w/ O-Ring
16	NSS	1	NOT SERVICED SEPARATELY, Housing, Priority Valve
17	NSS	3	NOT SERVICED SEPARATELY, Bolt
18	87397328	1	KIT, SEALS, OLS Priority Valve
19	NSS	2	NOT SERVICED SEPARATELY, O-Ring
20	NSS	2	NOT SERVICED SEPARATELY, Plug, w/ O-Ring
21	87397329	1	KIT, SEALS, PVE, Used with INTELLIGUIDE Applications.
22	87540544	2	VALVE, Valve, Shuttle, Used with INTELLIGUIDE Applications.
23	NSS	3	NOT SERVICED SEPARATELY, O-Ring, Used with INTELLIGUIDE Applications.
24	NSS	1	NOT SERVICED SEPARATELY, O-Ring, Used with INTELLIGUIDE Applications.
25	NSS	1	NOT SERVICED SEPARATELY, O-Ring, Used with INTELLIGUIDE Applications.
26	NSS	1	NOT SERVICED SEPARATELY, Solenoid, PVEH, Used with INTELLIGUIDE Applications.
27	NSS	1	NOT SERVICED SEPARATELY, Cover
28	NSS	3	NOT SERVICED SEPARATELY, Washer
29	NSS	1	NOT SERVICED SEPARATELY, Plug, w/ O-Ring
30	87637887	1	KIT, Steering Spool

08-13 TOW BLOCK VALVE ASSY



TJ430 TRACTOR (1/06-) - Hydraulic System

08-13 TOW BLOCK VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
	87452229	1	VALVE, Control, Tow Block, Inc. 1 - 24
1	NSS	1	NOT SERVICED SEPARATELY, Body
2	221576A1	2	PLUG, Hex Soc, M14 x 1.5, ORB, Inc. 3
3	86639042	3	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
4	86637959	1	BALL, 6mm Dia, 6 mm
5	352025A1	1	SPRING, Brake
6	221573A1	2	PLUG, Hex Soc, M12 x 1.5, ORB, M12 orb x 13, Inc. 7
7	86642448	2	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
8	326300A1	1	SPOOL, Manual Pump
9	282839A1	1	PLUG, Inc. 10, 11
10	9993141	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
11	86639043	1	O-RING, 15.3 ID x 2.2
12	86579678	1	CONNECTOR, HYD., 13/16"-16 ORFS x M22 x 1.5 ORB, Inc. 13, 14
13	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
14	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
15	86637953	1	WASHER, 11/32" x 11/16" x 0.89", HDN, 11/32 x 11/16 x 3/32
16	1994615C2	3	VALVE, CHECK,
17	221579A1	1	PLUG, Hex Soc, M22 x 1.5, ORB, Inc. 18
18	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
19	86637741	1	O-RING, -208, 70 Duro, .609" ID x .139" Thk,
20	A63399	1	SEAL, Oil Sensing
	234783A8	1	SOLENOID, Inc. 21 - 24
21	NSS	1	NOT SERVICED SEPARATELY, Solenoid
22	86637770	2	O-RING, -115, Cl 7, .674" ID x .103" Thk,
23	NSS	1	NOT SERVICED SEPARATELY, Coil
24	252462A2	1	NUT,

08-14 CABLE - TOW VALVE



TJ430 TRACTOR (1/06-) - Hydraulic System

08-14 CABLE - TOW VALVE

ссылка	Номер детали	Кол-во	Описание
1	344904A2	1	SUPPORT ASSY.,
2	A67295	1	PLUG,
3	86639013	1	PIN, CLEVIS, M8 x 25, 8 x 25 mm
4	86637652	1	PIN, SPLIT (COTTER), Int, 9/64" x .054",
5	86624184	2	WASHER, M8 x 16 x 1.6,
6	43362	2	NUT, M8, Cl 10,
7	349863A2	1	CABLE,

08-15 HYDRAULIC TANK



TJ430 TRACTOR (1/06-) - Hydraulic System

08-15 HYDRAULIC TANK

ссылка	Номер детали	Кол-во	Описание
1	87313209	1	TANK,
2	401394A1	1	LADDER, Rear, LH
3	401395A1	1	LADDER, Front, LH
4	87301185	5	STEP,
5	87408715	1	FILTER, STRAINER, Oil
6	254253A1	1	CAP, Oil Filter, if used
6	325737A1	1	CAP, Oil Filler, if used
7	86637723	1	PLUG, Hex Hd, 1/2"-14 NPTF, 1/2 PT
8	1971726C1	1	BREATHER,
9	435031A1	1	GASKET, Cover
10	435030A1	1	COVER, Access
11	86528579	8	NUT, LOCK, M8 x 1.25, Cl 10,
12	86624978	16	BOLT, Hex, M10 x 35, 10.9, Full Thd,
13	86514720	26	NUT, LOCK, M10 x 1.5
14	376530A1	2	SUPPORT, Step
15	V43471	2	BOLT,
16	363226A1	1	BUMPER,
17	86624176	10	WASHER, M10 x 20 x 2,
18	86636816	2	BOLT, CARRIAGE, M10 x 25; 8.8
19	86639325	8	WASHER, M10 x 24.5 x 3, HT,
20	86508618	8	BOLT, Hex, M10 x 45, 10.9,
21	337248A1	4	O-RING,
22	352767A1	2	CONNECTOR, HYD., Sight Gauge
23	86511845	2	BOLT, Hex Flg, M10 x 35, 8.8,
24	349869A1	1	CHANNEL, Sight Gauge
25	355179A1	1	HOSE, Sight Gauge
26	86637725	1	PLUG, Hex Soc, 1 1/4"-11 1/2 NPTF, Socket, 1-1/4
27	434856A1	1	DECAL, Hydraulic Oil Level, See Figure: 09-55
28	397307A3	1	FENDER, FRONT, Flare, Fender, LH
29	86624978	6	BOLT, Hex, M10 x 35, 10.9, Full Thd,
30	86500689	10	NUT, M10, Cl 10,
31	435032A1	1	NUT, LOCK,
32	87442437	1	BRACKET, Step Support, Outboard
33	87442438	1	BRACKET, Step Support, In-board
34	627-10025	4	BOLT, Hex, M10 x 25, 10.9, Full Thd,

08-16 STANDARD HYDRAULICS - PUMP LUBRICATION CIRCUIT, MANUAL SHIFT TRANSMISSION



08-16 STANDARD HYDRAULICS - PUMP LUBRICATION CIRCUIT, MANUAL SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	402484A2	1	TUBE ASSY.,
2	87400492	1	SCREEN, FILTER, with O-Rings
3	401617A3	1	TUBE ASSY.,
4	435413A1	1	HOSE, 114 mm (4-1/2 in)
5	86624194	6	CLAMP, HOSE, #36, 1.81/2.75 Type F Worm, 1-13/16 - 2-3/4
6	435454A1	2	HOSE, 102 mm (4 in), Cut From : 443069A1
7	87441239	1	TUBE ASSY., Inc. 15 & 16
8	87545498	1	VALVE, CHECK,
9	87307320	1	TUBE ASSY.,
10	358968A1	1	COUPLING, M18 orb x 1,5, Diagnostic, Inc. 11
11	86639043	1	O-RING, 15.3 ID x 2.2
12	349499A1	1	HOSE ASSY., 1420 mm (56 in)
13	87357616	1	HOSE,
14	86637769	2	O-RING, -228, 90 Duro, 2.234" ID x .139" Thk,
15	701-900	1	CAP, 11/16"-16 ORFS, Inc. 16
16	238-6012	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
17	335104A2	1	HOSE ASSY., 925 mm (36 in), Regulator Valve to Piston Pump
18	84989413	1	ELBOW, 90є, 1 7/16"-12 ORFS x 1 7/16"-12 Fem Sw, Inc. 19
19	9824050	1	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
20	86639002	1	CLAMP, 1 3/8", Insul, 7/16" Bolt,
21	86624184	12	WASHER, M8 x 16 x 1.6,
22	43235	1	BOLT, Hex, M8 x 30, 10.9,
23	238-6012	4	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
24	87309732	1	BLOCK,
25	426-620	4	
26	829-1408	1	NUT, M8, Cl 10,
27	701-319	1	ELBOW, 90є, 11/16"-16 ORFS x 11/16"-16 Fem Sw, 90
	178889A1	1	FITTING, Diagnostic, Inc. 28, 29
28	86502604	1	DUST CAP,
29	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 30
30	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
31	87436468	1	VALVE, CONTROL, Priority, See Figure: 08-12
32	238-6219	2	O-RING, -219, 90 Duro, 1.296" ID x .139" Thk,
33	238-6011	1	O-RING, -011, 90 Duro, .301" ID x .070" Thk,
34	87309930	1	HOSE, 800 mm (31"), BSN Z7F202275
34	87565932	1	HOSE ASSY., 869 mm (34-1/2"), ASN Z7F202275
35	327499A1	1	HOSE ASSY., 665 mm (26-1/2")
36	86639054	1	ELBOW, 45є, 1 7/16"-12 ORFS x M33 x 2 ORB, Inc. 38 & 47, BSN Z7F202275
38	9824050	1	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
39	9992298	2	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
40	700-102	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 11 & 39
41	87438228	1	HOSE ASSY., 1211 mm (47-1/2")
42	300209A1	1	VALVE, Shuttle, Inc. 23
43	87389531	1	HOSE, 1820 mm (71-5/8")
44	A12306	2	FLANGE, Split Clamp

ссылка	Номер детали	Кол-во	Описание
45	515-23254	1	CLAMP, 1", Insul, 3/8" Bolt,
46	700-165	1	CONNECTOR, HYD., 11/16"-16 ORFS x M12 x 1.5 ORB, Inc. 23 & 33
47	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
48	87550213	1	FITTING, 45, Special, ASN Z7F202275
49	700-101	1	CONNECTOR, HYD., 11/16"-16 ORFS x M14 x 1.5 ORB, , ASN Z7F202275
50	87565927	1	TUBE, Diagnostic Priority, ASN Z7F202275
51	701-909	1	NUT, LOCK, 11/16"-16, Blkhd, , ASN Z7F202275
52	190119A1	1	COUPLING, Diagnostic, ASN Z7F202275

08-17 STANDARD HYDRAULICS - PUMP LUBRICATION CIRCUIT, POWER SHIFT TRANSMISSION



TJ430 TRACTOR (1/06-) - Hydraulic System

08-17 STANDARD HYDRAULICS - PUMP LUBRICATION CIRCUIT, POWER SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	402484A2	1	TUBE ASSY.,
2	87400492	1	SCREEN, FILTER, with O-Rings
3	419665A2	1	TUBE ASSY.,
4	435413A1	1	HOSE, 114 mm (4-1/2 in)
5	86624194	6	CLAMP, HOSE, #36, 1.81/2.75 Type F Worm, 1-13/16 - 2-3/4
6	435454A1	2	HOSE, 102 mm (4 in), Cut From : 443069A1
7	87438195	1	TUBE ASSY., Inc. 15 & 16
8	87545498	1	VALVE, CHECK,
9	87307318	1	TUBE ASSY.,
10	358968A1	1	COUPLING, M18 orb x 1,5, Diagnostic, Inc. 11
11	86639043	1	O-RING, 15.3 ID x 2.2
12	327466A1	1	HOSE, 1486 mm (58")
13	87357616	1	HOSE,
14	86637769	2	O-RING, -228, 90 Duro, 2.234" ID x .139" Thk,
15	701-900	1	CAP, 11/16"-16 ORFS, Inc. 16
16	238-6012	2	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
17	335104A2	1	HOSE ASSY., 925 mm (36 in), Regulator Valve to Piston Pump
18	84989413	1	ELBOW, 90є, 1 7/16"-12 ORFS x 1 7/16"-12 Fem Sw, Inc. 19
19	9824050	1	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
20	86639002	1	CLAMP, 1 3/8", Insul, 7/16" Bolt,
21	86624184	12	WASHER, M8 x 16 x 1.6,
22	43235	1	BOLT, Hex, M8 x 30, 10.9,
23	238-6012	4	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
24	398274A2	1	BLOCK,
25	86637941	4	SCREW, Hex Soc Hd, 3/8"-16 x 2 3/4",
26	9515003	2	BOLT, Hex, M10 x 30, 10.9, Full Thd,
27	701-319	1	ELBOW, 90є, 11/16"-16 ORFS x 11/16"-16 Fem Sw, 90
	178889A1	1	FITTING, Diagnostic, Inc. 28, 29
28	86502604	1	DUST CAP,
29	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 30
30	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
31	87436468	1	VALVE, CONTROL, Priority, See Figure: 08-15
32	238-6219	2	O-RING, -219, 90 Duro, 1.296" ID x .139" Thk,
33	238-6011	1	O-RING, -011, 90 Duro, .301" ID x .070" Thk,
34	87309930	1	HOSE, 840 mm (33 in), BSN Z7F202275
34	87565932	1	HOSE ASSY., 869 mm (34-1/2"), ASN Z7F202275
35	395875A1	1	HOSE ASSY., 775 mm (30-1/2")
36	86639054	1	ELBOW, 45є, 1 7/16"-12 ORFS x M33 x 2 ORB, Inc. 38 & 47, BSN Z7F202275
37	87550213	1	FITTING, 45, Special, Inc. 38 & 47, ASN Z7F202275
38	9824050	1	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
39	9992298	2	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
40	700-102	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 11 & 39
41	87438228	1	HOSE ASSY., 1211 mm (47-1/2")
42	300209A1	1	VALVE, Shuttle
43	87389531	1	HOSE, 1820 mm (71-5/8")

08-17 STANDARD HYDRAULICS - PUMP LUBRICATION CIRCUIT, POWER SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
44	A12306	2	FLANGE, Split Clamp
45	515-23254	1	CLAMP, 1", Insul, 3/8" Bolt,
46	700-165	1	CONNECTOR, HYD., 11/16"-16 ORFS x M12 x 1.5 ORB, Inc. 23 & 33
47	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
48	86579671	1	CONNECTOR, HYD., 11/16"-16 ORFS x M14 x 1.5 ORB, Inc. 23 & 30, ASN Z7F202275
49	87565927	1	TUBE, Diagnostic Priority, ASN Z7F202275
50	701-909	1	NUT, LOCK, 11/16"-16, Blkhd, , ASN Z7F202275
51	190119A1	1	COUPLING, Diagnostic, ASN Z7F202275

08-18 STANDARD HYDRAULICS - PUMP MOUNTING



TJ430 TRACTOR (1/06-) - Hydraulic System

08-18 STANDARD HYDRAULICS - PUMP MOUNTING

ссылка	Номер детали	Кол-во	Описание
1	87308197	1	PUMP, 71 cc, Piston, See Figure: 08-19
2	87427941	1	PUMP, HYDRAULIC, 100 cc, Gear, See Figure: 08-24
3	238-5250	1	O-RING, -250, 70 Duro, 4.984" ID x .139" Thk,
4	86637949	2	WASHER, 17/32" x 1 1/8" x .060",
5	412398	2	BOLT, Hex, M16 x 50, 10.9,
6	9824055	1	CONNECTOR, HYD., 1-7/16 fc x 1-5/16 Or, Inc. 7, 8
7	167268	1	O-RING, 16-1, 90 Duro, 1.171" ID x .116" Thk,
8	9824050	1	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
9	201-308	1	ELBOW, 90є, 1 7/16"-12 x 1 5/8"-12, Adj, ORFS, 90, 1-7/16 fc x 1-5/16 Or, Inc. 10, 11
10	167268	1	O-RING, 16-1, 90 Duro, 1.171" ID x .116" Thk,
11	9824050	1	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
12	9824642	2	BOLT, Hex, M12 x 35, 10.9,
13	86505941	1	ELBOW, Inc. 14, 15
14	167269	1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,
15	9992069	1	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
16	A14141	4	FLANGE,
17	88904	8	BOLT, Hex, 1/2"-13 x 1 1/2", G8, Full Thd,
18	201-125	1	CONNECTOR, HYD., 11/16"-16 ORFS x 7/16"-20 ORB, 1/4" Or x 3/8" fc sl, Inc. 19 & 20
19	165202	1	O-RING, 4-1, 90 Duro, .351" ID x .072" Thk,
21	87419160	1	BRACKET, , Power Shift Transmission
21	87419158	1	BRACKET, , Manual Shift Transmission
22	87419159	1	PLATE,
23	L111928	2	CLAMP,
24	43235	4	BOLT, Hex, M8 x 30, 10.9,
25	86624184	8	WASHER, M8 x 16 x 1.6,
26	86528579	4	NUT, LOCK, M8 x 1.25, Cl 10,
27	436514A1	1	O-RING,
20	9993141	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,

08-19 PISTON PUMP ASSY - STANDARD HYDRAULICS



TJ430 TRACTOR (1/06-) - Hydraulic System

08-19 PISTON PUMP ASSY - STANDARD HYDRAULICS

ссылка	Номер детали	Кол-во	Описание
	87308197	1	PUMP, 71 cc, Inc. 1 - 23
1	NSS	1	NOT SERVICED SEPARATELY, Cylinder Assy
2	NSS	1	NOT SERVICED SEPARATELY, Piston Assy, Control
3	NSS	1	NOT SERVICED SEPARATELY, Housing
4	NSS	1	NOT SERVICED SEPARATELY, Block
5	NSS	1	NOT SERVICED SEPARATELY, Plate, Swash
6	NSS	1	NOT SERVICED SEPARATELY, Shaft
7	NSS	1	NOT SERVICED SEPARATELY, Washer
8	NSS	1	NOT SERVICED SEPARATELY, Spacer
9	NSS	1	NOT SERVICED SEPARATELY, Bearing, Roller
10	NSS	1	NOT SERVICED SEPARATELY, Bearing, Roller
11	NSS	2	NOT SERVICED SEPARATELY, Support
12	NSS	1	NOT SERVICED SEPARATELY, Seal
13	NSS	1	NOT SERVICED SEPARATELY, O-Ring
14	NSS	4	NOT SERVICED SEPARATELY, O-Ring
15	NSS	1	NOT SERVICED SEPARATELY, Ring, Snap
16	NSS	4	NOT SERVICED SEPARATELY, Screw
17	87308198	1	COMPENSATOR, Compensator
18	NSS	1	NOT SERVICED SEPARATELY, Plug
19	NSS	1	NOT SERVICED SEPARATELY, O-Ring
20	NSS	1	NOT SERVICED SEPARATELY, Pin
21	NSS	1	NOT SERVICED SEPARATELY, Coupling
22	NSS	2	NOT SERVICED SEPARATELY, Screw
23	436514A1	1	O-RING,
24	8604965	3	O-RING,
	388293A1	1	KIT, SEALS, Seals, Inc. 12 - 14, 19, 23

08-20 HIGH OUTPUT HYDRAULICS, PUMP LUBRICATION, MANUAL SHIFT TRANSMISSION



TJ430 TRACTOR (1/06-) - Hydraulic System

08-20 HIGH OUTPUT HYDRAULICS, PUMP LUBRICATION, MANUAL SHIFT TRANSMISSION

ссылка	Номер детали	Кол-во	Описание
1	327499A1	1	HOSE ASSY., 665 mm (26-1/2")
2	87306902	1	TUBE ASSY., Inc. 9 & 10
3	238-5232	1	O-RING, -232, 70 Duro, 2.734" ID x .139" Thk,
4	87545498	1	VALVE, CHECK,
5	87307260	1	TUBE ASSY.,
6	435413A1	2	HOSE, 114 mm (4-1/2")
7	214-1436	8	CLAMP, HOSE, #36, 1.81/2.75 Type F Worm,
8	87307313	1	TUBE ASSY.,
9	701-900	1	CAP, 11/16"-16 ORFS, Cap
10	238-6012	11	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
11	358968A1	1	COUPLING, Diagnostic, Inc. 12
12	637-63153	2	O-RING, Cl 6, 15.3MM ID x 2.2 Thk,
13	238-6014	5	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
14	238-6021	4	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
15	405572A1	1	TUBE ASSY.,
16	238-6228	2	O-RING, -228, 90 Duro, 2.234" ID x .139" Thk,
17	405574A1	1	TUBE ASSY.,
18	435454A1	2	HOSE, 102 mm (4"), Cut From: 443069A1
19	700-105	1	CONNECTOR, HYD., 1 7/16"-12 ORFS x M22 x 2 ORB, Inc. 14 & 20
20	637-64296	2	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
21	86992232	1	BLOCK, Pump
22	86637942	4	SCREW, Hex Soc Hd, 1/2"-13 x 2 1/2",
23	238-6222	1	O-RING, -222, 90 Duro, 1.484" ID x .139" Thk,
	178889A1	1	FITTING, Diagnostic, Inc. 24 - 26
24	86502604	1	DUST CAP,
25	NSS	1	NOT SERVICED SEPARATELY, Fitting, Inc. 26
26	637-63113	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
27	87307101	1	HOSE,
28	700-318	1	ELBOW, 45є, 1 7/16"-12 ORFS x M33 x 2 ORB, Inc. 14 & 20, BSN Z7F202275
29	87550213	1	FITTING, 45, Special, Inc. 14 & 20, ASN Z7F202275
30	701-339	1	ELBOW, 90є, 1 7/16"-12 ORFS x 1 7/16"-12 Fem Sw, Inc. 31
31	238-6025	1	O-RING, -025, 90 Duro, 1.176" ID x .070" Thk,
32	700-102	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 12 & 13
33	701-320	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Inc. 13
34	87441813	1	HOSE ASSY., 1403 mm (55-1/4")
35	87388639	1	HOSE, 1909 mm (75")
36	700-165	1	CONNECTOR, HYD., 11/16"-16 ORFS x M12 x 1.5 ORB, Inc. 13 & 37
37	637-63093	1	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
38	300209A1	1	VALVE, Shuttle, Inc. 40
39	412086A1	1	HOSE ASSY., Charge Pump to Charge Return Tube
40	201-105	1	CONNECTOR, HYD., 1 7/16"-12 ORFS x 1 5/16"-12 ORB, 1-5/16" Or x 1-7/16" fc sl, Inc. 14 & 41
41	237-6016	1	O-RING, 16-1, 90 Duro, 1.171" ID x .118" Thk,
42	515-24349	1	CLAMP, 1 3/8", Insul, 7/16" Bolt,
43	895-11008	5	WASHER, M8 x 16 x 1.6,
44	627-8025	1	BOLT, Hex, M8 x 25, 10.9,

ссылка	Номер детали	Кол-во	Описание
45	87357608	1	HOSE,
46	515-23254	1	CLAMP, 1", Insul, 3/8" Bolt,
47	829-1408	1	NUT, M8, Cl 10,
48	87442925	1	VALVE, CONTROL, Priority / EHPS, See Figure: 08-12, BSN Z7F202170
48	87585897	1	VALVE, HYDRAULIC, Priority / EHPS. See Figure: 08-12, ASN Z7F202170
49	701-319	1	ELBOW, 90є, 11/16"-16 ORFS x 11/16"-16 Fem Sw, 90
50	238-6012	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
51	1957867C1	1	SCREEN, FILTER, with O-Rings
52	335104A2	1	HOSE ASSY., 925 mm (36")
53	700-304	1	ELBOW, 90є, 11/16"-18 ORFS x M14 x 1.5 ORB, Inc. 10 & 26, ASN Z7F202275
54	87565929	1	TUBE, Diagnostic Priority, ASN Z7F202275
55	701-909	1	NUT, LOCK, 11/16"-16, Blkhd, , ASN Z7F202275
56	190119A1	1	COUPLING, Diagnostic, ASN Z7F202275

08-21 HIGH OUTPUT HYDRAULICS - PUMP LUBRICATION, POWER SHIFT CIRCUIT



TJ430 TRACTOR (1/06-) - Hydraulic System

08-21 HIGH OUTPUT HYDRAULICS - PUMP LUBRICATION, POWER SHIFT CIRCUIT

ссылка	Номер детали	Кол-во	Описание
1	9824055	2	CONNECTOR, HYD., 1-7/16 fc x 1-5/16 Or, Inc. 2, 3
2	9824050	5	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
3	167268	3	O-RING, 16-1, 90 Duro, 1.171" ID x .116" Thk,
4	9625546	1	CAP, 11/16"-16 ORFS,
5	413814A1	1	TUBE ASSY.,
6	515-23206	2	CLAMP, 13/16", Insul, 3/8" Bolt,
7	86637669	1	ELBOW, 90є, 1"-14 x 1 1/16"-12, Adj, ORFS, 90, 1 fc sl x 1-1/16 orb, Inc. 3, 9
8	87319946	1	VALVE, Destroke Pump
9	238-6012	11	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
10	363769A1	1	HOSE ASSY., 700 mm (27-1/2 in)
11	87357608	1	HOSE, 1625 mm (64 in)to Right Front Filter
12	515-23254	1	CLAMP, 1", Insul, 3/8" Bolt,
13	86624184	6	WASHER, M8 x 16 x 1.6,
14	829-1408	1	NUT, M8, Cl 10,
15	335103A1	1	HOSE ASSY., 1525 mm (60 in), Charge Pump to Charge Tube
16	86992232	1	BLOCK, Pump, BSN Z7F202275
16	87565931	1	BLOCK, Pump, ASN Z7F202275
17	86637942	4	SCREW, Hex Soc Hd, 1/2"-13 x 2 1/2",
18	700-165	1	CONNECTOR, HYD., 11/16"-16 ORFS x M12 x 1.5 ORB, Inc. 21 & 22
19	86624181	4	WASHER, M6,
20	238-6222	1	O-RING, -222, 90 Duro, 1.484" ID x .139" Thk,
21	637-63093	1	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
22	9992298	2	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
23	9840589	1	O-RING, -029, 90 Duro, 1.489" ID x .070" Thk,
24	87441879	1	HOSE ASSY.,
25	405572A1	1	TUBE ASSY.,
26	86637769	1	O-RING, -228, 90 Duro, 2.234" ID x .139" Thk,
27	86624194	8	CLAMP, HOSE, #36, 1.81/2.75 Type F Worm, 1-13/16 - 2-3/4
28	435454A1	2	HOSE, 102 mm (4 in), Cut From : 443069A1
29	413812A1	1	TUBE,
30	511284	1	O-RING, -232, 70 Duro, 2.734" ID x .139" Thk,
31	87441950	1	HOSE ASSY., 724 mm (28-1/2"), to Destroke Valve Drain Port
32	87307313	1	TUBE ASSY.,
33	435413A1	2	HOSE, 114 mm (4-1/2 in), Cut From : 443067A1
34	335104A2	1	HOSE ASSY., 925 mm (36 in)
35	87434311	1	HOSE ASSY., 535 mm (21"), to Destroke Valve Sense Port
36	9840543	2	ELBOW, 90є, 11/16"-16 x 9/16"-18 Adj, ORFS, 90, 9/16" or x 11/16" fc sl, Inc. 9 & 39
37	300209A1	1	VALVE, Shuttle
38	87441760	1	TUBE ASSY., Piston Pump Supply, Inc. 9 & 67
39	9617873	2	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
40	87545498	1	VALVE, CHECK,
41	84989413	1	ELBOW, 90є, 1 7/16"-12 ORFS x 1 7/16"-12 Fem Sw, Inc. 42
42	9824051	1	O-RING, -025, 90 Duro, 1.176" ID x .070" Thk,
	178889A1	1	FITTING, Diagnostic, Inc. 43 - 44
43	86502604	1	DUST CAP,

ссылка	Номер детали	Кол-во	Описание
44	NSS	1	NOT SERVICED SEPARATELY, Fitting, Diagnostic, Inc. 45
45	86639042	3	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
46	358968A1	1	COUPLING, M18 orb x 1,5, Diagnostic, Inc. 47
47	86639043	1	O-RING, 15.3 ID x 2.2
48	700-102	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 22 & 47
49	701-320	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Inc. 22, BSN Z7F202275
50	87550213	1	FITTING, 45, Special, Inc. 2 & 22, ASN Z7F202275
51	86556136	2	BOLT, Hex, M6 x 50, 10.9,
52	700-318	2	ELBOW, 45є, 1 7/16"-12 ORFS x M33 x 2 ORB, Inc. 2 & 20
53	86500688	2	NUT, M6, Cl 10,
54	396490A1	2	U-BOLT, M8
55	87441813	1	HOSE ASSY., 1403 mm (55-1/4")
56	87388638	1	HOSE, Destroke Outlet to Piston Pump Compenstator
57	87434200	1	BRACKET,
58	87442925	1	VALVE, CONTROL, Priority / EHPS, See Figure: 08-12, BSN Z7F202170
58	87585897	1	VALVE, HYDRAULIC, Priority / EHPS. See Figure: 08-12, ASN Z7F202170
59	412250	4	NUT, LOCK, M8 x 1.25, Cl 8,
60	9993143	2	CONNECTOR, HYD., 11/16"-16 ORFS x 9/16"-18 ORB, 9/16" or x 11/16" fc sl, Inc. 9, 39
61	86500688	2	NUT, M6, Cl 10,
62	701-319	1	ELBOW, 90є, 11/16"-16 ORFS x 11/16"-16 Fem Sw, 90
63	238-6012	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
64	1957867C1	1	SCREEN, FILTER, with O-Ring, ASN Z7F202275
65	700-101	1	CONNECTOR, HYD., 11/16"-16 ORFS x M14 x 1.5 ORB, Inc. 9 & 45, ASN Z7F202275
66	87565927	1	TUBE, Diagnostic Priority, ASN Z7F202275
67	701-909	1	NUT, LOCK, 11/16"-16, Blkhd, , ASN Z7F202275
68	190119A1	1	COUPLING, Diagnostic, ASN Z7F202275
69	87441927	1	HOSE ASSY., 622 mm (24-1/2 in)

08-22 HIGH OUTPUT HYDRAULICS - PUMP MOUNTING



TJ430 TRACTOR (1/06-) - Hydraulic System

08-22 HIGH OUTPUT HYDRAULICS - PUMP MOUNTING

ссылка	Номер детали	Кол-во	Описание
1	87308196	1	PUMP, 100 cc, Piston, See Figure: 08-23
2	496-81022	2	WASHER, .656" x 1.250" x .239" Thk
3	627-16050	2	BOLT, Hex, M16 x 50, 10.9,
4	510828	1	O-RING, -250, 70 Duro, 4.984" ID x .139" Thk,
5	87427941	1	PUMP, HYDRAULIC, Gear, See Figure: 08-24
6	A14141	2	FLANGE, Split
7	88904	8	BOLT, Hex, 1/2"-13 x 1 1/2", G8, Full Thd,
8	L14386	2	CLAMP, Split
9	43260	2	BOLT, Hex, M12 x 30, 10.9,
10	87419159	1	PLATE, Lower
11	87419459	1	BRACKET, , Power Shift Transmission
11	87419160	1	BRACKET, , Manual Shift Transmission
12	87362	8	WASHER, 5/16" SAE,
13	86528579	4	NUT, LOCK, M8 x 1.25, Cl 10,
14	43235	4	BOLT, Hex, M8 x 30, 10.9,
15	L111928	2	CLAMP,
16	436514A1	1	O-RING,
17	201-125	1	CONNECTOR, HYD., 11/16"-16 ORFS x 7/16"-20 ORB, 1/4" Or x 3/8" fc sl, Inc. 18 & 19
18	237-6004	1	O-RING, 4-1, 90 Duro, .351" ID x .072" Thk,
19	238-6012	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,

08-23 HIGH OUTPUT HYDRAULICS - PISTON PUMP ASSY



08-23 HIGH OUTPUT HYDRAULICS - PISTON PUMP ASSY

ссылка	Номер детали	Кол-во	Описание
	87308196	1	PUMP, 100 cc, Inc. 1 - 20
1	NSS	1	NOT SERVICED SEPARATELY, Cylinder Assy
2	NSS	1	NOT SERVICED SEPARATELY, Piston Assy
3	NSS	1	NOT SERVICED SEPARATELY, Housing
4	NSS	1	NOT SERVICED SEPARATELY, Block
5	NSS	1	NOT SERVICED SEPARATELY, Plate, Swash
6	NSS	1	NOT SERVICED SEPARATELY, Shaft
7	NSS	1	NOT SERVICED SEPARATELY, Spacer
8	NSS	1	NOT SERVICED SEPARATELY, Bearing, Roller
9	NSS	1	NOT SERVICED SEPARATELY, Bearing, Roller
10	NSS	2	NOT SERVICED SEPARATELY, Bearing, Support
11	NSS	1	NOT SERVICED SEPARATELY, Seal
12	NSS	1	NOT SERVICED SEPARATELY, O-Ring
13	NSS	4	NOT SERVICED SEPARATELY, O-Ring
14	NSS	1	NOT SERVICED SEPARATELY, Ring, Retaining
15	NSS	4	NOT SERVICED SEPARATELY, Screw
16	NSS	1	NOT SERVICED SEPARATELY, 1-1/16"-12 Or
17	NSS	1	NOT SERVICED SEPARATELY, Pin, Dowel
18	NSS	2	NOT SERVICED SEPARATELY, Plug
19	NSS	1	NOT SERVICED SEPARATELY, Coupling
20	87308198	1	COMPENSATOR, Compensator
21	436514A1	1	O-RING,
	388292A1	1	KIT, SEALS, Inc. 11 - 13, 21

08-24 GEAR PUMP ASSY



08-24 GEAR PUMP ASSY

ссылка	Номер детали	Кол-во	Описание
	87427941	1	PUMP, HYDRAULIC, Gear, Inc. 1 - 26
1	NSS	1	NOT SERVICED SEPARATELY, Housing, Rear
2	NSS	8	NOT SERVICED SEPARATELY, Screw
3	NSS	8	NOT SERVICED SEPARATELY, Washer
4	NSS	1	NOT SERVICED SEPARATELY, Seal
5	NSS	1	NOT SERVICED SEPARATELY, Pin, Dowel
6	NSS	2	NOT SERVICED SEPARATELY, Gear
7	NSS	1	NOT SERVICED SEPARATELY, Housing, Gear
8	NSS	2	NOT SERVICED SEPARATELY, Plate, Thrust
9	NSS	1	NOT SERVICED SEPARATELY, Shaft, Gear
10	NSS	1	NOT SERVICED SEPARATELY, Shaft, Gear
11	NSS	2	NOT SERVICED SEPARATELY, Seal
	87427777	1	VALVE KIT, 153 psi, Inc. 12 - 15
12	NSS	1	NOT SERVICED SEPARATELY, Plug
13	NSS	1	NOT SERVICED SEPARATELY, Spring
14	NSS	1	NOT SERVICED SEPARATELY, Poppet, Valve
15	NSS	1	NOT SERVICED SEPARATELY, Seat
16	NSS	1	NOT SERVICED SEPARATELY, Shim
	245847A1	1	PACKAGE, Pressure Relief, 550 psi, Inc. 17 - 20, 26
17	NSS	1	NOT SERVICED SEPARATELY, Spring
18	NSS	1	NOT SERVICED SEPARATELY, Plunger
19	NSS	1	NOT SERVICED SEPARATELY, Poppet, Valve
20	NSS	1	NOT SERVICED SEPARATELY, Seat
21	NSS	2	NOT SERVICED SEPARATELY, Pin, Dowel
22	NSS	1	NOT SERVICED SEPARATELY, Seal
23	NSS	1	NOT SERVICED SEPARATELY, Housing, Front
24	NSS	2	NOT SERVICED SEPARATELY, Seal, Channel
25	NSS	2	NOT SERVICED SEPARATELY, Seal, Backup
26	NSS	1	NOT SERVICED SEPARATELY, Plug
	334450A1	1	KIT, SEALS, Seals, Repair, Inc. 11, 20, 22, 24, 25

08-25 HYDRAULIC REMOTE HOSES ELECTRONIC REMOTE



TJ430 TRACTOR (1/06-) - Hydraulic System

08-25 HYDRAULIC REMOTE HOSES ELECTRONIC REMOTE

ссылка	Номер детали	Кол-во	Описание
1	87385879	1	BRACKET, Hoses
2	405517A1	1	BRACKET,
3	87388511	1	BRACKET,
4	405520A1	1	PLATE,
5	362419A1	1	CLAMP,
6	86624184	10	WASHER, M8 x 16 x 1.6,
7	43362	6	NUT, M8, Cl 10,
8	86639040	2	BOLT, Hex, M8 x 100, 10.9, Full Thd,
9	87306262	1	BRACKET,
10	86624176	10	WASHER, M10 x 20 x 2,
11	86500689	8	NUT, M10, Cl 10,
12	360134A2	1	HOSE ASSY., 3238 mm (127 in)
13	515-23206	1	CLAMP, 13/16", Insul, 3/8" Bolt,
14	87539204	1	HOSE, Regulator to Auxiliary Pump Supply, 3323 mm (131")
15	87394490	1	HOSE, Priority Valve to Auxiliary Load Sense, 4384 mm (172-1/2")
16	87438667	1	HOSE, from Priority Valve to Auxiliary Inlet, 3300 mm (130")
17	43127	7	BOLT, Hex, M8 x 25, 8.8,
18	405521A1	1	SHIELD,
19	86594406	1	CLAMP, 5/8", Insul, 3/8" Bolt,
20	86624177	4	WASHER, M12 x 24 x 2.5,
21	86625263	5	WASHER, M8 x 20 x 1.6,
22	701-908	1	NUT, LOCK, 1 7/16"-12, ORFS Blkhd,
23	404604A1	1	BRACKET, , Without Power Takeoff
24	86625266	4	WASHER, M17.5 x 30 x 4, HT,
25	827-16100	4	BOLT, Hex, M16 x 100, 10.9,
26	392530	4	NUT, M16, Cl 10,
27	387840A1	2	SLEEVE, 610 mm (24 in)
28	L18331	6	STRAP, CABLE,
29	S120426	1	SLEEVE,
30	86580180	1	ELBOW, 90є, 1 7/16"-12 ORFS x M33 x 2 ORB, Includes 34, 44
31	86625003	1	BOLT, Hex, M8 x 50, 10.9,
32	9824050	4	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
33	86579671	1	CONNECTOR, HYD., 11/16"-16 ORFS x M14 x 1.5 ORB, Inc. 34, 35
34	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
35	9993141	3	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
36	86580177	1	CONNECTOR, HYD., 11/16"-16 ORFS x M12 x 1.5 ORB, Includes 37, 35
37	86642448	1	O-RING, Cl 6, 9.3MM ID x 2.2 Thk,
38	87438486	1	TUBE ASSY., EF Outlet
39	86580179	2	CONNECTOR, HYD., 1 7/16"-12 ORFS x M22 x 2 ORB, Includes 40, 32
40	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
41	701-319	1	ELBOW, 90є, 11/16"-16 ORFS x 11/16"-16 Fem Sw, Inc. 35
42	311834A1	1	ELBOW, 90, 1-7/16 fc sl x swl, Inc. 32
43	832-10410	2	NUT, LOCK, M10 x 1.5, Cl 8,
44	238-6014	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
45	86639095	1	NUT, TUBE, 1"-14, ORFS,

08-25 HYDRAULIC REMOTE HOSES ELECTRONIC REMOTE

ссылка	Номер детали	Кол-во	Описание
46	86622968	1	REDUCER, 13/16"-16 Male x 1"-14 Fem, ORFS, 5/8 fcsl x 1/2; Inc. 47
47	9992069	1	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
48	86589753	1	PLUG, M18 x 15, Inc. 49
49	86639043	1	O-RING, 15.3 ID x 2.2
50	86625252	4	WASHER, M10 x 21.5 x 2.5, HT,
51	371838A1	1	SPACER,
52	87540204	1	BRACKET, Support

08-26 HYDRAULIC REMOTE CONTROL VALVE



TJ430 TRACTOR (1/06-) - Hydraulic System

08-26 HYDRAULIC REMOTE CONTROL VALVE

ссылка	Номер детали	Кол-во	Описание
1	355788	2	BOLT, Hex, M10 x 70, 10.9,
2	86625252	2	WASHER, M10 x 21.5 x 2.5, HT,
3	86514720	2	NUT, LOCK, M10 x 1.5
4	9827902	2	CLAMP, 1", Insul, 3/8" Bolt,
5	9515003	2	BOLT, Hex, M10 x 30, 10.9, Full Thd,
6	86500689	2	NUT, M10, Cl 10,
7	86579689	1	ELBOW, 90ε, 13/16"-18 ORFS x M14 x 1.5 ORB, Inc. 8, 9
8	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
9	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
10	435437A1	2	STRAP, CABLE, Tie
11	320374A1	AR	HOSE, Drain, 889 mm (35 in), Cut From : 443078A1
12	1289481C1	AR	ELBOW, 90, 1/4 stem x 1/8 PT
13	221576A1	1	PLUG, Hex Soc, M14 x 1.5, ORB, Inc. 14
14	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
15	86624176	4	WASHER, M10 x 20 x 2,

08-27 MANIFOLD VALVE ASSY



TJ430 TRACTOR (1/06-) - Hydraulic System

08-27 MANIFOLD VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
	87317169	1	VALVE, Inc. 1 - 21
1	NSS	1	NOT SERVICED SEPARATELY, Valve, Intake, Left-Hand
2	277634	4	O-RING, -117, 90 Duro, .799" ID x .103" Thk,
3	272344	4	O-RING, -112, 90 Duro, .487" ID x .103" Thk,
4	86505727	2	O-RING, -211, 70 Duro, .796" ID x .139" Thk,
5	NSS	1	NOT SERVICED SEPARATELY, Valve, Connector
6	NSS	1	NOT SERVICED SEPARATELY, Valve, Outlet, Right-Hand
7	338681A1	2	BRACKET,
8	86639228	4	BOLT, Hex, M12 x 65, 10.9,
9	86508619	2	BOLT, Hex, M10 x 60, 10.9,
10	86639266	1	SCREW, Hex Soc Hd, M10 x 70, 12.9,
11	221579A1	1	PLUG, Hex Soc, M22 x 1.5, ORB, Includes 23
12	221578A1	10	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 13
13	86639043	10	O-RING, 15,3 ID x 2,2
14	86514720	2	NUT, LOCK, M10 x 1.5
15	86625252	2	WASHER, M10 x 21.5 x 2.5, HT,
16	221576A1	7	PLUG, Hex Soc, M14 x 1.5, ORB, Includes 17
17	86639042	7	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
18	221580A1	2	PLUG, Hex Soc, M27 x 2, ORB, Includes 19
19	86639045	2	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
20	353828A1	13	PLUG, Expansion
21	334923A1	1	SCREEN,
22	358968A1	1	COUPLING, M18 orb x 1,5, Diagnostic, If Used, Inc. 13
23	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
24	337563	4	BOLT, Hex, M12 x 40, 10.9, Full Thd,
25	86625255	4	WASHER, M13.5 x 24.5 x 3, HT,
26	412126	4	NUT, LOCK, M12 x 1.75, Cl 8,
27	86508619	2	BOLT, Hex, M10 x 60, 10.9,

08-28 REMOTE VALVE ASSY - ELECTRONIC CONTROLLED



08-28 REMOTE VALVE ASSY - ELECTRONIC CONTROLLED

ссылка	Номер детали	Кол-во	Описание
1	87317169	1	VALVE, See Figure: 08-27
2	277634	AR	O-RING, -117, 90 Duro, .799" ID x .103" Thk,
3	272344	AR	O-RING, -112, 90 Duro, .487" ID x .103" Thk,
4	435375A1	AR	COUPLING, BREAK AWAY, See Figure: 08-29
5	9846677	AR	BOLT, Hex, M10 x 25, 10.9, Full Thd,
6	86556139	AR	BOLT, Hex, M10 x 110, 10.9,
7	86639227	AR	BOLT, Hex, M10 x 160, 10.9,
8	9501756	AR	BOLT, Hex, M12 x 110, 10.9,
9	86837481	AR	SCREW, Hex Soc Hd, M12 x 150, 12.9,
10	86637724	5	PLUG, Hex Soc, 1/8"-27 NPTF, Hex Socket, 1/8 PT
11	292295A3	AR	VALVE, Main, Four and Five Stack, See Figure: 08-30
12	393972A3	1	VALVE, Auxiliary, LH, See Figure: 08-30
13	319131A4	1	VALVE, Hitch, See Figure: 08-31
14	337563	AR	BOLT, Hex, M12 x 40, 10.9, Full Thd,
15	86625255	4	WASHER, M13.5 x 24.5 x 3, HT,
16	412126	4	NUT, LOCK, M12 x 1.75, Cl 8,
17	393973A3	1	VALVE, Auxiliary, RH, See Figure: 08-30

08-29 COUPLER VALVE ASSY



TJ430 TRACTOR (1/06-) - Hydraulic System

08-29 COUPLER VALVE ASSY

ссылка	Номер детали	Кол-во	Описание
	435375A1	1	COUPLING, BREAK AWAY, Inc. 1 - 7
1	NSS	1	NOT SERVICED SEPARATELY, Body
2	240969A1	2	SEAL, Dust
3	427104A1	4	SCREW,
4	240973A2	2	SCREW, With Sleeve and Washer
5	292326A1	2	PLATE, Cover
6	240974A2	2	COVER, DOOR, Dust
7	321623A2	2	COUPLING, QUICK, MALE,
	345193A1	1	KIT, SEALS, Coupler, Inc. 8 - 10
8	14454480	4	O-RING, -027, 70 Duro, 1.301" ID x .070" Thk,
9	93332C1	4	SEAL ASSY.,
10	345192A1	2	SEAL,
11	93330C1	2	SPRING, VALVE,
12	86013223	2	RING, SNAP, 1.625", Int, #162,
13	367755A1	2	RETAINER, Retaining
14	86642422	1	PLUG, Hex Socket, 1/4 PT

08-30 MAIN AND AUXILIARY VALVE ASSY - ELECTRONIC REMOTE



08-30 MAIN AND AUXILIARY VALVE ASSY - ELECTRONIC REMOTE

ссылка	Номер детали	Кол-во	Описание
	292295A3	1	VALVE, Main, Inc. 1 - 46
	393972A3	1	VALVE, Auxiliary, LH, Inc. 1 - 46
	393973A3	1	VALVE, RH, Inc. 1 - 46
1	NSS	1	NOT SERVICED SEPARATELY, Body
	1542563C1	1	VALVE, CHECK, Logic, Inc. 2 - 6
2	NSS	1	NOT SERVICED SEPARATELY, Plug
3	1543329C1	1	POPPET, VALVE,
4	NSS	1	NOT SERVICED SEPARATELY, Spring
5	G108723	1	RING,
6	165212	1	O-RING, -015, 90 Duro, .551" ID x .070" Thk,
7	9625178	1	PLUG, Hex Soc, 9/16"-18 ORB, 3/8 orb, Inc. 8
8	167266	1	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk,
9	292321A2	1	SPOOL,
10	301973A1	1	SPRING,
11	86625138	1	PLUG, Hex Soc, 7/8"-14 ORB, 5/8 orb, Includes 12
12	167269	1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,
	336278A3	1	VALVE SECTION, HYD, EH Pilot Block, Inc. 13 - 20
	392403A2	1	VALVE, PILOT, EH Block, Inc. 14 - 22
13	NSS	1	NOT SERVICED SEPARATELY, Body
14	NSS	1	NOT SERVICED SEPARATELY, Body
15	278506A2	1	VALVE, SOLENOID, Proportional
16	353830A1	1	GUARD,
17	86639307	2	WASHER, Lock, 4 mm
18	86624126	2	SCREW, Hex Soc Hd, M4 x 16, 8.8,
19	86629543	1	O-RING, -012, 70 Duro, .364" ID x .070" Thk,
20	9672548	1	O-RING, -011, 70 Duro, .301" ID x .070" Thk,
21	86639300	2	SCREW, Socket, M6 x 75; 8.8
22	372228A1	1	SEAL, Kit
23	87410063	1	SPOOL,
24	86632547	1	PLUG, Hex Soc, 5/16"-24 ORB, Socket, 1/8 orb, Includes 25
25	167269	1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,
26	9672549	2	O-RING, -120, 70 Duro, .987" ID x .103" Thk,
27	436518A1	2	WASHER, Centering
28	301969A2	2	SPRING, Return, Outer
	1957907C1	1	PISTON ASSY., Load Check, Inc. 29 - 31
29	NSS	1	NOT SERVICED SEPARATELY, Piston
30	NSS	1	NOT SERVICED SEPARATELY, Ring, Snap
31	NSS	1	NOT SERVICED SEPARATELY, Washer
	278550A2	1	VALVE, CHECK, Load, Inc. 32 - 44
32	9992069	1	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
33	G103862	1	RING,
34	G108723	1	RING,
35	165212	1	O-RING, -015, 90 Duro, .551" ID x .070" Thk,
36	167269	2	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,
37	G108727	1	RING, BACK-UP,

08-30 MAIN AND AUXILIARY VALVE ASSY - ELECTRONIC REMOTE

ссылка	Номер детали	Кол-во	Описание
38	NSS	1	NOT SERVICED SEPARATELY, Cap
39	NSS	1	NOT SERVICED SEPARATELY, Poppet
40	NSS	1	NOT SERVICED SEPARATELY, Body, Valve
41	NSS	1	NOT SERVICED SEPARATELY, Spring
42	1957964C1	1	RETAINER, Spring
43	NSS	1	NOT SERVICED SEPARATELY, Spring
44	NSS	1	NOT SERVICED SEPARATELY, Poppet
45	86632547	1	PLUG, Hex Soc, 5/16"-24 ORB, Soc. Hd, 1/8 or, Includes 46
46	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,

08-31 HITCH VALVE ASSEMBLY - ELECTRONIC REMOTE



08-31 HITCH VALVE ASSEMBLY - ELECTRONIC REMOTE

ссылка	Номер детали	Кол-во	Описание
	319131A4	1	VALVE, Inc. 1 - 34
1	NSS	1	NOT SERVICED SEPARATELY, Housing
2	NSS	1	NOT SERVICED SEPARATELY, Spool
3	86590562	2	PLUG, Hex Soc, 3/4"-16 ORB, Hex, 3/4 Or, Inc. 4
4	128825	2	O-RING, 8-1, 90 Duro, .644" ID x .087" Thk,
5	188104A1	2	SPOOL, Pilot
6	188116A1	2	PIN,
7	188117A1	2	TUBE, Override
8	NSS	2	NOT SERVICED SEPARATELY, Coil
9	188106A1	2	NUT,
10	86637957	1	BALL, 20mm Dia, 20 mm, gr 28
11	188114A1	1	SPRING, Compression
12	373760A1	1	PLUG,
13	167269	2	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk,
14	NSS	1	NOT SERVICED SEPARATELY, Poppet Valve
15	NSS	1	NOT SERVICED SEPARATELY, Stem, Servo
16	9672929	1	O-RING, .989" ID x .070" Thk
17	129740	1	O-RING, -023, 70 Duro, 1.051" ID x .070" Thk,
18	118111A1	1	TUBE,
19	9825770	1	O-RING, -011, 90 Duro, .301" ID x .070" Thk,
20	373767A1	1	RING, Backup
21	NSS	1	NOT SERVICED SEPARATELY, Seat
22	NSS	1	NOT SERVICED SEPARATELY, Valve
23	NSS	1	NOT SERVICED SEPARATELY, Compression
24	NSS	1	NOT SERVICED SEPARATELY, Plug
25	130282	1	O-RING, -014, 70 Duro, .489" ID x .070" Thk,
26	165217	1	O-RING, -142, 90 Duro, 2.362" ID x .103" Thk,
27	277634	3	O-RING, -117, 90 Duro, .799" ID x .103" Thk,
28	272344	5	O-RING, -112, 90 Duro, .487" ID x .103" Thk,
29	373761A1	1	PLUG,
30	165202	1	O-RING, 4-1, 90 Duro, .351" ID x .072" Thk,
31	86513328	2	O-RING, 3-1, .301" ID x .064" Thk,
32	86529630	2	PLUG, Hex Soc, 3/8"-24 ORB,
33	86513328	2	O-RING, 3-1, .301" ID x .064" Thk,
34	373758A1	1	VALVE, Check, Load Sense
35	373756A1	1	KIT, Relief
36	373757A1	1	KIT, Seal
37	243254A1	2	KIT, Solenoid
38	87430152	1	KIT, SERVICE, Meter Out
39	87423671	1	KIT, SPRING, Hitch Valve, Load Drop Check

08-32 MOTOR RETURN



TJ430 TRACTOR (1/06-) - Hydraulic System

08-32 MOTOR RETURN

ссылка	Номер детали	Кол-во	Описание
1	298291A1	1	BODY, Hydr., 3/4 in, Auxiliary, Main Return
2	334216A1	1	CAP, Dust
3	86637979	1	CLAMP, 13/16", Insul, 3/8" Bolt,
4	R54363	1	CLAMP,
5	347755A1	1	COUPLING, Hydr., 3/4 Male x 1-1/16 Female orb, Inc. 6
6	167266	1	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk,
7	385358A1	1	COUPLING, Hydr., 1/2 Male x 3/8 Female orb, Inc. 15
8	385357A1	1	COUPLING, Hydr., Female
9	436249A1	1	FITTING, 3/4 or x 13/16 fc sl, Inc. 10 & 16
10	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
11	86639083	1	NUT, LOCK, 13/16"-16, ORFS Blkhd,
12	442477A2	1	BRACKET, Motor Drain
13	444060A1	1	HOSE ASSY., 2171 mm (85 in)
14	86598103	2	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
15	128825	1	O-RING, 8-1, 90 Duro, .644" ID x .087" Thk,
16	9617873	1	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
17	84989383	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, Inc. 19
18	86514261	1	TEE, 13/16"-16 ORFS x 13/16"-16 Fem Sw Run, Inc. 19
19	9992298	4	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
20	87335428	1	FITTING, Implement Coupler, 1/2"-14 nptf
20	87335430	1	FITTING, Implement Coupler, 3/4"-16 orb
20	87335431	1	FITTING, Implement Coupler, 7/8"-14 orb
	719517003	1	KIT, Motor Return / Power Beyond, Inc: 1 - 13, See Figure: 08-33


10
2
3
11
1
4
11
1
4
12

08-33 COUPLERS - POWER BEYOND

ссылка	Номер детали	Кол-во	Описание
1	298291A1	2	BODY, Hydr., 3/4 in, Auxiliary
2	294603A1	1	BODY, Hydr., 1/4 in, Auxiliary
3	334218A1	1	CAP, Dust
4	334216A1	2	CAP, Dust
5	347755A1	2	COUPLING, Hydr., 3/4 in, Inc. 10, Not Illustrated
6	167266	2	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk, Not Illustrated
7	347756A1	2	COUPLING, Hydr., 1/4 in, Inc. 8, Not Illustrated
8	9617873	2	O-RING, 6-1, 90 Duro, .468" ID x .078" Thk,
6	167266	2	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk, Not Illustrated
9	385358A1	1	COUPLING, Hydr., 3/8, Case Drain, Not Illustrated
10	86598101	1	O-RING, Cl 6, 15.3MM ID x 2.2 Thk,
11	86598103	2	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
12	87335428	1	FITTING, Implement Coupler, 1/2"-14 nptf
12	87335430	1	FITTING, Implement Coupler, 3/4"-16 orb
12	87335431	1	FITTING, Implement Coupler, 7/8"-14 orb
	719517003	1	KIT, Motor Return / Power Beyond, Inc. 1 - 9, See Figure: 08-32

08-34 COUPLER MOUNTS - WITHOUT POWER TAKEOFF AND THREE POINT HITCH



08-34 COUPLER MOUNTS - WITHOUT POWER TAKEOFF AND THREE POINT HITCH

ссылка	Номер детали	Кол-во	Описание
1	404432A2	1	MOUNTING PARTS, Auxiliary Valve
2	86625260	4	WASHER, M20 x 37.5 x 4, HT,
3	9843612	4	BOLT, Hex, M20 x 100, 10.9,

08-35 THREE POINT HITCH HYDRAULICS - ELECTRONIC CONTROLLED HITCH SYSTEM



08-35 THREE POINT HITCH HYDRAULICS - ELECTRONIC CONTROLLED HITCH SYSTEM

ссылка	Номер детали	Кол-во	Описание
1	87304298	2	CYLINDER, See Figure: 08-36
2	86579702	1	TEE, 13/16"-16 ORFS x M18 x 1.5 ORB Run, Inc. 3, 4
3	9992298	2	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
4	86639043	1	O-RING, 15,3 ID x 2,2
5	86579691	4	ELBOW, 90є, 13/16"-18 ORFS x M18 x 1.5 ORB, Includes 6, 7
6	9992298	4	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
7	86639043	4	O-RING, 15,3 ID x 2,2
8	403207A1	1	TUBE ASSY.,
9	360496A1	2	HOSE ASSY., Cylinder Supply, 505 mm (20 in)
10	86639058	1	TEE, 13/16"-16 ORFS x M22 x 1.5 ORB Run, Inc. 11, 12
11	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
12	9992298	2	O-RING, -014, 90 Duro, .489" ID x .070" Thk, Pressure Line
13	86637979	4	CLAMP, 13/16", Insul, 3/8" Bolt, P-type
14	43232	1	SCREW,
15	86624184	5	WASHER, M8 x 16 x 1.6,
16	86579680	1	CONNECTOR, HYD., 1"-14 ORFS x M22 x 1.5 ORB, Includes 17, 18
17	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
18	9992069	1	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
19	87427995	1	HOSE ASSY., Return, 3540 mm (139 in)
20	394732A1	1	HOSE ASSY., Return, 1410 mm (55-1/2 in)
21	394733A1	1	HOSE ASSY., Pressure Line, 1397 mm (55 in)
22	9992069	1	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
23	D43839	1	CLAMP, 1-1/8" ID

08-36 CYLINDER ASSY - THREE POINT HITCH



TJ430 TRACTOR (1/06-) - Hydraulic System

08-36 CYLINDER ASSY - THREE POINT HITCH

ссылка	Номер детали	Кол-во	Описание
	87304295	1	CYLINDER, Three Point Hitch, Lift, Inc. 1 - 18
1	87378711	1	TUBE, Barrel
2	219-36	1	NIPPLE, LUBE, 45є, 1/8" NPT x 7/8" lg,
3	NSS	1	NOT SERVICED SEPARATELY, Nut, Lock, 1-1/4 NF
4	87378709	1	PISTON,
5	87378712	1	WASHER, Ring
6	NSS	1	NOT SERVICED SEPARATELY, Seal, Piston
7	NSS	2	NOT SERVICED SEPARATELY, Ring, Wear
8	NSS	1	NOT SERVICED SEPARATELY, O-Ring
9	NSS	1	NOT SERVICED SEPARATELY, Ring, Backup
10	NSS	1	NOT SERVICED SEPARATELY, O-Ring
11	NSS	1	NOT SERVICED SEPARATELY, O-Ring
12	87378710	1	COVER,
13	NSS	1	NOT SERVICED SEPARATELY, Seal
14	NSS	2	NOT SERVICED SEPARATELY, Wiper
15	87378708	1	ROD,
16	87378707	1	BUSHING,
17	NSS	1	NOT SERVICED SEPARATELY, Bearing, Wear
18	87378712	1	WASHER,
	87378692	1	KIT, Seal, Inc. 5 - 11, 13, 14

08-37 HYDRAULICS - MEGA FLOW CIRCUITRY



TJ430 TRACTOR (1/06-) - Hydraulic System

08-37 HYDRAULICS - MEGA FLOW CIRCUITRY

ссылка	Номер детали	Кол-во	Описание
1	407476A1	1	PUMP, HYDRAULIC, See Figure: 08-40
2	86900235	2	BOLT, Hex, M16 x 55, 10.9, Full Thd, , With Manual Shift Transmission
2	86508624	2	BOLT, Hex, M16 x 45, 10.9, , With Power Shift Transmission
3	86625266	2	WASHER, M17.5 x 30 x 4, HT,
4	414663A1	1	TUBE,
5	9824050	13	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
6	A12306	2	FLANGE, Split, 1
7	86529541	1	O-RING, -219, 90 Duro, 1.296" ID x .139" Thk,
8	414465A2	1	HOSE, 113-1/2" Lg
9	414429A2	1	CLAMP BRACKET,
10	414856A1	1	PLATE,
11	86639005	1	CLAMP, 5/8", Insul, 1/2" Bolt, 15.9 mm
12	379748	2	BOLT, Hex, M8 x 80, 10.9,
13	86624184	2	WASHER, M8 x 16 x 1.6,
14	86637769	1	O-RING, -228, 90 Duro, 2.234" ID x .139" Thk,
15	A14141	2	FLANGE, Split, 2
16	414077A1	1	TUBE,
17	414196A1	1	HOSE, 825 mm (32 in)
18	433047A2	1	BRACKET,
19	429384A1	2	CLAMP,
20	429414A1	1	PLATE, COVER,
21	86624182	2	WASHER, M6 x 18 x 1.6,
22	43228	2	BOLT, Hex, M6 x 80, 10.9,
23	414464A1	1	HOSE, 1626 mm (64 in)
24	419661A1	1	TUBE,
26	86580180	3	ELBOW, 90є, 1 7/16"-12 ORFS x M33 x 2 ORB, Includes 27, 28
25	86514261	1	TEE, 13/16"-16 ORFS x 13/16"-16 Fem Sw Run, Inc. 50
27	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
28	84989413	1	ELBOW, 90є, 1 7/16"-12 ORFS x 1 7/16"-12 Fem Sw, Inc. 5
29	419655A1	1	TUBE,
30	87341623	1	BRACKET, Filter
31	414219A1	6	FILTER, Hydraulic Oil, See Figure: 08-41
32	86624176	4	WASHER, M10 x 20 x 2,
33	9861444	2	BOLT, Hex, M10 x 20, 10.9, Full Thd,
34	9827902	1	CLAMP, 1", Insul, 3/8" Bolt,
34	86639003	1	CLAMP, 3/8", Insul, 7/16" Bolt, 9.5 mm
35	414854A1	1	HOSE, 1956 mm (77 in)
36	86637669	1	ELBOW, 90є, 1"-14 x 1 1/16"-12, Adj, ORFS, Inc. 37, 38
37	167266	1	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk,
38	9992069	2	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
39	431461A1	1	HOSE ASSY., 737 mm (29 in)
40	86642450	1	TEE, 1"-14 ORFS x 1"-14 Fem Sw Run, Inc. 38
41	9843615	1	TEE, 11/16"-16 ORFS x 11/16"-16 Fem Sw Run, Inc. 50
42	414855A1	1	HOSE, 2870 mm (113 in)
43	429941A2	1	TUBE,

ссылка	Номер детали	Кол-во	Описание
44	430536A1	1	TUBE,
45	86639054	1	ELBOW, 45є, 1 7/16"-12 ORFS x M33 x 2 ORB, Inc. 45, 46
46	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
47	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
48	1957867C1	1	SCREEN, FILTER, 1/4 orb x 3/8 fc sl, Inc. 49, 50
49	165202	1	O-RING, 4-1, 90 Duro, .351" ID x .072" Thk,
50	9993141	8	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
51	428078A1	1	ELBOW, 90, M14 orb, Inc. 47
52	334923A1	1	SCREEN,
53	84989392	1	ELBOW, 90є, 11/16"-16 ORFS x 11/16"-16 Fem Sw, Inc. 50
54	429943A2	1	TUBE,
55	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
56	445701A1	1	TUBE, HYD,
57	86579686	1	ELBOW, 90є, 11/16"-18 ORFS x M14 x 1.5 ORB, Inc. 5, 55
58	86579689	1	ELBOW, 90є, 13/16"-18 ORFS x M14 x 1.5 ORB, Includes 59, 60
59	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
60	9992298	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
61	419684A1	1	TUBE,
62	418816A2	1	TUBE ASSY.,

08-38 MEGA FLOW HYDRAULICS - AUXILIARY REMOTE MOUNTING



08-38 MEGA FLOW HYDRAULICS - AUXILIARY REMOTE MOUNTING

ссылка	Номер детали	Кол-во	Описание
1	429731A1	1	GUSSET, Support
2	86625255	5	WASHER, M13.5 x 24.5 x 3, HT,
3	337563	5	BOLT, Hex, M12 x 40, 10.9, Full Thd,
4	429730A2	1	BRACKET, Mounting
5	86624176	1	WASHER, M10 x 20 x 2,
6	398792	1	BOLT, Hex, M12 x 25, 10.9,
	411978A4	1	VALVE, HYDRAULIC, Two Section, Inc. 7 - 16
7	418456A4	1	MANIFOLD, Inlet / Outlet, See Figure: 08-39
8	393973A2	1	VALVE, Auxilary, Right-Hand, See Figure: 08-30
9	292295A3	1	VALVE, Auxilary, Main, See Figure: 08-30
	418704A2	2	COUPLING, Inc. 10, 11
10	440646A1	2	COUPLING, BREAK AWAY,
11	418705A1	1	COUPLING,
12	9846677	8	BOLT, Hex, M10 x 25, 10.9, Full Thd,
13	9501756	2	BOLT, Hex, M12 x 110, 10.9,
14	86556139	1	BOLT, Hex, M10 x 110, 10.9,
15	272344	12	O-RING, -112, 90 Duro, .487" ID x .103" Thk,
16	277634	12	O-RING, -117, 90 Duro, .799" ID x .103" Thk,
17	358968A1	1	COUPLING, Diagnostic
18	86598103	2	O-RING, CI 6, 23.6MM ID x 2.9 Thk,
19	298291A1	1	BODY, Coupler, Auxiliary, 3/4"
20	334216A1	5	CAP, Dust

08-39 MEGA FLOW HYDRAULIC MANFOLD ASSY



08-39 MEGA FLOW HYDRAULIC MANFOLD ASSY

ссылка	Номер детали	Кол-во	Описание
	418456A4	1	MANIFOLD, Inlet / Outlet, Inc. 1 - 13
1	NSS	1	NOT SERVICED SEPARATELY, Body
2	353828A1	2	PLUG, Expansion
3	221576A1	1	PLUG, Hex Soc, M14 x 1.5, ORB, Includes 4
4	86639042	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
5	221578A1	1	PLUG, Hex Soc, M18 x 1.5, ORB, Includes 6
6	86639043	1	O-RING, 15,3 ID x 2,2
7	221580A1	2	PLUG, Hex Soc, M27 x 2, ORB, Includes 8
8	86639045	1	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
9	221579A1	1	PLUG, Hex Soc, M22 x 1.5, ORB, Includes 10
10	86639044	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
11	431479A1	1	VALVE, CHECK,
12	334923A1	1	SCREEN,
13	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
14	221527A1	2	PLUG, Hex Soc, M33 x 2, ORB, Soc Hd, M33 or x 2, Inc. 14

08-40 MEGA FLOW HYDRAULIC PUMP ASSY



TJ430 TRACTOR (1/06-) - Hydraulic System

08-40 MEGA FLOW HYDRAULIC PUMP ASSY

ссылка	Номер детали	Кол-во	Описание
	407476A1	1	PUMP, HYDRAULIC, Inc. 1 - 22
1	NSS	1	NOT SERVICED SEPARATELY, Cylinder Assy
2	NSS	1	NOT SERVICED SEPARATELY, Piston Assy, Control
3	NSS	1	NOT SERVICED SEPARATELY, Housing
4	NSS	1	NOT SERVICED SEPARATELY, Block
5	NSS	1	NOT SERVICED SEPARATELY, Plate, Swash
6	NSS	1	NOT SERVICED SEPARATELY, Shaft
7	NSS	1	NOT SERVICED SEPARATELY, Washer
8	NSS	1	NOT SERVICED SEPARATELY, Spacer
9	NSS	1	NOT SERVICED SEPARATELY, Bearing, Roller
10	NSS	1	NOT SERVICED SEPARATELY, Bearing, Roller
11	NSS	2	NOT SERVICED SEPARATELY, Support
12	NSS	1	NOT SERVICED SEPARATELY, Seal
13	NSS	1	NOT SERVICED SEPARATELY, O-Ring
14	NSS	4	NOT SERVICED SEPARATELY, O-Ring
15	NSS	1	NOT SERVICED SEPARATELY, Ring, Snap
16	NSS	4	NOT SERVICED SEPARATELY, Screw
17	352875A2	1	VALVE, CONTROL,
18	NSS	1	NOT SERVICED SEPARATELY, Plug
19	NSS	1	NOT SERVICED SEPARATELY, O-Ring
20	NSS	1	NOT SERVICED SEPARATELY, Pin
21	NSS	2	NOT SERVICED SEPARATELY, Screw
22	430337A1	1	COUPLING, , With Manual Shift Transmission
22	432675A1	1	COUPLING, , With Power Shift Transmission
23	D53692	2	GASKET, , With Power Shift Transmission
24	86012300	1	O-RING, -256, 70 Duro, 5.734" ID x .139" Thk, , With Manual Shift Transmission
25	414192A1	1	FLANGE, Adapter, With Manual Shift Transmission
26	410995A1	3	O-RING, Control Valve
27	412596A1	4	SCREW,
28	388293A1	1	KIT, SEALS,
29	86991869	1	SPACER, , With Power Shift Transmission

08-41 OIL FILTER - MEGA FLOW HYDRAULICS



08-41 OIL FILTER - MEGA FLOW HYDRAULICS

ссылка	Номер детали	Кол-во	Описание
1	414219A1	1	FILTER, Inc. 2 - 6
2	NSS	1	NOT SERVICED SEPARATELY, Head
3	440086A1	1	INDICATOR, Restriction
4	86989735	1	FILTER, HYDRAULIC OIL, Inc. 5 - 6
5	NSS	1	NOT SERVICED SEPARATELY, Element
6	NSS	1	NOT SERVICED SEPARATELY, O-Ring

08-44 TRAILER BRAKES - HYDRAULIC



TJ430 TRACTOR (1/06-) - Hydraulic System

08-44 TRAILER BRAKES - HYDRAULIC

ссылка	Номер детали	Кол-во	Описание
1	87388358	1	VALVE SECTION, Trailer Brake / Priority, See Figure: 08-45
2	87418098	1	STUD, Tie, Rod
3	304951A1	1	NUT,
4	87430079	2	STUD, Tie, Rod
5	829-1312	2	NUT, M12 x 1.75, Cl 10,
6	700-304	1	ELBOW, 90є, 11/16"-18 ORFS x M14 x 1.5 ORB, Inc. 7 & 8
7	637-63113	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
8	238-6012	1	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
9	87346096	1	HOSE ASSY.,
10	238-6012	2	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
11	87342885	1	TUBE, HYD, Trailer Brake, RF
12	700-318	1	ELBOW, 45є, 1 7/16"-12 ORFS x M33 x 2 ORB, 45, Inc. 13 & 17
13	637-64296	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
14	515-2495	3	CLAMP, 3/8", Insul, 7/16" Bolt,
15	895-18010	4	WASHER, M10 x 18 x 1.6,
16	627-10020	3	BOLT, Hex, M10 x 20, 10.9, Full Thd,
17	238-6021	1	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
18	87346094	1	HOSE ASSY.,
19	87384904	1	BRACKET,
20	515-22254	1	CLAMP, 1", Insul, 5/16" Bolt,
21	895-11008	12	WASHER, M8 x 16 x 1.6,
22	627-8020	3	BOLT, Hex, M8 x 20, 10.9,
23	829-1408	7	NUT, M8, Cl 10,
24	238-6014	1	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
25	87342347	1	TUBE, HYD,
26	701-416	2	TEE, 13/16"-16 ORFS x 13/16"-16 Fem Sw Run, Inc. 27
27	238-6014	3	O-RING, -014, 90 Duro, .489" ID x .070" Thk,
28	700-102	1	CONNECTOR, HYD., 13/16"-16 ORFS x M18 x 1.5 ORB, Inc. 27 & 29
29	637-63153	1	O-RING, Cl 6, 15.3MM ID x 2.2 Thk,
30	700-305	1	ELBOW, 90є, 13/16"-18 ORFS x M18 x 1.5 ORB, 90
31	87367884	1	HOSE ASSY.,
32	515-23206	2	CLAMP, 13/16", Insul, 3/8" Bolt,
33	414937A1	2	SPACER,
34	827-8050	2	BOLT, Hex, M8 x 50, 10.9,
35	87371306	1	REMOTE S/D W/ KICK OUT AN, Quick Connect
36	701-320	1	ELBOW, 90є, 13/16"-16 ORFS x 13/16"-16 Fem Sw, 90

08-45 TRAILER BREAK, VALVE ASSY.



TJ430 TRACTOR (1/06-) - Hydraulic System

08-45 TRAILER BREAK, VALVE ASSY.

ссылка	Номер детали	Кол-во	Описание
1	87388358	1	VALVE SECTION, Trailer Brake, Inc. 2 - 24
2	NSS	1	NOT SERVICED SEPARATELY, Housing
3	87324557	1	PLUG, STOP,
4	87444752	1	BRAKE SPRING, Return
5	86988723	1	SPOOL, Inner
6	87324553	1	SPOOL,
7	87444751	1	BRAKE SPRING, Feathering Inner
8	87444750	1	BRAKE SPRING, Feathering Outer
9	NSS	AR	NOT SERVICED SEPARATELY, Shim
10	86988724	1	PISTON,
11	87454597	1	PLUG,
12	221580A1	1	PLUG, Hex Soc, M27 x 2, ORB, Includes 13
13	637-64236	1	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
14	NSS	1	NOT SERVICED SEPARATELY, Spool
15	408447A1	1	SPRING, COMPRESSION,
16	218-5212	1	PLUG, Hex Soc, 1 1/16"-12 ORB, Inc. 17
17	237-6012	1	O-RING, 12-1, 90 Duro, .924 ID x .118" Thk,
18	221576A1	1	PLUG, Hex Soc, M14 x 1.5, ORB, Includes 19
19	637-63113	1	O-RING, Cl 6, 11.3MM ID x 2.2 Thk,
20	221579A1	1	PLUG, Hex Soc, M22 x 1.5, ORB, Includes 21
21	637-63193	1	O-RING, Cl 6, 19.3MM ID x 2.2 Thk,
22	221527A1	1	PLUG, Hex Soc, M33 x 2, ORB, Inc. 23
23	637-64296	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
24	1542563C1	1	VALVE, CHECK, Logic


34
41
40
39
38
36
37
7
53
6
4
45
54
43
44
43
42
1
2
3
34
50
52
13
13
51
48
49
5
8
14
15
25
12
13
16
11
10
5
8
42
17
33
32
30
23
25
5
24
26
27
29
27
5
26
31
5
42
9
49
48
18
19
21
22
20
19
23
5
55
5
8
35
42
43
41
43
46
28
5
8
47
5
46
28

ссылка	Номер детали	Кол-во	Описание
1	407476A1	1	PUMP, HYDRAULIC, Implement, See Figure: 08-40
2	86900235	2	BOLT, Hex, M16 x 55, 10.9, Full Thd, , With Manual Shift Transmission
2	86508624	2	BOLT, Hex, M16 x 45, 10.9, , With Power Shift Transmission
3	86625266	2	WASHER, M17.5 x 30 x 4, HT,
4	87576188	1	TUBE, Pressure Pump
5	9824050	13	O-RING, -021, 90 Duro, .926" ID x .070" Thk,
6	A12306	2	FLANGE, Split, 1
7	86529541	1	O-RING, -219, 90 Duro, 1.296" ID x .139" Thk,
8	87381559	1	HOSE, 3323 mm (131")
9	87578492	1	CLAMP, HOSE,
10	414856A1	1	PLATE,
11	86639005	1	CLAMP, 5/8", Insul, 1/2" Bolt, 15.9 mm
12	379748	2	BOLT, Hex, M8 x 80, 10.9,
13	86624184	2	WASHER, M8 x 16 x 1.6,
14	86637769	1	O-RING, -228, 90 Duro, 2.234" ID x .139" Thk,
15	A14141	2	FLANGE, Split, 2
16	414077A1	1	TUBE,
17	414196A1	1	HOSE, 825 mm (32 in)
18	433047A2	1	BRACKET,
19	429384A1	2	CLAMP,
20	429414A1	1	PLATE, COVER,
21	86624182	2	WASHER, M6 x 18 x 1.6,
22	43228	2	BOLT, Hex, M6 x 80, 10.9,
23	414464A1	1	HOSE, 1626 mm (64 in)
24	419661A1	1	TUBE,
26	86580180	2	ELBOW, 90є, 1 7/16"-12 ORFS x M33 x 2 ORB, Includes 27, 28
27	86639046	1	O-RING, Cl 6, 29.6MM ID x 2.9 Thk,
28	700-313	2	ELBOW, 90є, 1 7/16"-12 ORFS x M27 x 2 ORB, Inc. 5 & 46
29	419655A1	1	TUBE,
30	87341623	1	BRACKET, Filter
31	414219A1	6	FILTER, Hydraulic Oil, See Figure: 08-41
32	86624176	2	WASHER, M10 x 20 x 2,
33	9861444	2	BOLT, Hex, M10 x 20, 10.9, Full Thd,
34	515-25254	1	CLAMP, 1", Insul, 1/2" Bolt,
35	87381560	1	HOSE, 2383 mm (94")
36	86637669	1	ELBOW, 90є, 1"-14 x 1 1/16"-12, Adj, ORFS, Inc. 37, 38
37	167266	1	O-RING, 12-1, 90 Duro, .924 ID x .116" Thk,
38	9992069	2	O-RING, -016, 90 Duro, .614" ID x .070" Thk,
39	431461A1	1	HOSE ASSY., 737 mm (29 in)
40	86642450	1	TEE, 1"-14 ORFS x 1"-14 Fem Sw Run, Inc. 38
41	9843615	1	TEE, 11/16"-16 ORFS x 11/16"-16 Fem Sw Run, Inc. 43
42	87572954	1	HOSE, 3138 mm (123-1/2")
43	9993141	8	O-RING, -012, 90 Duro, .364" ID x .070" Thk,
44	701-319	1	ELBOW, 90є, 11/16"-16 ORFS x 11/16"-16 Fem Sw,
45	237-6004	1	O-RING, 4-1, 90 Duro, .351" ID x .072" Thk,

ссылка	Номер детали	Кол-во	Описание
46	637-64236	2	O-RING, Cl 6, 23.6MM ID x 2.9 Thk,
47	701-339	1	ELBOW, 90є, 1 7/16"-12 ORFS x 1 7/16"-12 Fem Sw, Inc. 5
48	896-11012	4	WASHER, M13.5 x 24.5 x 3, HT,
49	514-842	4	BOLT, Hex, M12 x 1.25 x 25, 8.8, Full Thd,
50	87576505	1	BRACKET, Support
51	829-1408	1	NUT, M8, Cl 10,
52	627-8020	1	BOLT, Hex, M8 x 20, 10.9,
53	426-620	4	
54	1957867C1	1	SCREEN, FILTER, 1/4 orb x 3/8 fc sl, Inc. 49, 50
55	418816A2	1	TUBE ASSY.,

09-01 THREE POINT HITCH



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-01 THREE POINT HITCH

ссылка	Номер детали	Кол-во	Описание
1	403741A1	1	MOUNTING PARTS,
2	403743A1	1	ROCKSHAFT, See Figure: 09-02
3	435504A1	4	PIN,
4	86529976	4	BOLT, Hex, M16 x 35, 10.9,
5	896-15016	8	WASHER, M17.5 x 34 x 5, HT,
6	435501A1	8	SPACER,
7	403717A1	2	ARM, Draft
8	347641A1	1	PIN, RH
9	348061A1	1	PIN, LH, Not Illustrated
10	86639033	10	BOLT, Hex, M16 x 60, 10.9, Full Thd,
11	392530	4	NUT, M16, Cl 10,
12	86624980	4	BOLT, Hex, M12 x 65, 10.9,
13	NSS	1	NOT SERVICED SEPARATELY, Link Assy, Lift, RH, Not Illustrated, Order Component Parts, See Figure: 09-06
14	NSS	1	NOT SERVICED SEPARATELY, Link Assy, Lift, LH, Order Component Parts, See Figure: 09-06
15	403735A1	2	PLATE,
16	403744A1	1	BLOCK ASSY.,
17	403745A1	1	BLOCK ASSY.,
18	403746A1	1	BLOCK ASSY.,
19	403747A1	1	BLOCK ASSY.,
20	403748A1	2	BLOCK ASSY., Wear
21	322096A1	2	PIN,
22	A30338	2	PIN,
23	403204A1	2	PLATE,
24	9828248	2	BOLT, Hex, M16 x 60, 10.9,
25	86577946	2	BOLT, Hex, M16 x 80, 10.9,
26	86639319	28	WASHER, 26 x 44 x 5 mm
27	9780064	4	BOLT, Hex, M24 x 110, 10.9,
28	392530	2	NUT, M16, Cl 10,
29	86625260	6	WASHER, M20 x 37.5 x 4, HT,
30	259389A1	2	PLATE,
31	9848973	12	NUT, M24, Cl 10,
32	86639036	12	BOLT, Hex, M24 x 60, 10.9, Full Thd,
33	70-5967T1	2	SPACER,
34	86625266	2	WASHER, M17.5 x 30 x 4, HT,
35	86639032	2	BOLT, Hex, M16 x 25, 10.9, Full Thd,
36	9843590	4	BOLT, Hex, M20 x 50, 10.9,
37	87304295	2	CYLINDER, Lift, See Figure(s) : 08-36
38	86529976	2	BOLT, Hex, M16 x 35, 10.9,
39	435501A1	4	SPACER,
40	70-5973T2	2	PIN,
41	86625266	6	WASHER, M17.5 x 30 x 4, HT,
42	403204A1	2	PLATE, Retainer
43	321188A2	2	PIN,
44	896-11016	12	WASHER, M17.5 x 30 x 4, HT,

09-02 ROCKSHAFT



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-02 ROCKSHAFT

ссылка	Номер детали	Кол-во	Описание
	403743A1	1	ROCKSHAFT, Inc. 1 - 5, 12
1	NSS	1	NOT SERVICED SEPARATELY, Rockshaft
2	435500A1	4	BUSHING,
3	80719	2	NIPPLE, LUBE, 90є, 1/8" NPT x .84" lg,
4	328586A2	2	BUSHING,
5	612715	2	ELBOW, 45°, 1/8 PT x Fem PT
6	853764	2	CLAMP, 5/16", Insul, 5/16" Bolt,
7	43232	2	SCREW,
8	1339231C1	2	HOSE, 737 mm (29 in), Grease
9	86624184	2	WASHER, M8 x 16 x 1.6,
10	F53473	2	NUT, Special, 1/8 PT
11	87414	2	NIPPLE, LUBE, 1/4"-28 x .56" lg, Drive,
12	80717	2	NIPPLE, LUBE, 45є, 1/8" NPT x 7/8" lg,

09-03 THREE POINT HITCH - UPPER LINK, WITHOUT POWER TAKEOFF



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-03 THREE POINT HITCH - UPPER LINK, WITHOUT POWER TAKEOFF

сылка	Номер детали	Кол-во	Описание
1	403739A1	1	BRACKET,
2	309663A1	1	PIN,
3	403737A1	2	CLAMP,
4	86625260	12	WASHER, M20 x 37.5 x 4, HT,
5	9846950	6	BOLT, Hex, M20 x 90, 10.9,
6	259389A1	6	PLATE,
7	435501A1	2	SPACER,
8	86625266	2	WASHER, M17.5 x 30 x 4, HT,
9	86639032	2	BOLT, Hex, M16 x 25, 10.9, Full Thd,
10	9846949	6	BOLT, Hex, M20 x 80, 10.9,
11	NSS	1	NOT SERVICED SEPARATELY, Link, Upper, Order Component Parts, See Figure: 09-05
12	9847024	2	NUT, M20, Cl 10,
13	403736A1	1	PLATE,
14	86624176	4	WASHER, M10 x 20 x 2,
15	86500689	2	NUT, M10, Cl 10,
16	86624978	2	BOLT, Hex, M10 x 35, 10.9, Full Thd,
17	86639145	4	BOLT, Hex, M20 x 130, 10.9,

09-04 THREE POINT HITCH - UPPER LINK, WITH POWER TAKEOFF



09-04 THREE POINT HITCH - UPPER LINK, WITH POWER TAKEOFF

ссылка	Номер детали	Кол-во	Описание
1	403738A1	1	BRACKET,
2	9846949	6	BOLT, Hex, M20 x 80, 10.9,
3	86624994	8	BOLT, Hex, M20 x 230, 10.9,
4	NSS	1	NOT SERVICED SEPARATELY, Link, Upper, Order Component Parts, See Figure: 09-05
5	309663A1	1	PIN,
6	403737A1	2	CLAMP,
7	86625260	16	WASHER, M20 x 37.5 x 4, HT,
8	9846950	2	BOLT, Hex, M20 x 90, 10.9,
9	259389A1	2	PLATE,
10	435501A1	4	SPACER,
11	86625266	4	WASHER, M17.5 x 30 x 4, HT,
12	86639032	4	BOLT, Hex, M16 x 25, 10.9, Full Thd,
13	9847024	2	NUT, M20, Cl 10,
14	86639169	4	BOLT, Hex, M20 x 270, 10.9,

09-05 LINK ASSY - UPPER



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-05 LINK ASSY - UPPER

ссылка	Номер детали	Кол-во	Описание
1	403726A1	1	KNUCKLE ASSY.,
2	403731A1	1	LINK, U-Joint, LH
3	435504A1	2	PIN,
4	435501A1	2	SPACER,
5	86625266	2	WASHER, M17.5 x 30 x 4, HT,
6	86529976	2	BOLT, Hex, M16 x 35, 10.9,
7	86639255	2	PIN, ROLL, M6 x 55
8	403729A1	1	TURNBUCKLE,
9	403730A1	1	LOCK,
10	295004A1	4	PLUG,
11	282523A1	1	LOCK, Anti-Rotation
12	86624184	2	WASHER, M8 x 16 x 1.6,
13	43231	2	BOLT, Hex, M8 x 12, 10.9, Full Thd,
14	403728A1	1	KNUCKLE ASSY.,
15	403733A1	1	LINK, U-Joint, RH
16	87414	6	NIPPLE, LUBE, 1/4"-28 x .56" lg, Drive,

09-06 LINK ASSY - LIFT



09-06 LINK ASSY - LIFT

ссылка	Номер детали	Кол-во	Описание
1	329058A1	1	CLEVIS,
2	403720A1	1	KNUCKLE ASSY.,
3	403729A1	1	TURNBUCKLE,
4	403719A1	1	CLEVIS,
5	322446A1	1	BOLT, Special
6	435504A1	1	PIN,
7	435501A1	1	SPACER,
8	86625266	1	WASHER, M17.5 x 30 x 4, HT,
9	86529976	1	BOLT, Hex, M16 x 35, 10.9,
10	87414	3	NIPPLE, LUBE, 1/4"-28 x .56" lg, Drive,
11	295004A1	4	PLUG,
12	388469A1	1	PIN, CLEVIS,
13	86637653	1	PIN, SPLIT (COTTER), Int, 7/16" x .177", 7/16 x 3-13/16
14	86639255	2	PIN, ROLL, M6 x 55, Coiled Spring
15	344696A2	1	LATCH,

09-07 QUICK HITCH



09-07 QUICK HITCH

ссылка	Номер детали	Кол-во	Описание
			Category IV-Narrow
1	409653A1	1	COUPLING,
2	409654A1	1	HOOK,
3	86637940	4	BOLT, Hex Flg, 3/4"-10 x 2 1/2", G8,
4	409664A1	3	BLOCK, Retainer
5	435497A1	1	PIN,
6	9790143	6	BOLT, Hex, 1/2"-13 x 1", G8, Full Thd,
7	86624095	4	PIN, 1/2" x 2 1/2", Coiled,
8	409656A1	1	CAP, Spacer, RH
9	409658A1	1	CAP, Spacer, LH
10	409659A1	2	STOP, Hitch Release
11	409660A1	2	LATCH,
12	409661A1	2	LINK, CONNECTING,
13	409662A1	2	LINK, CONNECTING,
14	435440A1	2	SPRING, COMPRESSION,
15	86637812	6	PIN, 5/16" x 1 1/8", Coiled,
16	435496A1	2	PIN,
17	88904	4	BOLT, Hex, 1/2"-13 x 1 1/2", G8, Full Thd,
18	280375	4	NUT, LOCK, 3/4"-10, GC,
19	87381	4	WASHER, 3/4", SAE,

09-08 DRAWBAR - EXTENDABLE



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-08 DRAWBAR - EXTENDABLE

ссылка	Номер детали	Кол-во	Описание
1	402661A1	1	DRAWBAR, Receiver
2	9848973	12	NUT, M24, Cl 10,
3	403199A1	1	PIN, HITCH,
4	403194A1	1	YOKE,
5	403195A1	1	COVER,
6	435498A1	1	PLASTIC,
7	435540A1	2	SCREW, 1 NC x 9-1/4
8	86511609	2	NUT, 1"-8, G8,
9	86637660	1	PIN,
10	375720A1	1	PIN,
11	86625266	5	WASHER, M17.5 x 30 x 4, HT,
12	86529976	2	BOLT, Hex, M16 x 35, 10.9,
13	403196A1	2	PIN,
14	517758R91	2	SPLIT PIN/SAFETY PIN,
15	SFD014088	1	WASHER, 1-3/4"
16	361696A2	1	SPACER,
17	195941A1	1	PIN,
18	435501A1	1	SPACER,
19	86624189	1	WASHER, 21/32" x 1 5/16" x .150",
20	374835	1	BOLT, Hex, M16 x 40, 10.9,
21	87441225	1	HANGER,
22	86639319	26	WASHER, 26 x 44 x 5 mm
23	86505751	14	BOLT, Hex, M24 x 70, 10.9, Full Thd,
24	359506A1	1	DRAWBAR,
25	375719A1	1	STRAP, Drop Pin
26	375721A1	1	LATCH, Draw Bar
27	86625260	4	WASHER, M20 x 37.5 x 4, HT,
28	9843612	4	BOLT, Hex, M20 x 100, 10.9,
29	393878A1	1	PIN, Quick Release
30	70-4620T2	1	BUSHING, LARGE, Drawbar Receiver

09-09 DRAWBAR - HEAVY DUTY, WITHOUT THREE POINT HITCH



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-09 DRAWBAR - HEAVY DUTY, WITHOUT THREE POINT HITCH

ссылка	Номер детали	Кол-во	Описание
1	402654A1	1	DRAWBAR, Receiver
2	360219A3	1	DRAWBAR,
3	375719A1	1	STRAP, Drop Pin
4	375721A1	1	LATCH, Drop Bar
5	86625260	4	WASHER, M20 x 37.5 x 4, HT,
6	9843612	4	BOLT, Hex, M20 x 100, 10.9,
7	393878A1	1	PIN, Quick Release
8	195941A1	1	PIN,
9	361696A2	1	SPACER,
10	SFD014088	1	WASHER, 1-3/4"
11	435501A1	1	SPACER,
12	86624189	1	WASHER, 21/32" x 1 5/16" x .150",
13	374835	1	BOLT, Hex, M16 x 40, 10.9,
14	375720A1	1	PIN,
15	430620A1	1	PLATE, SPACER,
16	86529976	1	BOLT, Hex, M16 x 35, 10.9,
17	363131A2	1	SPACER,
18	80299	1	WASHER, 5/8",
19	375720A1	1	PIN, Hitch
20	430620A1	1	PLATE, SPACER,
21	86637660	1	PIN,
22	403220A1	1	HANGER,
23	403221A1	2	PLATE, PLATE
24	86639319	12	WASHER, 26 x 44 x 5 mm
25	9780064	6	BOLT, Hex, M24 x 110, 10.9,
26	9848973	6	NUT, M24, Cl 10,
27	402651A1	1	LINK, Hanger
28	363130A1	4	SPACER,
29	86505751	14	BOLT, Hex, M24 x 70, 10.9, Full Thd,
30	9848973	12	NUT, M24, Cl 10,
31	70-4620T2	1	BUSHING, LARGE, Drawbar Receiver

09-10 DRAWBAR - HEAVY DUTY, WITH THREE POINT HITCH



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-10 DRAWBAR - HEAVY DUTY, WITH THREE POINT HITCH

ссылка	Номер детали	Кол-во	Описание
1	402654A1	1	DRAWBAR, Receiver
2	360219A3	1	DRAWBAR,
3	375719A1	1	STRAP, Drop Pin
4	375721A1	1	LATCH, Draw Bar
5	86625260	4	WASHER, M20 x 37.5 x 4, HT,
6	9843612	4	BOLT, Hex, M20 x 100, 10.9,
7	361696A2	1	SPACER,
8	SFD014088	1	WASHER, 1-3/4"
9	86624189	1	WASHER, 21/32" x 1 5/16" x .150",
10	86624189	1	WASHER, 21/32" x 1 5/16" x .150",
11	374835	1	BOLT, Hex, M16 x 40, 10.9,
12	375720A1	1	PIN,
13	430620A1	1	PLATE, SPACER,
14	86529976	1	BOLT, Hex, M16 x 35, 10.9,
15	363131A2	1	SPACER,
16	80299	1	WASHER, 5/8",
17	9828248	1	BOLT, Hex, M16 x 60, 10.9,
18	403209A1	1	PIN,
19	86637660	1	PIN,
20	403217A1	1	YOKE,
21	403218A1	1	COVER ASSY,
22	363540A1	1	SPACER,
23	86639319	4	WASHER, 26 x 44 x 5 mm
24	86639187	2	BOLT, Hex, M24 x 270, 10.9,
25	9848973	14	NUT, M24, Cl 10,
26	403219A1	2	PIN ASSY.,
27	517758R91	2	SPLIT PIN/SAFETY PIN,
28	195941A1	1	PIN,
29	393878A1	1	PIN, Quick Release
30	87441225	1	HANGER,
31	86505751	14	BOLT, Hex, M24 x 70, 10.9, Full Thd,
32	70-4620T2	1	BUSHING, LARGE, Drawbar Receiver

09-11 DRAWBAR - REYNOLDS



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-11 DRAWBAR - REYNOLDS

ссылка	Номер детали	Кол-во	Описание
1	NSS	1	NOT SERVICED SEPARATELY, Drawbar, Purchase Assembly and Component Parts Directly From Reynolds, McAllen, Texas.
2	NSS	1	NOT SERVICED SEPARATELY, Mount, Purchase Assembly and Component Parts Directly From Reynolds, McAllen, Texas.
3	87448334	1	PLATE,
4	827-24180	3	BOLT, Hex, M24 x 180, 10.9, M24 x 180, CL10.9
5	86639319	32	WASHER, 26 x 44 x 5 mm
6	9848973	15	NUT, M24, Cl 10,
	433446A1	1	PIN, HITCH, Inc. 7 - 10
7	NSS	1	NOT SERVICED SEPARATELY, Pin
8	NSS	1	NOT SERVICED SEPARATELY, Pin, Cotter
9	NSS	1	NOT SERVICED SEPARATELY, Washer
10	NSS	1	NOT SERVICED SEPARATELY, Nut, Slotted
11	86639184	14	BOLT, Hex, M24 x 80, 10.9, Full Thd,
12	87317191	1	WASHER,
13	195941A1	1	PIN,
14	381065A1	1	SPACER,
15	435501A1	1	SPACER,
16	86624189	1	WASHER, 21/32" x 1 5/16" x .150",
17	374835	1	BOLT, Hex, M16 x 40, 10.9,
	365945A1	1	KIT, Adapter, Reverse, Inc. 18, 19
18	446133A1	1	ASSEMBLY, Reverse Adapter
19	359522A1	1	PIN,
20	434402A1	3	SPACER,
21	NSS	1	NOT SERVICED SEPARATELY, Hitch, Quick

09-12 CAB MOUNTING



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-12 CAB MOUNTING

ссылка	Номер детали	Кол-во	Описание
1	86639243	4	NUT, LOCK, M24 x 3, Cl 8,
2	87422287	4	MOUNT, RUBBER, Isolator
3	371043A1	4	WASHER, Steel
4	86639319	4	WASHER, 26 x 44 x 5 mm
5	827-24160	4	BOLT, Hex, M24 x 160, 10.9,

09-13 INTERIOR TRIM - DELUXE AND LUXURY CABS



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-13 INTERIOR TRIM - DELUXE AND LUXURY CABS

ссылка	Номер детали	Кол-во	Описание
1	394335A1	1	COVER, Post, Roll Over Protection
2	393376A1	1	COVER, Post, Roll Over Protection
3	394334A2	1	COVER, Post, Roll Over Protection
4	393374A1	1	COVER, Post, Roll Over Protection
5	394331A1	1	CONSOLE, Rear
6	394333A1	1	CONSOLE, Electronics
7	86500688	12	NUT, M6, Cl 10,
8	86624181	8	WASHER, M6,
9	245918C1	2	CAP, Blank Slot
10	43233	4	BOLT, Hex, M8 x 20, 10.9,
11	291835A4	1	BRACKET,
12	291836A3	1	BRACKET,
13	259461A1	3	FOAM, Cut From : 283086A1
14	394338A1	1	BEZEL,
15	303158A5	1	SUPPORT,
16	86525168	2	TUBE, No. 10 x 1
17	177269A1	2	NUT, Special
18	86505530	6	BOLT, Hex, M6 x 20, 10.9,
19	371685A4	1	BOX, Compact Disc, Deluxe Cab
20	119308A2	1	ASH TRAY, Storage
21	87608402	1	MAT, FLOOR,
22	376597A2	1	COVER, Hole
23	376553A1	3	FASTENER,
24	86639271	3	BOLT, Hex Flg, M8 x 30, 10.9, Full Thd,
25	435490A1	4	FOAM,
26	308579A1	2	BRACKET,
27	114549A1	1	COAT HOOK,
28	86639121	2	SCREW, SELF TAPPING, Oval Hd, M4.2 x 16,
29	86624182	4	WASHER, M6 x 18 x 1.6,
30	1961435C1	1	LATCH,
31	86637656	2	RIVET, Pop, 1/8" x .337",
32	1977929C1	1	STUD, Ball
33	87408613	1	FILTER, CAB, Air Recirculation
34	87416388	1	INSULATOR BLOCK,
35	355371A2	1	TAPE, ADHESIVE,
36	356717A1	2	TAPE, ADHESIVE,
37	349366A2	1	FOAM,
38	356789A1	2	FASTENER, Velcro Hook, Cut From : 356788A1
39	357564A1	2	FASTENER, Velcro Loop, Cut From : 357653A1
40	369937A1	1	NET, Cargo
41	369929A1	5	FASTENER, Christmas Tree
42	307026A1	1	SHIELD, Cable Access
43	86624185	3	WASHER, M8 x 17.5 x 2, HT,
44	418506A1	1	SWITCH, Park Brake, Manual Shift Transmission
45	409808A1	1	INDICATOR, Hi / Lo, Manual Shift Transmission

09-14 CAB - FLOORMATS AND DOORS



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-14 CAB - FLOORMATS AND DOORS

ссылка	Номер детали	Кол-во	Описание
1	87561589	1	MAT, FLOOR, Rubber, Power Shift Transmission
2	87562811	1	MAT, FLOOR, Rubber, Manual Shift Transmission
3	87562812	1	CARPET,
4	87537334	1	FRAME, CAB, ROPS
4	87537336	1	FRAME, CAB, ROPS / FOPS
5	87537771	1	INSULATION, FOAM, Floor, Rear
6	390360A1	2	SEAL, Cut From : 388449A1
7	130003	2	PIN, SPLIT (COTTER), M3.2 x 20,
8	86637800	2	PLUG, 2-1/2 ID
9	369719A1	1	BRACKET, Door, Left-Hand
10	371554A1	1	BRACKET, Door, Right-Hand
11	86624181	8	WASHER, M6,
11	353-404	1	PLUG, Dome, .500" hole, Nylon, , Used without INTELLISTEER Option
12	442085A1	2	MOUNTING PARTS, Stud
13	3234063R1	2	BALL JOINT,
14	413022A2	1	DOOR ASSY., See Figure: 09-15
	389175A3	1	WINDOW ASSY, Inc. 13, 15, 16 - 23, 33 & 42 - 44
15	389176A1	1	FRAME, WINDOW, RH
16	181242A3	1	WINDOW, Glass
17	87420877	1	BRACKET, Latch
18	87422906	1	BUSHING, M6
19	87423414	2	WASHER, Nylon
20	87418389	1	LATCH ASSY., RH Door
21	9804256	2	BOLT, Hex Flg, M6 x 20, 8.8,
22	86639037	2	BOLT, Hex, M6 x 16, 10.9,
23	9804276	2	NUT, M6 x 1, Flg, Cl 8,
24	87543673	10	SPACER,
25	87423532	1	PIN, Door Catch
26	86639244	1	NUT, Flange, M8
27	87429877	4	BUSHING,
28	R51754	1	CATCH, Striker
29	86637767	1	NUT, Flange, 7/16
30	241637	1	PLUG, Dome, .625" hole, Nylon, 5/8
31	86639049	11	PLUG, 1/2
32	87423389	1	DAMPER, Gas Spring
33	403749A1	1	NUT, M10; 10.9
34	43362	4	NUT, M8, Cl 10,
35	414699A1	1	PLATE, , Without Manual Transmission
36	120100	2	BOLT, Hex, M6 x 20, 8.8, , Without Manual Transmission
37	404287A1	2	INSERT, , Without Manual Transmission
38	327310A1	1	PLATE, Cover
39	86624184	4	WASHER, M8 x 16 x 1.6,
40	86512498	2	NUT, M16 x 2, Flg, Cl 10,
41	3233348R1	2	CLIP, Retainer, 13mm (1/2 in)
42	87423716	1	CAP, Vinyl

ссылка	Номер детали	Кол-во	Описание
43	9824259	3	WASHER, M6 x 12 x 1.6,
44	86514335	1	NUT, LOCK, M6, CL8
45	86624185	1	WASHER, M8 x 17.5 x 2, HT,
46	86625130	1	PLUG, Dome, 1.250" hole, Nylon, Dome, 1-1/4", Used without INTELLISTEER Option
47	329720A1	1	CYLINDER, Gas Spring
48	353-403	3	PLUG, Dome, .437" hole, Nylon,

09-15 DOOR ASSY



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-15 DOOR ASSY

ссылка	Номер детали	Кол-во	Описание
	413022A2	1	DOOR ASSY., Inc. 1 - 27
1	388785A2	1	DOOR,
2	388934A1	1	LEVER, Door Latch
3	181239A4	1	WINDOW ASSY, Glass
4	435491A1	1	HANDLE,
5	86977786	1	BOLT, Hex, M6 x 25, 8.8,
6	388874A2	1	LATCH,
7	86639101	1	CLEVIS, M6 x 12
8	906020R1	1	CLIP, M6 x 6
9	86624182	4	WASHER, M6 x 18 x 1.6,
10	86639114	1	PIN, SPLIT (COTTER), M1.6 x 10,
11	86500688	2	NUT, M6, Cl 10,
12	3234063R1	1	BALL JOINT,
13	403749A1	1	NUT, M10; 10.9
14	86511933	1	SCREW, Cross Pan Hd, 1/4"-20 x 1 1/4",
15	7770	1	NUT, 1/4"-20, G5,
16	86639143	3	BOLT, Hex, Lock, M6 x 35, Cl 10.9,
17	86639119	3	SCREW, SELF TAPPING, Pan Hd, M4.2 x 16,
18	194174A1	1	GASKET, Rubber
19	194175A1	1	GASKET, Rubber
20	388122A1	1	HANDLE,
21	388120A2	1	ARMREST,
22	87543673	10	SPACER,
23	86639117	1	SCREW, SELF TAPPING, Pan Hd, M4.2 x 16,
24	86639314	2	WASHER, M5 x 10 x 1,
25	352842A1	1	KNOB, Lock
26	388936A1	1	ROD,
27	88961	4	SCREW, Hex Soc Flat Hd, 1/4"-20 x 3/4",
28	86639119	2	SCREW, SELF TAPPING, Pan Hd, M4.2 x 16,
29	329720A1	1	CYLINDER, Gas Spring
30	397159A1	1	COVER,
31	369566A1	1	TAPE, ADHESIVE,
32	130003	2	PIN, SPLIT (COTTER), M3.2 x 20,
33	3233348R1	2	CLIP, Retainer

09-16 CAB - SKIRTS AND GLASS



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-16 CAB - SKIRTS AND GLASS

ссылка	Номер детали	Кол-во	Описание
1	341574A4	1	BRACKET,
2	86624184	4	WASHER, M8 x 16 x 1.6,
3	43362	4	NUT, M8, Cl 10,
4	443864A1	2	SPACER,
5	87535372	1	SKIRT, Rear
6	87358026	1	SKIRT, LH
7	87348261	1	COVER, SKIRT, LH, with Lower Front Wipers
8	87358025	1	COVER, SKIRT, RH
9	87348210	1	COVER, SKIRT, RH, with Lower Front Wipers
10	361191A1	4	GROMMET,
11	86639326	4	WASHER, M17.5 x 34 x 5, HT,
12	86529976	4	BOLT, Hex, M16 x 35, 10.9,
13	181240A2	1	GLASS, Rear
14	87436557	1	GLASS, TINTED, Windshield
14	87436560	1	GLASS, TINTED, Windshield, Laminated (Europe Only)
15	87543673	52	SPACER,
16	117707A3	7	CLAMP, Window
17	86624184	8	WASHER, M8 x 16 x 1.6,
18	43362	8	NUT, M8, Cl 10,
19	259462A1	1	INSULATION, FOAM, 1525 mm (60 in)
20	87312395	1	INSULATION, FOAM,
21	86585703	4	SCREW, Cross Pan Hd, M8 x 20,
22	404882A1	4	FASTENER, Spring
23	355716A3	1	FOAM,
24	364156A1	4	BRACKET, Roof Support
25	43362	8	NUT, M8, Cl 10,
26	86625263	8	WASHER, M8 x 20 x 1.6,
27	43234	4	BOLT, Hex, M8 x 25, 10.9,
30	86511830	2	SCREW, Cross Pan Hd, M6 x 20,
28	86528579	4	NUT, LOCK, M8 x 1.25, Cl 10,
29	86511831	10	SCREW, Cross Pan Hd, M6 x 25,
31	241637	1	PLUG, Dome, .625" hole, Nylon, , Without Flex Control
32	404287A1	4	INSERT, Threaded ,M6 x 1
33	NSS	1	NOT SERVICED SEPARATELY, Roof Assy, See Figure: 09-17
34	895-15006	4	WASHER, M6 x 25 x 1.6,
35	60-5021T1	2	SPACER,
36	60-6840T1	2	GROMMET,

09-17 ROOF



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-17 ROOF

ссылка	Номер детали	Кол-во	Описание
1	320246A1	4	LAMP, Warning, Hazard, See Figure: 04-24
2	355532A1	6	WASHER, Nylon
3	353561A1	1	BRACKET, Light, RH, Front
4	92269C1	6	LAMP, WORK, See Figure: 04-24
5	86639309	12	WASHER, M8 x 16 x 1.6,
6	43234	6	BOLT, Hex, M8 x 25, 10.9,
7	86528579	6	NUT, LOCK, M8 x 1.25, Cl 10,
8	86546084	8	SCREW, Cross Pan Hd, M5 x 35,
9	353563A1	2	BRACKET, Light, RH, Rear
10	86500689	6	NUT, M10, Cl 10,
11	451165A1	8	INSERT, THREADED,
12	353562A1	2	BRACKET, Light, LH, Rear
13	353560A1	1	BRACKET, Light, LH, Front
14	87394824	1	ROOF,
15	408658A1	2	DECAL, Cover, Without Mirror
16	361191A1	4	GROMMET,
17	86639311	4	WASHER, M16 x 34 x 3,
18	86529976	4	BOLT, Hex, M16 x 35, 10.9,
19	435436A1	7	MOUNT, RUBBER, Cable Tie

09-18 CAB - HEADLINER AND CONTROL PANEL







TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-18 CAB - HEADLINER AND CONTROL PANEL

ссылка	Номер детали	Кол-во	Описание
1	87453142	1	PANEL, Control
	393319A1	1	PANEL, Headliner Assy., Inc. 2 - 5
2	NSS	1	NOT SERVICED SEPARATELY, Headliner
3	393383A1	1	BRACKET, Domelight
4	328039A1	3	PAD, No. 6 x 5/8"
5	302862A1	6	NUT, Special
6	393384A1	2	BRACKET, Domelight
7	328037A1	1	PAD, 9 x 20 x 1.6 mm
8	86639246	8	NUT, Crown, M6, Cl8,
9	1983391C1	3	LAMP, Interior, Inc. 10
10	E35556	1	BULB,
11	435438A1	2	SPACER,
12	435493A1	1	BRACKET,
13	A177462	1	MIRROR, Rearview, Inc. 14, 15
14	85700573	1	WASHER, LOCK, Ext Tooth, M6,
15	86642419	1	PIN, LOCK, 1/4 NF
16	86639023	2	BOLT, Hex Flg, M6 x 30, 10.9,
17	177269A1	8	NUT, Special
18	372892A1	1	LAMP, Map
19	280569A2	1	BEZEL,
20	400111A1	2	COVER, Speaker
21	83882C91	1	LAMP,
22	1270741C1	10	SCREW, SELF TAPPING, Cross Pan Hd, #8 x 1", Pointed
23	87450400	1	VISOR, SUN, Rear
24	87450399	1	VISOR, SUN, Front
25	86637783	4	SCREW, SELF TAPPING, Cross Pan Hd, #6 x 5/8",
26	297865A1	8	WASHER, 9 x 20 x 1.6 mm
27	280628A1	1	PLUG, Switch, Without Mirror
28	384759A1	1	FOAM,

09-19 CONSOLE - RIGHT-HAND ARMREST, MANUAL





TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-19 CONSOLE - RIGHT-HAND ARMREST, MANUAL

ссылка	Номер детали	Кол-во	Описание
1	87364048	1	SUPPORT, Electronic, Non-Adjustable
2	86625254	1	WASHER, M12 x 28 x 2.5,
3	86639031	1	BOLT, Hex, M12 x 45, 10.9, Full Thd,
4	9804277	1	NUT, M8 x 1.25, Flg, Cl 8,
5	349563A1	1	BRACKET, , Without Arm Rest Unit
6	86639293	2	SCREW, Hex Soc Hd, M4 x 12, 8.8,
7	86624179	2	WASHER, M4,
8	86511816	4	SCREW, Cross Pan Hd, M3 x 16,
9	86508812	4	NUT, M3, Cl 8,
10	86639310	4	WASHER, M3,
11	86598598	1	CLAMP, 3/4", Insul, 1/2" Bolt,

09-20 CONSOLE - RIGHT HAND ARMREST, ELECTRIC, BSN Z7F202358



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-20 CONSOLE - RIGHT HAND ARMREST, ELECTRIC, BSN Z7F202358

ссылка	Номер детали	Кол-во	Описание
	87519426	1	SUPPORT, Electronic, Inc. 1 - 27
1	NSS	1	NOT SERVICED SEPARATELY, Plate
2	NSS	1	NOT SERVICED SEPARATELY, Support
3	222292A1	1	NUT, Special
4	185062R1	1	BUSHING,
5	NSS	1	NOT SERVICED SEPARATELY, Support, Lower
6	294296A1	1	BUSHING,
7	355343A1	1	BOLT, Special
8	NSS	1	NOT SERVICED SEPARATELY, Link
9	NSS	3	NOT SERVICED SEPARATELY, Washer, Shoulder
10	355342A1	1	BRACKET,
11	355344A1	1	BOLT, Special
12	319870A1	1	KNOB,
13	43234	3	BOLT, Hex, M8 x 25, 10.9,
14	86625263	3	WASHER, M8 x 20 x 1.6,
15	86528579	3	NUT, LOCK, M8 x 1.25, Cl 10,
16	277582A1	2	WASHER, Special
17	86639041	2	BOLT, Hex, M6 x 25, 10.9, Full Thd,
18	86624181	2	WASHER, M6,
19	277576A1	1	SPACER,
20	86639261	1	SCREW, Cross Pan Hd, M4 x 14,
21	86624179	1	WASHER, M4,
22	86625075	1	NUT, LOCK, M4 x .7, Cl 8,
23	412250	2	NUT, LOCK, M8 x 1.25, Cl 8,
24	277570A1	2	WASHER, Special
25	NSS	1	NOT SERVICED SEPARATELY, Spring
26	294295A1	3	BUSHING,
27	NSS	1	NOT SERVICED SEPARATELY, Support, Upper
28	86625254	1	WASHER, M12 x 28 x 2.5,
29	355345A1	1	WASHER, Ribbed
30	86639031	1	BOLT, Hex, M12 x 45, 10.9, Full Thd,
31	9804277	1	NUT, M8 x 1.25, Flg, Cl 8,
32	87314389	1	CONSOLE, Armrest, Upper, w/ Decals, Inc. 33 & 34
33	410518A1	1	DECAL, Throttle and EH Levers
34	87314390	1	COVER, Upper
35	277204A2	1	CUSHION,
36	86639117	4	SCREW, SELF TAPPING, Pan Hd, M4.2 x 16,
37	405227A1	1	HOUSING, Lower, Without Flex Control
37	87339622	1	HOUSING, Lower, With Flex Control
38	86639294	6	SCREW, Hex Soc Hd, M4 x 20, 8.8, , With Flex Control
39	86624126	6	SCREW, Hex Soc Hd, M4 x 16, 8.8, , Without Flex Control
40	86624179	16	WASHER, M4,
41	100012	4	NUT, M4, Cl 8,
42	331649A1	1	HOLDER, Cup
43	44334	4	SCREW, Cross Pan Hd, M4 x 12,

09-20 CONSOLE - RIGHT HAND ARMREST, ELECTRIC, BSN Z7F202358

ссылка	Номер детали	Кол-во	Описание
44	86598598	1	CLAMP, 3/4", Insul, 1/2" Bolt,

09-20(01) CONSOLE - RIGHT HAND ARMREST, ELECTRIC



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-20(01) CONSOLE - RIGHT HAND ARMREST, ELECTRIC

ссылка	Номер детали	Кол-во	Описание
	87566268	1	Electronic, Inc. 1 - 5
1	87604589	1	BRACKET, Plate
2	87604590	1	PLATE, Support
3	87578954	1	
4	87566581	1	KNOB,
5	NSS	1	NOT SERVICED SEPARATELY, Support, Upper
6	895-15010	1	WASHER, M11 x 24 x 2,
7	627-10020	1	BOLT, Hex, M10 x 20, 10.9, Full Thd,
8	87314389	1	CONSOLE, Armrest, Upper, w/ Decals, Inc. 9 & 10
9	410518A1	1	DECAL, Throttle and EH Levers
10	87314390	1	COVER, Upper
11	277204A2	1	CUSHION,
12	86639117	4	SCREW, SELF TAPPING, Pan Hd, M4.2 x 16,
13	405227A1	1	HOUSING, Lower, Without Flex Control
13	87339622	1	HOUSING, Lower, With Flex Control
14	86639294	6	SCREW, Hex Soc Hd, M4 x 20, 8.8, , With Flex Control
15	86624126	6	SCREW, Hex Soc Hd, M4 x 16, 8.8, , Without Flex Control
16	86624179	16	WASHER, M4,
17	100012	4	NUT, M4, Cl 8,
18	331649A1	1	HOLDER, Cup
19	44334	4	SCREW, Cross Pan Hd, M4 x 12,
20	86598598	1	CLAMP, 3/4", Insul, 1/2" Bolt,
21	893-11004	6	WASHER, LOCK, Ext Tooth, M4,

09-21 FRONT CONSOLE



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-21 FRONT CONSOLE

ссылка	Номер детали	Кол-во	Описание
1	87438118	1	VENT, Air Conditioning and Heating
2	257059A2	1	PLATE, Support
3	281138A2	1	GUIDE,
4	281139A1	1	GUIDE,
5	246476A1	2	VENT,
6	275601A1	1	LINK,
7	86625075	1	NUT, LOCK, M4 x .7, Cl 8,
8	86511042	1	SCREW, Cross Pan Hd, M4 x 16,
9	86511823	3	SCREW, Cross Pan Hd, M4 x 8,
10	86624179	1	WASHER, M4,
11	435474A1	3	BEARING, NYLON,
12	414161A2	1	CONSOLE,
13	87517381	1	STEERING ASSY,
14	86508616	2	BOLT, Hex, M6 x 12, 10.9,
15	277438A1	1	SUPPORT,
16	275602A1	1	ACTUATOR, Actuator
17	280566A1	1	SUPPORT,
18	86639117	3	SCREW, SELF TAPPING, Pan Hd, M4.2 x 16,
19	86639037	4	BOLT, Hex, M6 x 16, 10.9,
20	281140A1	1	WASHER, Special
21	86585706	1	SCREW, Cross Pan Hd, M4 x 10,
22	895-11010	4	WASHER, M10 x 20 x 2,
23	86500689	4	NUT, M10, Cl 10,
24	414350A1	10	VENT,
25	301098A1	2	CLIP,
26	86000535	1	PLUG, 1.427" x .62", Plastic, Switch, Without Ether Start
27	356717A1	1	TAPE, ADHESIVE,
28	87340325	1	SWITCH, Decleration
29	384786A2	2	FOAM, , Deluxe Cab
30	895-11006	2	WASHER, M6,
31	436276A1	3	SCREW, Button Hd
32	A67295	1	PLUG,
33	436276A1	3	SCREW, M6
34	446687A1	2	FOAM,
35	87437453	1	FOAM, Accoustical
36	87437455	1	FOAM, Accoustical
37	87437454	1	DECAL, Sealing
38	87442532	1	SEAL,
39	829-1406	2	NUT, M6, Cl 10,
40	87433404	1	PLATE, Access
41	843-1616	4	SCREW, Hex Flat Hd, M6 x 16, 4.8, Flg hd, M6 x 16, CL4.8
42	195-81023	3	WASHER, #12,
43	87561659	1	PLATE, MOUNTING, Decel Switch


5
2
3
4
1

09-22 SEAT - NON-INSTRUCTIONAL

ссылка	Номер детали	Кол-во	Описание
1	1961435C1	1	LATCH,
2	402710A1	1	TRAY,
3	1977929C1	1	STUD, Ball
4	86637656	2	RIVET, Pop, 1/8" x .337",
5	302456A1	1	ASH TRAY, If Used

09-23 SEAT - INSTRUCTIONAL



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-23 SEAT - INSTRUCTIONAL

ссылка	Номер детали	Кол-во	Описание
1	365674A1	1	HINGE,
2	249707A2	1	BRACKET,
3	87439262	1	CUSHION, Backrest, Cloth
3	86984296	1	CUSHION, SEAT, Backrest, Leather
4	406682A1	2	FASTENER,
5	252928A2	1	BRACKET,
6	395132A1	1	TRAY,
7	86511931	3	SCREW, Cross Pan Hd, 1/4"-20 x 5/8",
8	281926A2	1	BELT, Seat
9	302456A1	3	ASH TRAY, If Used
10	9846677	3	BOLT, Hex, M10 x 25, 10.9, Full Thd,
11	9804278	3	NUT, M10 x 1.5, Flg, Cl 8,
12	86624183	2	WASHER, M6 x 25 x 1.6,
13	86990053	1	CUSHION, Seat, Cloth
13	86984293	1	CUSHION, SEAT, Leather
14	281032	3	BOLT, Hex, 1/4"-20 x 3/4", G8, Full Thd,
15	906051R1	2	SCREW, Hex Soc But Hd, M6 x 1 x 10, 12.9, 1/4 x 3/4
16	369635A2	1	HOLDER, Cup Holder
17	394828A1	1	PLATE, Tray
19	719528013	1	KIT, Instructional Seat, Cloth

09-24 SEAT - OPERATORS



09-24 SEAT - OPERATORS

ссылка	Номер детали	Кол-во	Описание
1	87553809	1	SEAT ASSY., Cloth, without Heat, See Figure: 09-25
1	87553811	1	SEAT ASSY., Cloth, Heated, See Figure: 09-25
1	87553441	1	SEAT ASSY., Cloth, Heated, Semi-Active, See Figure: 09-25
1	87553443	1	SEAT ASSY., Leather, Heated, Semi-Active, See Figure: 09-25
2	87395380	1	SUSPENSION, Suspension, See Figure: 09-26
2	87395381	1	SUSPENSION, Suspension, Semi-Active, See Figure: 09-27
3	9804277	4	NUT, M8 x 1.25, Flg, Cl 8, , Used on Scrapper Models
4	389277A1	2	BELT, Tether, Used on Scrapper Models
5	NSS	2	NOT SERVICED SEPARATELY, Spacer, Used on Scrapper Models
6	87039401	2	WASHER, 13/32" x 13/16" x .134", HDN,
7	86575418	2	BOLT, Hex, 3/8"-16 x 2 1/4", G8,
8	87039402	2	NUT, LOCK, 3/8"-16, GB,
9	87431487	1	KIT, FIP, Tether Belt, Used on Scrapper Models
10	337475	1	NUT, M12, Cl 10,
11	86625255	3	WASHER, M13.5 x 24.5 x 3, HT,
12	87313413	1	TUBE SPACER, Steel, .875" x .5"
13	87015314	1	BOLT, Hex, Lock, M12 x 40, Cl 10.9,
14	806-12030	1	BOLT, Hex, Lock, M12 x 30, Cl 10.9,
15	444877A1	1	SEAT BELT,

09-25 SEAT - CUSHION ASSEMBLY



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-25 SEAT - CUSHION ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
	87553809	1	SEAT ASSY., Cloth, without Heat, Inc. 1 - 7, 10 - 12, 16 - 24
	87553811	1	SEAT ASSY., Cloth, Heated, Inc. 1 - 24
	87553441	1	SEAT ASSY., Cloth, Heated, Inc. 1 - 24
	87553443	1	SEAT ASSY., Leather, Heated, Inc. 1 - 24
1	86994150	1	SEAT ASSY., Backrest, Cloth, without Heat
1	87395383	1	CUSHION, Backrest, Cloth, Heated
1	87397612	1	CUSHION, Leather, Heated
2	87347890	1	SEAT, BACK, Cloth, Without Heat
2	87395382	1	CUSHION, SEAT, Cloth, Heated
2	87397611	1	CUSHION, Leather, Heated
3	86994155	1	ASSEMBLY, Seat Back, with Lumber & Pouch
4	87416475	1	KNOB, Recline Control
5	NSS	1	NOT SERVICED SEPARATELY, Pan, Seat
6	86512499	1	NUT, M20 x 2.5, Flg, Cl 10,
7	87300397	1	SWITCH, Seat, Air Control
8	87395388	1	SWITCH, Heater, Round Rocker
9	87395390	1	HARNESS, Heater, Center Section
10	87347956	1	KIT, SERVICE, Swivel
11	87308130	1	SEAT BACK ADJUST. DEVICE, Lumbar, Inc. 12
12	87037462	1	SEAT BACK ADJUST. DEVICE, Lumbar Knob
13	87347958	1	KIT, SERVICE, Operators Ride Control
14	87347944	1	KIT, SERVICE, Harness, Suspension
15	87395389	1	CONTROL, Heater, Resistor
16	302016A1	1	PACKAGE, SERVICE, Slide Pucks
17	86639024	1	SCREW, Hex Soc, Shoulder, M10 12 X 30mm, Cl12.9,
18	87347934	1	LATCH, Seat Slide
19	87347942	1	KIT, SERVICE, Swivel Control
20	87347941	1	KIT, SERVICE, Fore / Aft Slide Control
21	87347940	1	KIT, SERVICE, Height Control
22	86994165	1	SEAT ACCESSORY, Recliner Control
23	87347936	1	KIT, SERVICE, Swivel
24	87347939	1	KIT, SERVICE, Armrest, Left-Hand, Cloth, without Heat
24	86994250	1	ASSEMBLY, Armrest, Left-Hand, Cloth, Heated
25	87300397	1	SWITCH, Operator Presence
26	86994172	1	KIT, SERVICE, Manual Holder

09-26 SEAT - SUSPENSION ASSEMBLY



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-26 SEAT - SUSPENSION ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
1	87395380	1	SUSPENSION, Inc. 2 - 24
2	87395392	1	HOUSING, Upper
3	333275A1	1	HOUSING, Lower
4	333276A1	1	ARM,
5	302033A1	1	SHAFT,
6	87347944	1	KIT, SERVICE, Harness, Not Shown, See Figure: 09-25
7	87347943	1	KIT, SERVICE, Suspension Boot
8	302029A2	1	PLATE,
9	333279A2	1	KIT, Air Spring
10	87347951	1	KIT, SERVICE, Air Compressor
11	87347945	1	KIT, SERVICE, Suspension Bearing and Rollers
12	87347946	1	KIT, SERVICE, Isolator Rollers
13	87395394	1	ISOLATOR, Lateral Isolator Shock Absorber
14	447956A1	1	PACKAGE, SERVICE, Suspension Shock Absorber
15	333659A1	1	PACKAGE, SERVICE, Boot Pin
16	87395395	1	ISOLATOR, Fore and Aft Shock Absorber
17	373470A2	1	PACKAGE, SERVICE, Fore and Aft Isolator Control
18	373473A1	1	PACKAGE, SERVICE, Lateral Isolator Control
19	333295A1	1	PACKAGE, SERVICE, Suspension Bumper
20	87396231	1	TUBE, PLASTIC-RUBBER, Tube and Fitting
21	333296A1	1	PACKAGE, SERVICE, Fore and Aft Isolator Shock Block, Not Shown
22	87347955	1	CABLE, Suspension Shock Cable
23	87395393	1	HOUSING, Upper Lateral Isolater
24	373469A1	1	PACKAGE, SERVICE, Knobs, Suspension

09-27 SEAT - SEMI ACTIVE SUSPENSION ASSEMBLY



09-27 SEAT - SEMI ACTIVE SUSPENSION ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
1	87395381	1	SUSPENSION, Inc. 2 - 26
2	87395392	1	HOUSING, Upper
3	86994256	1	HOUSING, Lower
4	86994258	1	ARM,
5	302033A1	1	SHAFT,
6	87347944	1	KIT, SERVICE, Harness, Not Shown, See Figure: 09-25
7	87347943	1	KIT, SERVICE, Suspension Boot
8	302029A2	1	PLATE,
9	333279A2	1	KIT, Air Spring
10	87347951	1	KIT, SERVICE, Compessor
11	87407047	1	KIT, SERVICE, Knobs
12	87347945	1	KIT, SERVICE, Suspension Bearing and Rollers
13	87347946	1	KIT, SERVICE, Isolator Rollers
14	87395394	1	ISOLATOR, Lateral Isolator Shock Absorber
15	86994260	1	KIT, SERVICE, Shock
16	333659A1	1	PACKAGE, SERVICE, Boot Pin
17	87395395	1	ISOLATOR, Fore and Aft Shock Absorber
18	373470A2	1	PACKAGE, SERVICE, Fore and Aft Isolator Control
19	87395396	1	DAMPER, Control Kit
20	373473A1	1	PACKAGE, SERVICE, Lateral Isolator Control
21	333295A1	1	PACKAGE, SERVICE, Suspension Bumper
22	86994267	1	LEVER, Suspension Shock Cable
23	333296A1	1	PACKAGE, SERVICE, Fore and Aft Isolator Shock Block (Not Shown)
24	87347960	1	KIT, SERVICE, Air Tank
25	87396231	1	TUBE, PLASTIC-RUBBER, Air Tank Hose
26	87395393	1	HOUSING,

09-28 MIRRORS



09-28 MIRRORS

ссылка	Номер детали	Кол-во	Описание
1	A177462	1	MIRROR, Interior, Inc. 2, 3
2	85700573	1	WASHER, LOCK, Ext Tooth, M6,
3	86642419	1	PIN, LOCK, 1/4 NF
4	313139A1	1	ARM, Manual, RH, BSN Z6F202001
4	313140A1	1	ARM, Manual, LH, BSN Z6F202001
4	87363073	1	ARM, Manual, RH, ASN Z6F202001
5	87363070	1	ARM, Manual, LH, Not Illustrated, ASN Z6F202001
6	514-865	4	BOLT, Hex, M12 x 80, 10.9,
7	86639330	4	WASHER, M12 x 24.5 x 3, HT,
8	365414A1	2	MIRROR, Manual, BSN Z6F202001
8	87350494	2	MIRROR ASSY., Manual, ASN Z6F202001
9	313141A1	1	ARM, RH, Electric, BSN Z6F202001
9	87363082	1	ARM, RH, Electric, ASN Z6F202001
10	87369735	1	ARM, LH, Electric, Not Illustrated, BSN Z6F202001
10	87363077	1	ARM, LH, Electric, Not Illustrated, ASN Z6F202001
11	412065	4	PIN, M12 x 80; 10.9
12	86639330	4	WASHER, M12 x 24.5 x 3, HT,
13	360580A1	2	MIRROR, Electric, Inc. 14
13	87363066	1	MIRROR, Electric, ASN Z6F202001
14	324437A1	1	MIRROR, REPLACEMENT, Glass
15	280627A1	1	SWITCH,
16	280628A1	1	PLUG,

09-29 FRONT FRAME, TJ380 / 430 & T9030 / 9040



09-29 FRONT FRAME, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87407729	1	FRAME ASSY,
2	363226A1	2	BUMPER, Rubber
3	86625253	28	WASHER, M11 x 24 x 2,
4	86500689	6	NUT, M10, Cl 10,
5	627-12045	1	BOLT, Hex, M12 x 45, 10.9, Full Thd,
6	86625255	33	WASHER, M13.5 x 24.5 x 3, HT,
7	9824642	12	BOLT, Hex, M12 x 35, 10.9,
8	337475	24	NUT, M12, Cl 10,
9	43234	3	BOLT, Hex, M8 x 25, 10.9,
10	NSS	1	NOT SERVICED SEPARATELY, Tank Assy, Hydraulic, See Figure: 08-15
11	NSS	1	NOT SERVICED SEPARATELY, Door Assy, Battery, RH, See Figure: 09-31
12	413475A1	1	SCREEN, Bumper
13	627-6016	7	BOLT, Hex, M6 x 16, 10.9,
14	895-15006	7	WASHER, M6 x 25 x 1.6,
15	627-12040	13	BOLT, Hex, M12 x 40, 10.9, Full Thd,
16	87372424	1	RETAINER, CABLE,
17	627-10025	1	BOLT, Hex, M10 x 25, 10.9, Full Thd,
18	9846677	1	BOLT, Hex, M10 x 25, 10.9, Full Thd,
19	87309871	1	COVER, DOOR, Access
20	87528060	1	
21	374895	1	BOLT, CARRIAGE, Short NK, M12 x 25, Cl8.8, Full Thd,
22	87522173	1	GUSSET,
23	413470A1	1	BUMPER,
24	D55216	1	PAD, Non-Slip
25	87444725	1	SUPPORT, Air Intake
26	87443717	1	COVER, Access
27	832-10408	2	NUT, LOCK, M8 x 1.25, Cl 8,
28	443357A1	1	BRACKET, Door Stop
29	627-8025	10	BOLT, Hex, M8 x 25, 10.9,
30	87316943	1	STEP, With Fender
31	D55216	3	PAD, Anti-Skid
32	87318292	1	FRONT FENDERS 4WD, RH
33	397308A3	1	FENDER, Flare, RH, Front
34	396412A1	2	STRIP, RUBBER,
35	328197A1	3	SEAL, Foam
36	86639151	1	BOLT, Hex, M12 x 120, 10.9,
37	412126	1	NUT, LOCK, M12 x 1.75, Cl 8,
38	86624978	6	BOLT, Hex, M10 x 35, 10.9, Full Thd,
39	87386271	1	SHIELD, Trash
40	86624185	8	WASHER, M8 x 17.5 x 2, HT,
41	895-11010	2	WASHER, M10 x 20 x 2,
42	426285A1	42	STUD, Threaded
43	384163A1	1	PLUG, PLASTIC,

09-31 BATTERY DOOR



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-31 BATTERY DOOR

ссылка	Номер детали	Кол-во	Описание
1	87361594	1	COVER, DOOR,
2	87301185	3	STEP,
3	86624978	16	BOLT, Hex, M10 x 35, 10.9, Full Thd,
4	86514720	12	NUT, LOCK, M10, CL8
5	87582012	2	PLATE, Door Hinge
6	895-11010	12	WASHER, M10 x 20 x 2,
7	87340774	1	LATCH, Door
8	896-15010	4	WASHER, M10 x 24.5 x 3, HT,

09-32 GRILLE


1
10
5
11
14
17
18
4
16
39
11
5
13
3
12
37
38
19
2
15
15
8
6
28
25
6
8
7
28
21
22
36
24
23
19
20
29
27
31
32
30
26
34
9
33
35
9

TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-32 GRILLE

ссылка	Номер детали	Кол-во	Описание
1	87314929	1	GRILLE, , TJ380 /430, T9030 / 9040
1	87439516	1	GRILLE ASSY, , TJ480 / 530, T9050 / 9060
2	87309303	1	GRILLE, Grille Frame, T9030 / 9040, TJ380 /430
2	87439515	1	GRILLE ASSY, Grille Frame, T9050 / 9060, TJ480 / 530
3	86625254	1	WASHER, M12 x 28 x 2.5,
4	87314942	1	ROD, Grille Prop
5	529761R1	4	BUSHING,
6	86625252	6	WASHER, M10 x 21.5 x 2.5, HT,
7	86625005	2	BOLT, Hex, M8 x 60, 10.9, Rubber
8	86500689	2	NUT, M10, Cl 10,
9	86625255	4	WASHER, M13.5 x 24.5 x 3, HT,
10	86639189	2	BOLT, Hex, M6 x 60, 10.9,
11	86624184	4	WASHER, M8 x 16 x 1.6,
12	733-4020	1	PIN, SPLIT (COTTER), M4 x 20, Cotter, 4 x 20 mm
13	86528579	2	NUT, LOCK, M8 x 1.25, Cl 10,
14	87312706	1	CLIP, Clip
15	395578A1	2	SEAL, 558 mm (22 in), Cut From : 353729A1
16	352768A1	1	SEAL, Foam, TJ380 /430, T9030 / 9040
16	87439824	1	SEAL, Foam, TJ480 / 530, T9050 / 9060
17	86625261	2	WASHER, M5 x 10 x 1,
18	614-5020	2	BOLT, Hex, M5 x 20, 8.8, Full Thd, M5 x 20, CL8.8
19	86639038	9	BOLT, Hex, M6 x 25, 10.9,
20	L106237	1	SPRING,
21	86639008	1	CLAMP, 1/4", Insul, 1/2" Bolt, 1/4 ID
22	443297A1	1	CABLE PULLING GRIP,
23	393392	1	NUT, LOCK, M6 x 1, Cl 8,
24	43260	6	BOLT, Hex, M12 x 30, 10.9,
25	440891A1	1	SEAL, Cut From : 436609A1, T9030 / 9040, TJ380 /430
25	369741A1	1	SEAL, , T9050 / 9060, TJ480 / 530
26	388554A1	2	GROMMET, 127 mm (5 in), Cut From : 443080A1
27	357893A1	2	SCREW,
28	412557A1	2	SEAL, RUBBER, 581 mm (23 in)
29	325525A3	1	ARM, Safety, TJ380 /430, T9030 / 9040
30	414503A1	1	LINK, Hood, T9030 / 9040
30	87311749	1	ARM ASSY., Hood, TJ480 / 530, T9050 / 9060
31	86625253	2	WASHER, M11 x 24 x 2,
32	9861444	2	BOLT, Hex, M10 x 20, 10.9, Full Thd,
33	337475	4	NUT, M12, Cl 10,
34	316937A1	2	SPACER,
35	43263	2	BOLT, Hex, M12 x 60, 10.9,
36	86639325	6	WASHER, M10 x 24.5 x 3, HT,
37	356813A2	4	BRACKET, SUPPORTING, Nut Strip
38	86624182	8	WASHER, M6 x 18 x 1.6,
39	440890A1	1	SEAL, Foam, T9030 / 9040, TJ380 /430
39	87440015	1	SEAL, Foam, T9050 / 9060, TJ480 / 530

09-33 HOOD AND SUPPORT, TJ380 / 430 & T9030 / 9040



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-33 HOOD AND SUPPORT, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	87443686	1	HOOD ASSY., Engine
2	87445180	1	INSULATION, FOAM, Hood
3	87313225	1	ARM, w/ Lock
4	435437A1	2	STRAP, CABLE, 7 in
5	87317695	4	BOLT, Hex, M6 x 30, 10.9, Full Thd,
6	86625060	2	NUT, LOCK, Self, Threading, 1/4",
7	86625255	8	WASHER, M13.5 x 24.5 x 3, HT,
8	339543A2	1	ARM, Lift, See Figure: 09-35
9	87367456	1	BRACKET, Hood Latch
10	86639105	1	PIN, CLEVIS, M6 x 20, Clevis, 6 x 20 mm
11	86624182	8	WASHER, M6 x 18 x 1.6,
12	314842A3	4	BEARING,
13	86639188	4	BOLT, Hex, M6 x 40, 10.9,
14	86624181	4	WASHER, M6,
15	86514335	4	NUT, LOCK, CL 10, M6 x 1
16	443297A1	1	CABLE PULLING GRIP,
17	318159A1	1	LATCH,
18	87303387	1	SUPPORT, Radiator, LH
19	87303386	1	SUPPORT, Radiator, RH
20	80337563	8	SCREW, Cap, HH, CL 10.9, M12 x 1.75 x 40
21	86639114	1	PIN, SPLIT (COTTER), M1.6 x 10,
22	87353799	1	GUIDE, Hood Sight
23	87305954	1	BRACKET, Air Cleaner Cover
24	627-6020	2	BOLT, Hex, M6 x 20, 10.9,
25	829-1406	2	NUT, M6, Cl 10,
26	87307537	4	PLATE,
	87524895	1	SCREEN, Assy., RH, Inc. 27, 28, 30, 32, 33, 38 - 40
27	87524896	1	SCREEN, Engine, RH
28	87313245	1	SOFT TRIM, RH, 1923 mm (76"), Cut From: 87371080
	87313250	1	SCREEN, Assy., LH, Inc. 29, 31 - 33, 38 - 40
29	87313251	1	SCREEN, Engine, LH
30	87313230	1	SOFT TRIM, Dipstick Hole, 476mm (18 - 3/4 in), Cut from: 87371080
31	87425602	1	MOLDING, LH, 1923mm (76"), Cut from: 87371080
32	87312706	1	CLIP,
33	87315570	2	MOUNT, RUBBER, SPACER
34	87422371	2	CABLE,
35	86511315	4	WASHER, M8 x 16 x 1.6,
36	120104	2	BOLT, Hex, M8 x 20, 8.8,
37	86528579	2	NUT, LOCK, M8 x 1.25, Cl 10,
38	614-5020	2	BOLT, Hex, M5 x 20, 8.8, Full Thd,
39	895-11005	2	WASHER, M5 x 10 x 1,
40	832-10405	2	NUT, LOCK, M5 x .8, Cl 8,
41	827-10040	4	BOLT, Hex, M10 x 40, 10.9, Full Thd,
42	895-11010	4	WASHER, M10 x 20 x 2,

09-35 HOOD - LIFT ARM



09-35 HOOD - LIFT ARM

ссылка	Номер детали	Кол-во	Описание
1	339543A2	1	ARM, Lift, TJ380 /430, T9030 / 9040
1	87532171	1	ARM, SUPPORTING, , TJ480 / 530, T9050 / 9060
2	339551A1	2	BRACKET,
3	339547A1	2	CLEVIS, ADJUSTABLE,
4	339549A1	2	SPRING, COIL,
5	328754	2	BOLT, CARRIAGE, Short NK, M12 x 40, Cl8.8, Full Thd,
6	337475	2	NUT, M12, Cl 10,
7	86625255	2	WASHER, M13.5 x 24.5 x 3, HT,
8	V43471	4	BOLT,
9	86625253	4	WASHER, M11 x 24 x 2,
10	86500689	4	NUT, M10, Cl 10,
11	86625256	6	WASHER, M12 x 28.5 x 4, HT,
12	86639103	2	PIN, CLEVIS, M12 x 90, M2 X 90
13	130003	2	PIN, SPLIT (COTTER), M3.2 x 20,
14	313992A1	2	SPOOL,
15	320429A1	2	SPOOL,
16	86639115	4	PIN, SPLIT (COTTER), M2 x 12,
17	86639107	2	PIN, CLEVIS, M8 x 60, Clevis, M8 x 60
18	86639106	2	PIN, CLEVIS, M8 x 40, Clevis, M8 x 40

09-36 CENTER LINK



09-36 CENTER LINK

ссылка	Номер детали	Кол-во	Описание
	87384059	1	LINK, CONNECTING, Connecting, Inc. 1 - 4, T9050, T9030 / 9040, TJ480, TJ380 /430
	87384060	1	LINK, CONNECTING, Connecting, Inc. 1 - 4, TJ380 /430, T9030 / 9040, T9050 / 9060, TJ480 / 530
1	NSS	1	NOT SERVICED SEPARATELY, Link
2	435499A1	1	BEARING,
3	86637648	1	RING, SNAP, #354, Int, No. 354
4	435529A1	1	BUSHING,
5	195941A1	2	PIN, 1-3/4" x 8"
6	435501A1	2	SPACER,
7	896-11016	2	WASHER, M17.5 x 30 x 4, HT,
8	627-16040	2	BOLT, Hex, M16 x 40, 10.9,
9	219-1	1	NIPPLE, LUBE, 1/8"-27 x .66 lg,
10	219-36	1	NIPPLE, LUBE, 45є, 1/8" NPT x 7/8" lg,
11	D95143	2	SEAL,
12	87423436	1	COVER, Drive Shaft, LH
13	87423437	1	COVER, Drive Shaft, RH
14	895-11010	4	WASHER, M10 x 20 x 2,
15	627-10020	4	BOLT, Hex, M10 x 20, 10.9, Full Thd,
16	495-11053	4	WASHER, 1/2", SAE,
17	426-812	4	BOLT, Hex, 1/2"-13 x 3/4", G8, Full Thd, 1/2" NC x 3/4", CL8

09-37 REAR FRAME



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-37 REAR FRAME

ссылка	Номер детали	Кол-во	Описание
1	400676A1	1	FRAME,
2	433479A1	1	CAP, Fuel Fill, BSN Z7F202118
2	87555106	1	CAP FUEL, LOCKABLE, , ASN Z7F202118
3	80717	1	NIPPLE, LUBE, 45є, 1/8" NPT x 7/8" lg,
4	413188A1	2	CHANNEL,
5	86624184	8	WASHER, M8 x 16 x 1.6,
6	86625003	4	BOLT, Hex, M8 x 50, 10.9,
7	86528579	4	NUT, LOCK, M8 x 1.25, Cl 10,
8	384163A1	1	PLUG, PLASTIC, LH
9	426937A6	1	FENDER, REAR, LH
10	86639336	4	PLUG, Hex Hd, 1/8"-27 NPTF,
11	87311338	1	BEARING, Roller
12	330032A1	2	RING,
13	434069A1	2	SPACER,
14	394364A1	1	PIN, Pivot
15	433478A1	2	GASKET,
16	D95148	2	WIPER,
17	432444A1	16	SPACER,
18	430250A1	2	RETAINER,
19	43248	16	BOLT, Hex, M10 x 40, 10.9, Full Thd,
20	433480A2	2	COVER,
21	86637658	16	SCREW, Hex Hd, #10-32 x 1/2", G5,
22	426938A6	1	FENDER, REAR, RH
	433481A1	2	HOUSING, Bearing, Inc. 23, 24
23	NSS	2	NOT SERVICED SEPARATELY, Housing
24	NSS	8	NOT SERVICED SEPARATELY, Spacer
25	SFD014088	1	WASHER, 1-3/4 in.
26	86637665	1	NUT, Jam
27	86979890	8	GROMMET, 11/16" ID x 1" Groove Dia, Str Cut, 11/16"
28	321232A1	10	BUSHING, M10 x 35; 10.9
29	86625253	8	WASHER, M11 x 24 x 2,
30	86624979	2	BOLT, Hex, M10 x 75, 10.9,
31	86639030	2	BOLT, Hex, M10 x 70, 10.9, Full Thd,
32	43249	2	BOLT, Hex, M10 x 50, 10.9,
33	86500689	2	NUT, M10, Cl 10,
34	402769A2	1	PLATE,
35	86624176	2	WASHER, M10 x 20 x 2,
36	86624978	2	BOLT, Hex, M10 x 35, 10.9, Full Thd,
37	86528579	2	NUT, LOCK, M8 x 1.25, Cl 10,
38	413188A1	1	CHANNEL,
39	86625256	1	WASHER, M12 x 28.5 x 4, HT,
40	406390A1	1	HANDLE,
41	86977726	4	BOLT, Hex, M6 x 12, 8.8,
42	86517328	4	WASHER, LOCK, M6,
43	404287A1	4	INSERT,

сылка	Номер детали	Кол-во	Описание
44	86624181	4	WASHER, M6,
45	412250	4	NUT, LOCK, M8 x 1.25, Cl 8,
46	436218A2	1	SHIELD, LH
47	436162A2	1	SHIELD, RH, Not Illustrated
48	432280A1	1	LAMP, TAIL, Mounting, LH
49	432279A1	1	LAMP, TAIL, Mounting, RH, Not Illustrated
50	434066A1	2	SPACER,
51	434068A1	4	SPACER,
52	353-411	1	PLUG, Dome, 1.000" hole, Nylon, Not Illustrated, Used without Rear Fender Lamps
53	353-403	2	PLUG, Dome, .437" hole, Nylon, 7/16 in, Not Illustrated, Used without Rear Fender Lamps
54	627-10085	2	BOLT, Hex, M10 x 85, 10.9, Full Thd,

09-38 HEATER - HOSES, TJ380 / 430 & T9030 / 9040



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-38 HEATER - HOSES, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	86984542	1	END FITTING, Inc. 2
2	238-6018	1	O-RING, -018, 90 Duro, .739" ID x .070" Thk,
3	87271484	1	FITTING, Inc. 5 & 13
4	515-23159	2	CLAMP, 5/8", Insul, 3/8" Bolt,
5	8500571	1	SPACER,
6	87447841	2	HOSE, Supply, Cut From: 32-050
7	86984554	1	TUBE ASSY.,
8	895-11008	2	WASHER, M8 x 16 x 1.6,
9	43362	1	NUT, M8, Cl 10,
10	43233	1	BOLT, Hex, M8 x 20, 10.9,
11	82012722	4	CLAMP, HOSE, 1/2 - 29/32 dia
12	R54363	3	CLAMP,
13	87343576	1	BOLT, M7 x 45, CL8.8
14	217-144	1	ELBOW, 45є, 5/8" Hose x 1/2" NPTF Beaded,
15	87356804	1	HOSE, Return, Cut From: 32-050
16	86572009	1	CLAMP, 3/8", Insul, 3/8" Bolt,

09-40 AIR CONDITIONING SYSTEM, TJ380 / 430 & T9030 / 9040



09-40 AIR CONDITIONING SYSTEM, TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	86993463	1	COMPRESSOR, AIRCOND.,
2	87315600	1	CONDENSER,
3	433723A1	2	NO DESCRIPTION, Clamp
4	295006A1	1	RECEIVER-DRYER, 134a
5	87311553	1	HOSE, 2152 mm (84-3/4"), Inc. 6 - 9
6	128485A1	3	O-RING, 9/16 ID x 1/16
7	128483A1	3	O-RING, 5/16 ID x 1/16
8	128484A1	2	O-RING, 7/16 ID x 1/16
9	122554A1	1	CAP,
10	87580494	1	HOSE ASSY., 3165 mm (124-1/2"), Inc. 6, 12
11	87282333	1	BELT, Accessory Drive, Alternator & A/C
12	122553A1	1	CAP,
13	87437756	1	HOSE ASSY., 2418 mm (95"), Inc. 7, 8
14	86639011	3	CLAMP, J, 3/4", Insul, 3/8" Bolt,
15	9846677	1	BOLT, Hex, M10 x 25, 10.9, Full Thd,
16	87447519	1	HOSE ASSY., 2190 mm (86-1/4"), Inc. 7
17	86572009	1	CLAMP, 3/8", Insul, 3/8" Bolt, 3/8 ID
18	R54363	2	CLAMP,
19	86624005	1	CLAMP, 3/4", Insul, 3/8" Bolt,
20	86624184	14	WASHER, M8 x 16 x 1.6,
21	86624176	4	WASHER, M10 x 20 x 2,
22	9780069	2	BOLT, Hex, M8 x 40, 10.9,
23	43362	9	NUT, M8, Cl 10,
24	284273A2	1	SWITCH,
25	43234	3	BOLT, Hex, M8 x 25, 10.9,
26	86500689	3	NUT, M10, Cl 10,
27	86639005	1	CLAMP, 5/8", Insul, 1/2" Bolt,
28	9804258	4	BOLT, Hex Flg, M8 x 20, 8.8,
29	86505868	2	NUT, M8, Flg Ser,
30	619284	5	CLAMP, 15/16", Insul, 3/8" Bolt,
31	86512165	4	BOLT, Hex, M8 x 100, 10.9,

09-42 AIR CONDITIONING - DUCTS



09-42 AIR CONDITIONING - DUCTS

ссылка	Номер детали	Кол-во	Описание
1	87365878	1	AIR CONDITIONER, See Figure: 09-45
2	319970A3	1	HOUSING,
3	384950A2	1	BRACKET,
4	86624176	6	WASHER, M10 x 20 x 2,
5	86500689	6	NUT, M10, Cl 10,
6	359586A1	1	SEAL, Filter
7	43362	2	NUT, M8, Cl 10,
8	278967A3	1	GASKET, Mounting, Floor Plate
9	NSS	1	NOT SERVICED SEPARATELY, Blower Assy, Suction / Pressurizer, See Figure: 09-44
10	307024A4	1	HOSE, Output
11	87380071	1	HOSE, Air Intake
12	86994156	1	FILTER, AIR, Recirculation
13	86050202	4	CLAMP, HOSE, #32, 1.56/2.50 Type F Worm,
14	86508616	4	BOLT, Hex, M6 x 12, 10.9,
15	86625263	6	WASHER, M8 x 20 x 1.6,
16	86528579	4	NUT, LOCK, M8 x 1.25, Cl 10,
17	327851A1	1	DUCT,
18	359670A2	1	SEAL,
19	328051A2	1	INSULATION, FOAM, RH
20	328052A2	1	INSULATION, FOAM, LH

09-43 AIR CONDITIONING - AIR FILTER HOUSING ASSEMBLY



09-43 AIR CONDITIONING - AIR FILTER HOUSING ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
	319970A3	1	HOUSING, Air Filter, Inc. 1 - 9
1	NSS	1	NOT SERVICED SEPARATELY, HOUSING, Filter, Upper
2	319969A1	1	HINGE,
3	307016A1	1	COUPLING,
4	86625261	7	WASHER, M5 x 10 x 1,
5	359585A2	1	SEAL, Cut From : 87432208
6	307021A2	1	CLIP,
7	NSS	1	NOT SERVICED SEPARATELY, HOUSING, Filter, Lower
8	400193A1	1	LATCH,
9	86637655	7	RIVET, Pop, 3/16" x .450", 5/32 x 43/64

09-44 AIR CONDITIONING - BLOWER ASSEMBLY



09-44 AIR CONDITIONING - BLOWER ASSEMBLY

ссылка	Номер детали	Кол-во	Описание
1	307104A3	1	SUPPORT,
2	313282A1	1	SEAL, Cut From : 187874C1
3	175435A3	1	BLOWER, Suction / Pressurizer
4	86639262	5	SCREW, Cross Pan Hd, M5 x 8,

09-45 AIR CONDITIONING - CLIMATE CONTROL UNIT WITH AUTO TEMP CONTROL



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-45 AIR CONDITIONING - CLIMATE CONTROL UNIT WITH AUTO TEMP CONTROL

ссылка	Номер детали	Кол-во	Описание
	87365878	1	AIR CONDITIONER, Inc. 1 - 54
1	322996A1	1	BOX,
2	86990262	1	CORE, Evaporator and Heater, Inc. 3 - 5
3	386535A1	1	VALVE, Expansion
4	128485A1	1	O-RING, 9/16 ID x 1/16
5	128484A1	1	O-RING, 7/16 ID x 1/16
6	322994A1	4	GASKET, Mounting
7	87306776	1	CASE ASSY.,
8	1250522C3	2	ELBOW,
9	1977334C1	2	HOSE, 610 mm (24-1/8 in), Cut From : 198091CX
10	109239C2	2	VALVE, Check
11	86637781	1	GROMMET, 1" ID x 1 3/8" Groove Dia,
12	322989A1	1	GROMMET,
13	322990A1	1	GROMMET,
14	87324951	1	GASKET, Cover
15	87365492	1	MODULE, Blower Motor, 12V
16	323610A1	1	BLOWER,
17	322985A1	1	PIPE, Outlet
18	322987A1	1	PIPE, Inlet
19	87306495	1	COVER,
20	427356A1	1	VALVE, CONTROL, Regulator
21	322995A1	4	GASKET, Mounting
22	87306773	1	INSULATION, FOAM,
23	87306706	1	TERMINAL CONNECTOR, Linear Blower
24	324484A1	1	INSULATOR,
25	86517328	5	WASHER, LOCK, M6,
26	86508568	4	BOLT, Hex, M6 x 16, 8.8,
27	80681	4	WASHER, LOCK, 5/16",
28	43234	4	BOLT, Hex, M8 x 25, 10.9,
29	88538	1	WASHER, LOCK, Ext-Int Tooth, 1/4",
30	86500688	3	NUT, M6, Cl 10,
31	86637777	2	GROMMET, 1/2" ID x 13/16" Groove Dia, Diag Cut, 13/16 dia
32	1954736C1	6	CLAMP, HOSE, No. 24
33	87414866	1	RELAY, 20 AMP
34	87454442	1	SENSOR, Thermometer
35	323016A1	1	SENSOR,
36	87323958	1	HARNESS,
37	86625035	1	CLAMP, 1/2", Insul, 1/4" Bolt,
38	86637791	4	SCREW, SELF TAPPING, Hex Wash Hd, #10 x 3/4",
39	322839A1	1	PIPE, Suction, Inc. 40 - 43
40	128485A1	1	O-RING, 9/16 ID x 1/16
41	1250594C2	1	CORE,
42	128483A1	1	O-RING, 5/16 ID x 1/16
43	128485A1	1	O-RING, 5/8 ID x 1/16
44	322840A1	1	PIPE, Inc. 45, 46

09-45 AIR CONDITIONING - CLIMATE CONTROL UNIT WITH AUTO TEMP CONTROL

ссылка	Номер детали	Кол-во	Описание
45	128484A1	1	O-RING, 7/16 ID x 1/16 Thk
46	NSS	1	NOT SERVICED SEPARATELY, 5/16 ID x 1/16
47	368313A1	1	PLUG, PLASTIC,
48	1321290C2	1	HOSE, 127 mm (5 in), Cut From : 97252C1
49	324022A1	1	HOSE, 54 mm (2-1/8 in), Cut From : 97252CX
50	324023A1	1	HOSE, 64 mm (2-1/2 in), Cut From : 97252CX
51	87323829	1	SWITCH, PRESSURE, Low Pressure
52	87408707	1	FILTER, Recirculated Air
53	385681	1	NUT, LOCK, M4 x .7, Cl 8,
54	86637790	2	SCREW, SELF TAPPING, Hex Wash Hd, #8 x 1/2",

09-46 COMPRESSOR, AIRCOND.,TJ380 / 430 & T9030 / 9040





09-46 COMPRESSOR, AIRCOND.,TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	504078610	1	COMPRESSOR, AIRCOND., - ASSY, See Figure: 09-47
2	16598325	4	SCREW, M8X100 mm
3	504093239	1	
4	17097024	1	WASHER,
5	16692324	2	BOLT, M10X35 mm
5	504080093	2	BOLT,
6	504078624	1	BRACKET, SUPPORTING,
7	87282333	1	BELT, Accessory Drive, Alternator, Water & A/C

09-47 COMPRESSOR, AIRCOND. - COMPONENTS,TJ380 / 430 & T9030 / 9040





09-47 COMPRESSOR, AIRCOND. - COMPONENTS,TJ380 / 430 & T9030 / 9040

ссылка	Номер детали	Кол-во	Описание
1	8093816	1	CLUTCH,
2	42535660	4	COMPRESSOR, AIRCOND.,

09-48 MONITOR MOUNTING



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-48 MONITOR MOUNTING

ссылка	Номер детали	Кол-во	Описание
1	409391A2	1	MOUNTING PARTS, Window Monitor, RH
2	86624184	6	WASHER, M8 x 16 x 1.6,
3	43234	4	BOLT, Hex, M8 x 25, 10.9,
4	87530660	3	MOUNTING PARTS, Angle, Window
5	87526197	6	U-BOLT, 1/4 in, Inc. Nut
6	443908A1	1	TUBE, Mounting
7	7770	12	NUT, 1/4"-20, G5,
8	369275A1	1	TUBE, A-Post Monitor
9	9780069	2	BOLT, Hex, M8 x 40, 10.9,
10	371838A1	2	SPACER,
11	719516003	1	KIT, Window Monitor, RH, Inc. 1 - 5, 7
12	353-408	2	PLUG, Dome, .750" hole, Nylon,

09-49 STORAGE BOX



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-49 STORAGE BOX

ссылка	Номер детали	Кол-во	Описание
1	87325332	1	BOX,
2	435534A1	1	HINGE,
3	87307236	1	STEP,
4	86624181	14	WASHER, M6,
5	393392	7	NUT, LOCK, M6 x 1, Cl 8,
6	86639037	7	BOLT, Hex, M6 x 16, 10.9,
7	86624176	12	WASHER, M10 x 20 x 2,
8	9846677	6	BOLT, Hex, M10 x 25, 10.9, Full Thd,
9	86500689	6	NUT, M10, Cl 10,
10	410814A1	1	BRACKET, , Without Weights
11	410815A2	1	BRACKET, , Without Weights
12	87301185	1	STEP, Lower
13	274251	8	BOLT, Hex Serr Flg, M10 x 25,
14	43435	8	NUT, M10, Flg Ser,
15	86625256	3	WASHER, M12 x 28.5 x 4, HT,
16	9824642	3	BOLT, Hex, M12 x 35, 10.9,
17	410817A1	1	BRACKET, , With Weights
18	86624177	3	WASHER, M12 x 24 x 2.5,
19	9824642	3	BOLT, Hex, M12 x 35, 10.9,
20	410816A1	2	BRACKET,
21	87307237	3	STRIP, ANTI-SKID,

09-50 WEIGHTS - FRONT FRAME



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-50 WEIGHTS - FRONT FRAME

ссылка	Номер детали	Кол-во	Описание
1	413310A1	1	HANGER, , T9030 / 9040, TJ380 /430
1	87433786	1	HANGER, , TJ480 / 530, T9050 / 9060
2	86625260	14	WASHER, M20 x 37.5 x 4, HT,
3	86639145	10	BOLT, Hex, M20 x 130, 10.9,
4	413312A1	2	INSERT, Nine Weight
5	86500689	2	NUT, M10, Cl 10,
6	413313A1	2	BRACKET,
7	86639034	4	BOLT, Hex, M16 x 320, 10.9, Full Thd,
8	87309541	1	PLATE, Weight, RH
9	9843495	4	BOLT, Hex, M20 x 60, 10.9,
10	87309542	1	PLATE, Weight, LH
11	86508619	2	BOLT, Hex, M10 x 60, 10.9,
12	229483A1	4	RETAINER,
13	86639326	4	WASHER, M17.5 x 34 x 5, HT,
14	403140A1	AR	WEIGHT, 45Kg (100 lb)
15	413316A1	2	GRAB RAIL,
16	86625252	4	WASHER, M10 x 21.5 x 2.5, HT,

09-51 WEIGHTS - REAR FRAME



09-51 WEIGHTS - REAR FRAME

ссылка	Номер детали	Кол-во	Описание
1	413389A1	1	WEIGHT, , Order From Machinery Price List
2	413390A1	2	BRACKET,
3	413391A2	2	BRACKET,
4	413392A2	2	PLATE,
5	86625260	24	WASHER, M20 x 37.5 x 4, HT,
6	9846950	8	BOLT, Hex, M20 x 90, 10.9,
7	412641	6	BOLT, Hex, M20 x 70, 10.9,
8	9847024	8	NUT, M20, Cl 10,
9	9843612	2	BOLT, Hex, M20 x 100, 10.9,
10	413393A1	2	PLATE,
11	374835	4	BOLT, Hex, M16 x 40, 10.9,
12	403140A1	AR	WEIGHT, 45Kg (100 lb)

09-52 WEIGHTS - WHEEL



09-52 WEIGHTS - WHEEL

ссылка	Номер детали	Кол-во	Описание
1	405829A1	2	WEIGHT, 500 lb, Order From Machinery Price List
1	405830A1	2	WEIGHT, 1000 lb, Order From Machinery Price List
2	86625266	12	WASHER, M17.5 x 30 x 4, HT,
3	412066	6	NUT, LOCK, M16 x 2, Cl 8,
4	86639152	6	BOLT, Hex, M16 x 200, 10.9, , Use With 500 lbs. Weight
4	43281	6	BOLT, Hex, M16 x 120, 10.9, , Use With 1000 lbs. Weight

09-53 TOW CABLE



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-53 TOW CABLE

ссылка	Номер детали	Кол-во	Описание
1	369837A1	1	SHACKLE,
2	86637794	1	BOLT, Hex, 1 1/2"-6 x 10", G8,
3	86637798	1	NUT, 1 1/2"-6, G8,
4	408793A1	1	PLATE,
5	409753A1	1	LINK,
6	369838A1	1	SHACKLE,
7	86625260	4	WASHER, M20 x 37.5 x 4, HT,
8	9843612	4	BOLT, Hex, M20 x 100, 10.9,
9	379523A1	1	CABLE ASSY.,
10	408795A1	1	HOOK, Side
11	435501A1	1	SPACER,
12	408796A1	1	LATCH, Side Hook
13	86639326	7	WASHER, M17.5 x 34 x 5, HT,
14	374835	1	BOLT, Hex, M16 x 40, 10.9,
15	86639102	1	SPLIT PIN/SAFETY PIN, Clevis, 12 x 40 mm
16	435425A1	1	PIN, 1/8
17	385380A1	1	PLATE ASSY.,
18	9847468	3	BOLT, Hex, M16 x 70, 10.9,
19	409751A1	4	SPACER, M20 x 40, with 450 Series Axle
20	719546003	1	KIT, Tow Cable, Inc. 1 - 19

09-54 FIRE EXTINGUISHER



TJ430 TRACTOR (1/06-) - Chassis/Attachments

09-54 FIRE EXTINGUISHER

ссылка	Номер детали	Кол-во	Описание
	719972003	1	DIA KIT, TRACTOR, Fire Extinguisher, Inc. 1 - 9
1	43248	2	BOLT, Hex, M10 x 40, 10.9, Full Thd,
2	9515003	6	BOLT, Hex, M10 x 30, 10.9, Full Thd,
3	86625253	14	WASHER, M11 x 24 x 2,
4	412141	8	NUT, LOCK, M10 x 1.5, Cl 8,
5	NSS	1	NOT SERVICED SEPARATELY, Extinguisher, Fire, 10 lb., ABC
6	1980543C1	1	SPLIT PIN/SAFETY PIN,
7	87417139	1	BRACKET, SUPPORTING, Left-Hand Stair Mount, If Used
8	87427312	1	BRACKET, SUPPORTING, Fender Mount, If Used
9	87420884	1	BRACKET, SUPPORTING, Toolbox Mount, If Used

1
TJ380 New Holland
2
New Holland TJ380
3
TJ430 New Holland
4
New Holland TJ430
5
TJ480 New Holland
6
New Holland TJ480
8
TJ530 New Holland
9
New Holland TJ530
7
HD

09-55 DECALS - HOOD

ссылка	Номер детали	Кол-во	Описание
1	87365216	1	DECAL, Hood, LH, TJ380
2	87365220	1	DECAL, Hood, RH, TJ380
3	87365221	1	DECAL, Hood, LH, TJ430
4	87365222	1	DECAL, Hood, RH, TJ430
5	87365223	1	DECAL, Hood, LH, TJ480
6	87365224	1	DECAL, Hood, RH, TJ480
7	441882A1	2	DECAL, Heavy Duty, TJ380
8	87365225	1	DECAL, Hood, LH, TJ530
9	87365226	1	DECAL, Hood, RH, TJ530

1
TJ380
New Holland
2
New Holland
TJ380
3
TJ430
New Holland
4
New Holland
TJ430
5
TJ480
New Holland
6
New Holland
TJ480
7
TJ530
New Holland
8
New Holland
TJ530
9
HD

09-55(01) DECALS - HOOD

ссылка	Номер детали	Кол-во	Описание
1	87602237	1	DECAL, Hood, LH, TJ380
2	87602238	1	DECAL, Hood, RH, TJ380
3	87602241	1	DECAL, Hood, LH, TJ430
4	87602242	1	DECAL, Hood, RH, TJ430
5	87602244	1	DECAL, Hood, LH, TJ480
6	87602246	1	DECAL, Hood, RH, TJ480
7	87602247	1	DECAL, Hood, LH, TJ530
8	87602249	1	DECAL, Hood, RH, TJ530
9	441882A1	2	DECAL, Heavy Duty

09-57 DECALS

1

⚠ WARNING

AVOID INJURY
OR DEATH

BEFORE STARTING ENGINE:

1. Read the operator's manual for safety information and operating instructions.
2. Read all tractor safety signs.
3. Be sure other people are clear of tractor and equipment.
4. Start engine only from seat.
5. Shields are for your protection. Keep them in place.

OPERATION:

1. Always buckle and adjust seat belt.
2. No riders on tractor or equipment.
3. Training seat for training operators only, do not allow children to ride or operate tractor.
4. Keep hands, feet and clothing away from power driven parts.
5. For road travel, use flashing warning lamps and keep the SMV emblem visible.
6. Do not pull with elastic tow ropes. Elastic stores energy and sudden release will cause an uncontrolled rope recoil.
7. Stay clear of hinge area when engine is running. Never turn steering wheel unless everyone is clear of equipment.

TRACTORS CAN BE UPSET:

1. Reduce speed on turns and rough ground. Avoid steep slopes.
2. Avoid rear upset. Pull only from drawbar, never higher.

WHEN TRACTOR HAS STOPPED:

1. Engage park brake.
2. Lower implement to ground.
3. Disengage PTO, stop engine and wait for all movement to stop before servicing or cleaning equipment.

329105A1

2

⚠ WARNING

NO CLEARANCE FOR
PERSON WHEN
TRACTOR TURNS



TO PREVENT PERSONAL INJURY:

Stay clear of hinge area when engine is running.
Shut off engine before servicing hinge area.
Install articulation cylinder locking blocks before lifting tractor, transporting tractor on another vehicle, performing maintenance in hinge area or operating stationary PTO equipment.
Be sure to remove locking blocks before driving tractor.
Keep driveline shields in place.

3



4



5



6



7



9



09-57 DECALS

ссылка	Номер детали	Кол-во	Описание
1	325926A2	1	DECAL, Safety Warning
2	341953A2	2	DECAL, Articulation Warning
3	435668A1	1	DECAL, Fuel
4	327567A3	1	DECAL, Power Takeoff, Warning
5	404992A1	1	DECAL, New Holland
6	87516902	1	DECAL, Fuse, Power Shift Transmission
7	87371088	1	DECAL, Fuse, Manual Shift Transmission
8	9847773	2	NUT, Flg, M5 x .8
9	387030A1	1	DECAL, Main Electronics

1



4



10



12



17



2



11



9





09-58 DECALS

ссылка	Номер детали	Кол-во	Описание
1	431230A1	1	DECAL, Light Panel
2	434856A1	1	DECAL, Hydraulic Oil Level
3	281032	2	BOLT, Hex, 1/4"-20 x 3/4", G8, Full Thd,
4	87450974	1	DECAL, Climate Control, With Automatic Temperature Control
	311860A1	1	EMBLEM, Slow Moving Vehicle, Inc. 4, 5
5	NSS	1	NOT SERVICED SEPARATELY, Plate
6	311858A1	1	DECAL,
7	87361	2	WASHER, 1/4", SAE,
8	7770	2	NUT, 1/4"-20, G5,
9	87403322	1	DECAL, Insert, Without Power Takeoff
10	87314394	1	DECAL, RH Armrest, Without Three Point Hitch
11	399083A1	1	DECAL, Coolant
12	393821A1	1	DECAL, Three Point Hitch
13	431187A1	1	BRACKET,
14	43248	2	BOLT, Hex, M10 x 40, 10.9, Full Thd,
15	86624176	4	WASHER, M10 x 20 x 2,
16	86514720	2	NUT, LOCK, M10 x 1.5
17	329051A1	1	DECAL, Emergency Exit

1

MPH LOW	MPH HIGH	GEAR	RANGE
2.5	2.6	1	A
3.3	3.6	2	A
4.1	4.4	1	B
4.6	4.9	3	A
5.6	6.0	2	B
6.5	7.0	1	C
7.6	8.2	3	B
8.8	9.5	2	C
10.3	11.0	1	D
12.1	13.0	3	C
13.9	14.9	2	D
19.0	20.4	3	D
3.5	3.8	R	A
5.9	6.3	R	B
9.3	10.0	R	C

2



3



11



4



5



6



7

8

9



10



12

13

09-59 DECALS

ссылка	Номер детали	Кол-во	Описание
1	411564A1	1	DECAL, Range / Gear Shift, 24 Speed, With Manual Shift Transmission
2	431156A2	1	DECAL, Maintenance
3	410704A1	1	DECAL, Instruction Seat
4	87427097	1	DECAL, DANGER, Battery
5	87423866	1	DECAL, Remote Hitch Safety
6	82029421	1	DECAL, WARNING, Radiator Pressure
7	87427096	1	DECAL, Pos. (+) Post
8	87427317	1	DECAL, Neg. (-) Post
9	389794A1	1	DECAL, Hydraulic Coupler, Black, 5 Spool Application
9	432771A1	1	DECAL, Hydraulic Coupler, Green
9	432772A1	1	DECAL, Hydraulic Coupler, Blue
9	432773A1	1	DECAL, Hydraulic Coupler, Ginger
9	440438A1	1	DECAL, Hydraulic Coupler, Grey
10	418215A1	1	DECAL, Ignition Switch
11	87368125	1	DECAL, WARNING, Front Weights
12	A187743	1	DECAL, WARNING, Ground Speed Radar
13	8603092	1	DECAL, WARNING, Ether, T9030 / 9040, TJ380 /430